

HP 82481A Circuit Analysis Pac Owner's Documentation Addendum

When you do not have an HP-IL module plugged into your HP-71B, and you attempt to print the current circuit (using the Pr routine in the main menu), the program stops and displays the following error message:

```
ERR L37: XWORD Not Found
```

The program is suspended. To proceed, type:

```
CONT 38 ENDLINE
```

The program continues and displays the circuit elements (instead of attempting to print them).



Portable Computer Division
1000 N.E. Circle Blvd., Corvallis, OR 97330, U.S.A.

European Headquarters
150, Route du Nant-D'Avril
P.O. Box, CH-1217 Meyrin 2
Geneva-Switzerland

HP-United Kingdom
(Pinewood)
GB-Nine Mile Ride, Wokingham
Berkshire RG11 3LL