

# HP42S BDM Slope Staking



#### NOTICE

No express or implied warranty is made by D'Zign Land Survey & Development or the author with regard to the procedures and program material offered or their merchantability or their filness for any particular purpose. The keystroke procedures and program material are made available solely on an "as-is" basis, and the entire risk as to their quality and performance is with the user. Should the procedures or program material prove defective, the user (and not D'Zign Land Survey & Development nor any other party) shall bear any and all cost of all necessary correction and all incidental or consequential damages. D'Zign Land Survey & Development and/or the author shall not be liable for any incidental or consequential damages in connection with or arising out of the furnishing, use, or performance of the keystroke procedures or program material.

## HP42S EDM Slope Staking

Library of Congress Catalog Card No. 89-81214 ISBN 0-944889-08-5

Manufactured in the United States of America

Copyright<sup>©</sup> 1990 by Ted J. Kerber

All rights reserved. No part of this work covered by the copyright hereon may be reproduced or used in any form or by any means - graphic, electronic, or mechanical, including photocopying, recording, taping or information storage and retrieval systems - without written permission of the author.

published by DZign Land Survey & Development Glendale, California, U.S.A. 1990

ISBN 0-944889-08-5

#### TECHNICAL ASSISTANCE

The program material, instructions and procedures contained in this book assume that the user has a working knowledge of both surveying and the general operation of the HP-42S calculator.

Technical assistance is limited to verification of the results shown in the various examples used in the book.

If you have any questions or suggestions regarding this book or other **D'Zign** publications, please feel free to call us. The number is (818) 507-7408, and someone is available to answer technical questions from 3:00 A.M. to 5:30 A.M. and from 4:30 P.M to 6:30 P.M. (Pacific time), as a service to users from other time zones.

This software and book are both protected by U.S. Copyright Law (Title 17 United States Code). Unauthorized reproduction and/or sales may result in imprisonment of up to one year and fines of up to \$10,000 (17 USC 506). Copyright infringers may also be subject to civil liability. Hewlett-Packard has produced a really powerful calculator at a very good price, the HP-42 Scientific Calculator, which lends itself nicely to solving surveying problems. It can not be programmed by insertion of a module, or with a card reader, like the HP-41 series, but it has a really simple system for typing in a program.

#### the operations index

To find a function for the first time, HP has provided an "Operations Index" on pages 310 through 335 of the instruction manual, which tells you exactly what keystrokes to use to type in the function you want.

Even better, this index gives you the page number that you can refer to if you want to know more about the function you are using. If, while typing in a program, you aren't sure how to input a particular function, simply refer to the Operations Index.

#### the softkey menus

All of the programs in this booklet take advantage of the "softkey" menu system built into this calculator. When you want to start a program you stroke **XEQ** and then the softkey corresponding to the program you want, from the menu displayed in the bottom half of the screen.

#### the programs

There are several different ways to slope stake, and we've tried to make this program as convenient as possible for everyone. You can use it as is, or maybe change some of the output labels to match what is used in your particular area.

The main program is set up to allow setting of a catch point at any convenient location, and the station at which the stakes are set is output. There is also a subroutine which lets you precalculate the angle and distance to a specific station, at any offset, to begin at.

It's a good idea to take your time with the input of the program steps, to avoid errors. You might also want to do the programming in stages, rather than all at one sitting. Be extra careful with the proof-reading.

#### sub**r**outines

Because of the way the calculator works, we will start by input of some subroutines.

Once the subroutine has been input, its name appears in the menu when you stroke E, and all you have to do to add it as a step in the program you are typing in is stroke GTO or XEQ followed by keystroking the key corresponding to the subroutine to input the program step GTO XXX or XEQ XXX.

#### getting started

Begin by stroking the shift key, then the **XEQ** key. The display will show a menu which will be blank (if you haven't yet input any programs) except for .END. on the left. The keys just below each of the menu portions will correspond to the menu instruction above it. Stroke the key just below the .END. in the display. 00 { 113-Byte Prom } 02 "YES" 03 KEY 1 GTO 01 04 "NO" 05 KEY 2 GTO 02 96 MENU 07 STOP 081LBL 01 09 SF 10 10 GTO 03 111LBL 02 12 CF 10 131LBL 03 14 CLMENU 15 EXITALL 16 RTN

00▶( 0-Byte Prgm ) 01 .END. Next, go into **program mode** by stroking the shifted **NS** key, and you should have a display similar to the one shown to the left. Begin typing in the program "**YN**".

#### quick tip

Program steps 03 and 05 use a function which stores the prompt to the menu, and at the same time assigns the key.

To access the function, stroke PGM.FCN 🔼 🛄

You'll receive a prompt, **KEY\_**. Stroke the key number (we'll use 1 as the example), and you will get a prompt, **KEY 1 GTO\_\_**. Now type in the 01.

#### next subroutine

This one has three steps we might want to review before you start:

- 09 ARCL ST X То use а store or recall function involving the stack, stroke **sto** (or RCL) This brings up a menu from which you can select the function to complete the program step.
- Third row down, second from the right, 05 1E2 is a key, 🔳 . Stroke this key, then the number (in this case 2). Nothing will happen until you input the next step, usually 'times' or 'divide'.
- 11 ⊢"+" The  $\vdash$  symbol is "append", which adds to what is already in the alpha register.

01ÞLBL "STA" 02 CF 29 03 FIX 00 04 STO 21 This program changes the output of the stationing to really read like It takes up 48 bytes of stationing. memory.

> After you've input the program make sure to proof read it. Look, in particular, for steps that are alpha but shouldn't be, or should be alpha and aren't.

> Follow the same procedure to begin the input as with the first subroutine, "YN", and type in the steps. When you input the END at step 22, do it by stroking XEQ before going into alpha mode to type in the rest.

#### testing

21 FIX 22 END FIX 04

05 1E2 06 07

08 IP

09 10

11

12 13

17

18 19 20

ENTER

**⊢**"+"

1E2 14 X 15 16 10

X>Y?

Ê'ø'

FIX Ø3

ARCL ST X

ARČL ST Y RCL 21 SF 29

After you do the proof-reading, you can give it quick check, to see if it's working properly. First, clear the alpha register, then input 1204.78 and execute the Now, if you go into alpha mode, or execute program. AVIEW, the display portion should read as 12+04.780.

If you go to the program, "STA", which was just input and scroll up to 00, you can begin the next subroutine. When you input the last step, END, the calculator will automatically divide the two programs.

You could also use a RTN, instead 01▶LBL UL 02 ∑REG 00 CL∑ "CL1" of END as step number 15. This leaves the two programs together but, since 03 CLΣ 04 ΣREG 11 neither of them uses any subroutine ČLΣ Zręg 22 05 lables, they will both still work properly. 06 07 ĈĽΣ RTN 08 RTN 09€LBL "CL1" is а register clearing "FCL" 09PLDL 10 0.013 FN The other, "FCL", clears all routine. of the flags 00 through 13. 12 CF IND ST X 13 ISG ST X 14 GTO "FN" This group of programs uses 44 15 END bytes of memory for both programs.

By now you should be familiar with most of the strokes used in the programming. The next subroutine (below) outputs angles labeled with the <sup>o</sup>, ' and " symbols.

All of these subroutines can be used with other programs. In this one, if flag 19 is set the program clears the alpha register before it starts. When flag 19 is clear alpha labels ahead of the numeric portion are retained.

01€LBL "DMS	5 14	ABS	27 XEQ 01
02 FS?C 19	15	STO 18	28 ARCL ST X
03 CLA	16	IP	29 F <sup>wnm</sup>
04 ENTER	17	XEQ 01	30 CLX
05 STO 19	18	ARCL ST X	31 FIX 04
06 IP	19	F	32 SF 29
07 CF 29	20	RCL 18	33 RCL 19
08 FIX 00	21	FP	340LBL 01
09 ARCL ST	X 22	100	35 10
10 ⊢"""	23	X	36 X(>Y
11 -	24	FIX 02	37 X(Y?
12 100	25	RND	38 F"0"
13 X	26	FIX 01	39 END

Take a few minutes to look the program over after you finish with the input. Like "STA", "DMS" may be checked by using it. Input 12.34567 and stroke **EP INF**. If you execute AVIEW, or go into alpha, the display should be 12°34'56.7". If it isn't, something is wrong with one or more of the program steps. When a program is long it runs slower. The search for a specific label goes all of the way around the loop until it comes to the label it's looking for. For this reason, the input prompting sequences have been set up as a separate program, "INPT", which is the next to be put in.

#### important strokes

The symbol,  $r_{\rm s}$ , is "line feed", and we use it to control the display (the first time we use it is at program step 04). You can input it by stroking



This time, put the program in at the permanent .END. and it will have the secondary effect of removing .END. from your GTO/XEQ menu. The programs should be grouped in such a way that the ones you use most often appear in the first menu, for convenience. Enter **program mode** and scroll up to 00 to begin.

00 { 512-Bute Prgm } 01 LBL 1 INPT 29 CL 03 "Instrument" 31 XX 04 +" station?\" 32 36 05 PROMPT 33 + 06 STO 05 34 ST 07 "Offset?\" 35 "I 08 PROMPT 36 PR 09 STO 06 37 ST 10 RCL 05 38 "P 11 X<0? 39 PR 12 XEQ 06 40 ST 13 "Backsight" 41 ST 13 "Backsight" 42 EN 15 PROMPT 43 ENC 15 PROMPT 44 EN 15 PROMPT 45 PR 16 STO 03 44 C 17 "Offset?\" 45 PR 18 PROMPT 46 + 19 STO 04 48 R+ 19 STO 04 48 R+ 19 STO 04 48 R+ 21 X<0? 50 PR 22 XEQ 02 51 + 23 RCL 03 51 + 24 RCL 04 55 1E 25 PR 26 X <yy 1e<br="" 55="">27 RCL- 05 56 ÷</yy>	X 9 0 0 0 0 0 0 0 1 0 0 1 0 1 0 0 0 0 0 0 0 0 0 0 0 0 0
--	--

ABS RCL+ STO 104 105 STO 10 CF 21 "Ve<u>rt</u>ical Curve?" 152 RCL+ 14 57 15 153 →REC Š8 106 107 2**4** 13 154 +/-59 60 ŘĊĹ RCL+ F5? +/-155 156 157 14 AVIEW SF 21 108 ABS 05 61 109 2 62 63 ČLMENU XEQ "YN" 110 111 112 113 XEQ "YN" FC? 10 GTO 09 SF 04 "B.V.C." F" Station?4" ÷ 158 RTN TAN 1590LBL 05 64 65 66 67 RCL× 14 160161162163164165166167RCL 14 26 STO ΡI 114 \_ x STO 25 115 RCL RCL XEQ 15 68 116 RCL 117 STO+ 118 RTN 119 LBL 15 26 03 69 77 77 77 77 77 75 76 PROMPT STO 16 "Length V.C.?\" PROMPT STO 17 "Grade Out?\" DOOT ØŠ RCL 04 01 XEQ 04 120 121 122 123 124 125 126 127 128 127 128 129 131 132 133 133 R∓ STÖ X<>Y RCL+ 168 169 170 Ū4 CLX RCL 14 170 RCL 171 STO 172 RTN 173 LBL 173 LBL 174 +/-175 STO 176 XEQ 177 XEQ 178 RTN 179 LBL 180 PTN 15 PROMPT ΡI 03 1E2 x 77 78 79 RCL RCL XEQ RCL 15 06 STO 09 GTO 09 05 03 80€LBL 81 CF 05 00 06 CF 01 "B.C. PROMPT X<0? SF 01 X<0? +/-XEQ STO X<>Y RCL+ STO 00 04 82 station?4" 01 **0**6 83 09 84 15 85 86 87 01 05 181 182 183 RTN RTN CLMENU CF 01 CF 21 "NEXT" AVIEW 135€LBL 136 +/-02 136 137 138 139 140 88)LBL 07 184 89 CLMENU STO XEQ XEQ RTN 03 185 186 187 STO 15 FS? 01 RTN "Radius?4" 90 00 05 91 92 93 94 SF B 21 KEY 1 GTO KEY 1 GTO KEY 6 GTO MENU 188 141 LBL 03 188 B.C 189 KEY 190 "END 191 KEY 192 MENU 193 STOP 194 LBL PROMPT STO 14 "Delta?4" 07 142 9Ś +/-143 96 08 144 180 97 PROMPT 145 146 147 х X<>A 98 99 →HR X<0? SF 05 STO 1 08 95 100 +/-RTN 1 148 196 197 198 149€LBL 150 FC? SF 101 13 01 04 102 103 ĞTO 07 →RAD 05 RCL× .END. 14 151 +/-

Proof read the program at least once, looking for typos. One quick check is to execute the program and run/stop through the prompts. This will check the **sequence** of the prompts, and should run as follows: First, execute "INPT", to bring up the first prompt.

stroke we after each of the prompts appears, until you get to the beginning of the prompts for the vertical curve.

Answer this one "yes" to bring up the remaining vertical prompts, and finally, the prompt for "**NEXT"** and the prompt bar for selection of either an ending point or a B.C. station.

When you stroke **vs** at this prompt the display should clear. Go into program mode, and your program pointer should be at step 93, "Radius?4".

Exit and stroke we twice to bring up the next prompt, and continue. A we after "Delta?" will not bring up another prompt. If you go into program now, you should be at step 120, LBL 01.

#### the main program, "SS"

The best place to put this next program is at the bottom of "INPT". GTO "INPT" and enter **program mode**. Scroll upward 3 times, to put the pointer at step 197, GTO 07, and type in the first step of the new program, LBL "SS".

Next, scroll upward to GTO 07 again, stroke **E** and then enter **alpha mode** and type in "END". This separates the programs and positions the new one correctly. Leave **program mode** and GTO "**SS**" to input the rest of the program listing which begins on page 8.

Take your time with the programming, because this is a rather long one, and extremely difficult to debug.

Instrument Station?	<b>0</b> /S
Offset?	R/S
Backsight Station?	
Offset?	073
Inst. H.I.?	
Profile Elev.?	
Cut Factor?	N/ 5
Fill Factor?	D/S
% Grade?	
Vertical Curve?	RZS
YES NU	
B.V.C. Station?	
Length V.C.?	R/S
Grade Out?	R/S
NEXT	
B.C. [	
🗌 🗾 🥵 93 "Radius?4"	N/ 5
EXIT R/S	R/S
Radius?	B/S
Delta?	R/S
R/S 120€LBL 01	
	EXII

1008-Byte Pr9m ) BL SS CF 22 EQ "CL1" 56 STOP EQ\_"FCL" 57▶LBL 06 EQ\_"FCL" 58 STO 30 109 FS?C 06 { 00 110 GTO 10 01 LBL 02 XEQ 03 XEQ 111 STO 12 112 113 Ř↓ X<>Y CLST SF 01 XEQ "INPT" 04 59 CLA 60 CF 21 61 XEQ "STA" 114 →HR 05 115 116 117 RCL+ X(>Y →REC 07 06 61 XEQ "STA" 62 AVIEW 63 SF 21 64 STOP 65 ►LBL 14 66 RCL+ 33 67 STO 27 68 STO 20 69 STOP 70 ►LBL 25 71 RCL+ 33 72 STO 28 73 STO 20 74 STOP 75 ►LBL 17 07€LBL 00 08 CLX CLMENU HKEY 1 GTO 01 "ZK" 2 GTO 01 118 RCL+ 05 Ö9 STO 30 X<>Y 119 10 120 121 122 123 124 125 11 ŘĊĹ+ 0 STO 31 X<>Y 12 13 06 KĚÝ 2 GTO 01 "S.D." KEY 3 GTO 01 "C" 14 ŔĊĹ X≦Y? 24 15 16 17 **КЕ́Х 4** СТО 126 127 128 129 130 131 132 133 134 135 GTO 08 С CLX 18 RCL FS? GTO X>Y? KEY 5 ROD 15 19 GTO F 20 74 STOP 75 LBL 17 76 FIX 02 77 CLA 78 "RP Elev = 79 ARCL ST X 80 F"5" 01 21 22 23 24 KEY 6 KEY 7 11 GTO A KEY 7 KEY 8 KEY 9 GTO 02 GTO 02 GTO 03 GTO 11 ĞŤŌ X<>Y F5? 05 25 MENU 260LBL 27 STO 04 260LBL 04 27 STOP 28 GTO 04 290LBL 02 30 CLMENU 31 STA 32 KEY 1 GTO 06 33 "0/S" 34 KEY 2 GTO 07 35 "-USE-" 36 KEY 3 GTO 12 RCL- 12 +/-81 136 137 138 +7-82 83 84 85 85 x∑0? ⊢"+" RCL- 14 +/-84 F"+" 85 ARCL ST X 86 F" P 87 ARCL 34 88 F" to S.S." 89 AVIEW 90 CF 06 91 ADV 92 GT0 89 139 +POL 140 +/-RCL+ 1 FS? 05 +/-141 14 142 143 35 36 37 144 145 146 \$ΤΟ 31 X<>Y KEY 3 GTO 12 "NEWC" KEY 4 GTO 14 "NEWF" KEY 5 GTO 25 "RFF" 91 GTO 00 92 GTO 00 930LBL A 94 SF 03 95 FC? 22 ℃ RCL 01 22 ÷RAD 38 39 40 147 RCLX 14 RCL+ 148 15 KEY 5 REF KEY 6 STO 30 RCL\_24 149 41 ŘĊĽ X≟Y? 150 151 152 153 154 155 156 157 158 159 RCL FS? +/-96 97 FS? 98 +/-99 STO 01 100 R+ 101 X<>Y +HR 42 GTO 09 KEY KEY MENU 43 44 45 7 GTO 00 ĜŦĊ 08 8 GTO 00 R+ X<>Y F5? 05 4<u>6</u>▶L<u>B</u>L\_05 STOP 47 +/-÷ĤR x<≻y 48 GTO 05 490LBL 03 50 CLMENU 51 EXITALL 52 STOP 53 RTN X 103 105 104 105 106 107 →REC RCL+ 11 RCL+ 01 FS? 06 ENTER 51 EXITAL 52 STOP 53 RTN 54€LBL 01 GTO 11 160 RTN 161▶LBL 27 162 RCL 08 108 XEQ 17

 

 "W/2 = "
 217 LBL 29
 24

 PROMPT
 219 X)0?
 219 X)0?

 PROMPT
 220 RTN
 221 -1

 SF 08
 222 STOX 00

 RCL 29
 223 RTN

 ENTER
 225 FIX 01

 Y="?"
 226 CLA

 CF 08
 227 "FILL "

 R+
 228 RCL 02

 FIX 00
 229 X(0?

 CF 29
 230 "CUT "

 FS 08
 232 ARCL ST X

 "Slope Ratio = "
 233 F"4"

 "Slope Ratio = "
 233 F"4"

 "Slope Ratio = "
 233 F"4"

 "Sto 29
 240 RCL 30

 SF 21
 236 GF 03

 PROMPT
 237 AVIEW

 FIX 02
 238 CF 03

 SF 29
 239 RCL 32

 STO 29
 240 RCL 30

 RCL 12
 242 LBL 11

 STO 02
 243 RV

 RCL 23
 244 CLA

 RCL 31
 248 FIX 02

 X(0?
 249 X)0?

 +/ 250 GTO 13

 251 +/ 

 STO 00
 253 RCL ST X

 CLA
 257 A 271 H"%at " 272 ARCL ST X 273 H" Right" 274 GTO 15 165 2/5 LBL 28 276 RCL 30 277 F5? 04 278 GTO 21 279 LBL 26 280 RCL 30 281 RCL- 05 282 RCL× 10 283 RCL 20 284 LBL 24 285 + 286 STO 23 287 F "Grade 288 ARCL ST 289 FC? 03 299 AVIEW 291 ADV 292 F5? 03 299 AVIEW 291 ADV 292 F5? 03 299 STO 34 300 R+ 301 RCL+ 31 302 LBL 07 303 RCL- 06 304 RCL 30 305 RCL 24 306 X≦Y? 307 GTO 20 308 CLX 309 RCL 15 310 X≦Y? 311 XEQ 315 →POL 316 LBL 16 315 →POL 316 LBL 18 317 FIX 02 318 "DIST = " 320 F"4" 321 FIX 04 322 CLX 323 X<>Y 324 PC' 169 170 171 172 173 174 175 176 177 178 179 186 191 192 195 196 199 206 207 208 212 212 CF 213 AVI 214 SF 215 XEQ 216 RTN

325 X ¥Y? 326 360 327 + 328 → HMS 329 + "∡ = 1 330 XEQ "DI 331 AVIEW 332 ADV 333 GTO 10 334 ▶LBL 19 335 -HMS
H"∡ = "
XEQ "DMS" 335 336 337 338 339 RCL÷ 14 ⇒ĎĒG STO 03 COS X<>Y FC? 05 340 341 342 +/-343 344 345 346 RCL+ 14 х STO 04 RCL 03 347 TAN 348 349 350 351 352 352 x RCL 15 RCL- 05 RCL 04 RCL- 14 FC? 05 +/-354 355 +/-356 X(>Y 357 GTO 16 358▶LBL 20 359 R+ R↓ X<>Y 360 361 X() RCL+ X()Y RCL-POL X()Y RCL+ X()Y 06 362 363 364 365 365 366 25 13

368 →REC 369 X<>Y 370 RCL- 06 371 X<>Y 372 RCL 26 373 RCL- 05 374 + 375 →POL 376 GTO 18 377 ►LBL 22 378 RCL- 17 379 X>Y? 380 GTO 23 382 ►LBL 21 363 RCL 16 384 RCL+ 17 385 X>Y? 386 XEQ 22 387 X<Y 388 RCL 16 X>Y? XEQ 22 X<>Y RCL 16 RCL 17 2 ÷ 388 389 390 391 392 392 + 393 ENTER 394 RCL- ( 395 RCLX 396 RCL+ ( 397 RCL 3) 398 RCL-398 RCL-399 RCL 1 RCL- 05 RCLX 10 RCL+ 20 RCL- 20 RCL 30 RCL- 16 RCL 17 2 ÷ 400 401 402 -403 RCLX 09 404 GTO 24 405 LBL 23 406 407 ENTER 408 ENTER 409 RCL 09 410 RCL- 10 411 1E2

412 х 412 413 414 415 415 416 417 RCL÷ 17 X 2 ÷ RCL 10 418 1E2 419 × 420 + 421 × 422 × ± 422 ÷ 423 ÷ 424 RCL 425 RCL 426 RCL 426 RCL 427 RCL 428 GTO 430 LBL 431 STO 432 GTO 433 LBL 435 STO 434 RCL 435 RCL 438 RCL 438 RCL RCL 16 RCL- 05 RCL× RCL+ 10 20 GTO 24 ē Ž7 20 10 F 28 20 10 08 31 RCL зõ 440 RCL-26 441 442 443 →POL X<>Y RCL-13 444 +/-445 446 447 XXXY +REC RCL+ 25 STO 30 X<>Y +/-448 449 450 451 452 5T0 31 X<>Y 453 ENTER 454 GTO 11 455 .END.

Before starting with the user's instructions and the keystroke examples, this is a good place to look at how the program is set up.

#### vertical grade



When the station that is occupied by the instrument is within a vertical curve, the elevation that is input as profile grade is the elevation of the **vertical tangent** at the instrument station.

It's a simple matter to calculate this elevation since it is just the extention of the back vertical tangent (even if the instrument is upstation of the PVI).

#### slope **r**atio

The slope ratio is carried as a constant, and is displayed each shot. If you want to change it, input the new number before stroking pres. If it is the ratio you plan to use just stroke pres.

#### half-width

Like the slope ratio, the half-width (distance from the centerline to the hinge point) is displayed each shot. If it is the width you want to use, stroke  $\mathbb{R}^{s}$ . If not, input the new number and then stroke  $\mathbb{R}^{s}$ .

Both of the variables above may be changed at any time, during the shot input, allowing for widening the roadbed or flattening the slope as the cut or fill approaches a "daylight" area.

#### referencing

A routine has also been included which calculates the angle to turn and the distance to measure to set the reference stake. The amount of offset is input by the user and the angle and distance are calculated. A shot taken on the reference hub after it is set will output the elevation of the RP and the plus or minus to the slope stake.

#### setting specific stations

This program allows the flexibility of setting stakes wherever the terrain forms a high or low point, to best define the top or toe of slope. Since the program calculates the finished grade at any station you shoot, it isn't necessary to only set those points with elevations shown on the profile.

To stake at specific stations, at 25' or 50' intervals, you can set the station at an offset (determined as approximate catch point based on the drawings) for the first trial station, using  $\blacksquare$  and  $\blacksquare$ .

After input of the station and offset the program will output the angle and distance to that point. Set a temporary point there and take a shot on it. The output will tell you which way, and how far, to the catch point.

Since the ground changes, it should be understood that this distance is where the catch point would be if the ground were flat.

#### the cut and fill factors

The actual point where the slope will end is seldom at the same elevation as profile grade. Use of these factors causes the adjustments to profile grade to be made automatically. These factors are discussed in more detail as part of the keystroke instructions.

#### sizing

To use the basic program, the calculator should be sized to 0035. This means that registers 00 through 34 are used for storage. If you decide to add either or both of the optional routines (resection and data storage) additional registers will have to be allocated for their use. To begin, the program is initialized by keystroking **EXE**. This clears the registers, resets the status of the flags, and calls up the first prompt:

#### **Instrument Station?**

Input the station which (or opposite which) is occupied by the instrument. If this station is within a curve on the alignment, stroke to before stroking

**Offset?** 

If the instrument is on centerline, input 0. If the instrument is at an offset distance from centerline, input the offset distance. If the offset is left of centerline, stroke before

#### **Backsight Station?**

Input the station at the backsight. If the station is within a curve (and the instrument station was not), first stroke , then

#### **Offset?**

Input 0 if the sight is on centerline, or input the offset distance. If the offset of the point is to the left of centerline, stroke before

#### **B.C. Station?**

This prompt will appear after the instrument station input, if the instrument is on a curve in the alignment, or after input of the backsight information, if it is on a curve. If there is a curve, the prompts marked **\*** will appear.

If neither point was on a curve, but there is a curve in the work area, a later prompt provides the opportunity to input the curve data. Input the station, Input the length of the radius of the curve

R/S

R/S

#### Delta?\*

Input the central angle of the curve. If the curve is a curve to the left, 2 before stroking

#### Inst. H.I.?

Input the elevation of the height of instrument. Stroke

#### Profile Elev.?

Input the **finished grade** elevation at the instrument station. If the instrument is at a station which is located within a vertical curve, input the elevation of the **back tangent profile grade**.

#### Cut Factor?

Input the "cut factor". This is the difference in elevation between the finished (profile) grade and the hinge-point of the cut section. If negative,  $\checkmark$ , then stroke

#### Fill Factor?

Input the "fill factor". This is the difference between profile grade and the hinge-point in a fill section. If negative, and stroke

#### % Grade?

Input the percent of grade for the vertical alignment. If negative, 🔽. Stroke

## Vertical Curve?

This prompt requires a yes or no answer. If the answer is "YES", the next three prompts for input of the vertical data will appear:

#### **B.V.C.** Station?

Input the station at the beginning of the vertical curve. In the case of a grade break, instead of a curve, input the station at the grade break

R/S

#### Length V.C.?

Input the length of the vertical curve. If this is a grade break instead of a curve, input 0

#### Grade Out?

Input the percent of grade leaving the vertical curve. If negative, before stroking

### NEXT

#### ENDE

If there is a curve in the work area, input the B.C. station and stroke **E**. If there is not, input a station that is as far as you intend to go, to set the auto-stop option, stroke **E**.

#### INPUT SHOT K ZK 5.0. C F RUD

The first time this prompt appears, or at any time when you want to change the hinge point elevation (from cut to fill or from fill to cut) select the appropriate factor

If staking a cut, stroke

If staking a fill, stroke

#### INPUT SHOT HK ZK S.D. C 7 RUD

Input the horizontal angle

Input the zenith angle

Input the measured slope distance

Because, in slope staking, the rod always a minus the program will indicate that; you need not change the sign

Once the rod has been input you do not have to input it again, unless it changes. Stroking will cause the program to repeat the last rod reading for this shot.

Input the rod reading

The next two prompts are for the "half-width" and Since they both vary, the value about the slope ratio. to be used for the calculation is displayed, and may be changed at this time by input of a new value, prior to stroking R/S.

W/2 = 0.00

Input the correct half-width value, if it different than the value which is is displayed

#### R/S

#### Slope Ratio = 0:1

Input the correct slope ratio value, if different from the value displayed

At this point the display will show the distance to the actual catch point. If the distance is considered to be within tolerance, stroke 🔤 . If it is not, have the rodman move to a new position (based on the display), scroll once, with 🚺 or 🚺 and begin with input of the data from the new shot.

#### to set a reference stake

Once you have reached the catch point, stroking will display the information for making out the slope stake. Input the distance you want to use, from the slope stake to the reference stake. If it is left of centerline,  $\sim$ , then stroke

**Output** will be the distance to the reference point and the horizontal angle to turn to set it.

#### **INPUT SHOT**

After setting the reference point, take a shot on it and input it in the same manner as the previous shots.

**Output** will be the elevation of the reference point and the difference in elevation to the slope stake.

#### changing the cut or fill factors

At times, design conditions change and a new "Typical Section" means using a different cut or fill factor. There are keys for doing this in the second menu.

To change the cut factor, input the new factor and stroke

To change the fill factor, input the new factor and stroke

This will calculate the elevations based on the new input until you change it again. The new factor also becomes the **current** factor. If you have just input a new fill factor, but are currently staking a cut stroke **the** before beginning input of the shot.



Before you begin input of the alignment information, take a moment to calculate the cut and fill factors. This is simply the difference in elevation between the finish profile grade and the hinge point you are staking to. If for instance, you were staking to the back of a bench in a cut section, this could be a difference of 20 or more feet.

We are going to use the roadway details shown on the opposite page for the keystroke examples, so we won't have that type of condition. In the typical cut section we are going to be staking to the flowline of the ditch.

The **factor** will be the sum of the differences. We have 17.5 feet at -2%, +0.5' for the curb, and 8.5' at +4% on both sides; (17.5)(-.02) + 0.5 + (8.5)(.04) = +0.49. This is the **fill factor**. For a cut, we have the added ditch, 4' @ 2:1, which is -2', so the **cut factor** will be -1.51'.

Let's start with the keystrokes for input of the basic information about our setup and the alignments of our roadway. The calculator should be sized at **030**, and we initialize the program by stroking **1 E S**.











The shots listed below will give you some additional practice with the keystrokes. The shots are to the catch points, still using the same alignment. Remember to change the cut or fill factor (if necessary) before input of the shot. Forgetting to do so will result in an error at the catch point.

1. <b>Cut section</b> , set the RP @ 15'. Use a zenith angle of 88°12'20" for the RP shot.	CUI 6.4 AT 9.6 Sta 13+94.686 at 39.57 Left Elev. = 119.18 Grade = 112.78
horiz. angle = 354°40'50"	DIST = 403.87
zenith angle = 88°29'25"	∡ = 352°35'47.1"
slope distance = 400.70'	RP Eley = 121.27
the rod reading is 5.00'	-2.09 № 15.00 to 5.5.

2. Fill section, set the RP @ 15'. Use a zenith angle of 89°40'30" for the RP shot.

horiz. angle = 6°13'55" zenith angle = 89°25'40" slope distance = 477.50' the rod reading is 5.00'

3. Cut section, set the RP @ 15'. Use a zenith angle of 87°52'10" for the RP shot.

horiz. angle = 351°23'30" zenith angle = 88°21'00" slope distance = 315.00' the rod reading is 5.00' FILL 4.8 AT 14.4 Sta 14+79.939 at 40.40 Right Elev. = 113.39 Grade = 118.19 DIST = 477.67  $4 = 8^{\circ}01^{\circ}53.3^{\circ}0$ RP Elev = 111.33 +2.06 @ 15.00 to s.s. CUT 8.3 AT 12.5 Sta 13+09.986 at 42.54 Left Elev. = 117.69 Grade = 109.39 DIST = 317.39  $4 = 348^{\circ}42^{\circ}48.1^{\circ}$ RP Elev = 120.42 -2.73 @ 15.00 to s.s.

The two most likely sources of error when using this program are forgetting to change the factor when going from cut to fill (or fill to cut) and not checking that the half-width and slope ratio are correct for the shot being taken.

If you're using the calculator without a printer, remember to continue stroking **v** after output, until the next answer or prompt appears.

#### resection

This program has been added as an option, for those days when you could stake the whole job if you had a point "up on that hill". It works with the stations and offsets, so you can determine the station and offset of a random point anywhere that you can see three known points from.

The progrom locates the station and offset of the instrument setup point, and then outputs the distances to the points which were used as backsights, as a check on the shots used. All that is required is the input of the Station/Offset information for three points and the angles between the first and second and second and third points.

The best place to put this one is on top of "SS". Stroke To Stroke To go to "SS", then scroll up above the .END. to begin. When you have finished the input, the "END" on this program will separate them.

00 ( 587-Byte prom )       34         01 LBL "R'SEC"       35         02 XEQ "CLI"       36         03 XEQ "FCL"       37         04 180       38         05 STO 15       39         06 SF 07       40         07 "Sta 1 "       41         08 ASTO 30       42         09 H"+ 0/St"       43         10 PROMPT       44         11 XEQ 03       45         12 LBL 07       46         13 STO 01       47         14 X(>Y       48         15 STO 00       49         16 SF 08       50         17 "Sta 2 "       51         18 ASTO 31       52         19 H"+ 0/St"       53         20 PROMPT       54         21 XEQ 03       55         22 LBL 08       56         23 STO 03       57         24 X(>Y       58         25 STO 02       59         26 SF 09       60         27 "Sta 3 "       61         28 ASTO 32       62         29 H"+ 0/St"       63         30 PROMPT       64         31 XEQ 03       65         3	X()Y STO 04 " 4 1st - 2nd?4" PROMPT +HR STO 11 " 4 2nd - 3rd?4" PROMPT +HR STO 12 RCL 01 RCL-03 RCL 04 RCL-03 RCL-04 RCL-03 RCL-04 RCL-03 RCL-04 RCL-03 RCL-04 RCL-03 RCL-04 RCL-14 RCL-11 RCL-12 STO 10 2 ÷ ENTER TAN RCL 07	68 RCL ÷ 06 69 RCL 11 70 SIN 71 X 72 RCL 12 73 SIN 74 ÷ 75 1 76 - 77 X 78 LASTX 79 2 80 + 81 → POL 82 R↓ 83 + ENTER 85 X<0? 86 XEQ 05 87 STO 08 88 CF 07 89 X<>Y 90 +/- 91 RCL+ 10 95 RCL 09 95 RCL 14 97 RCL 11 98 RCL - 15 99 + 100 +
---	--	--

RCL 08 SIN RCL× 06 RCL 11 209 STO+ 16 210 RTN 2111LBL 05 212 RCL+ 15 213 RTN 101 "YN" 155 XEQ FS? 102 156 157 10 103 XĔġ 10 104 158 GTO 13 105 SIN 159 RTN 160€LBL 161 FS? 106 2140LBL 215 R+\_ 13 10 107 →REC 09 R↓ FS? RCL+ 02 STO 16 X(>Y RCL+ 03 108 162 163 164 216 217 218 GTO FS? 09 00 109 **Ø**8 XĔQ FS? 11 110 GTO FS? GTO 08 00 111 165 07 RTN "B.C.Station?4" 112 113 STO 17 166 167 07 ADV RTN PROMPT 167 RTN 168 LBL 169 RCL 170 RCL 171 X>Y 172 XEQ 173 RCL 174 X4Y 115▶LBL 06 116 0 117 STO 24 STO 36 "Radius?4" 14 RCL 39 0 5TO 24 30 5TO 20 RCL 39 RCL 16 X>Y? XEQ 16 RCL 36 X<Y? PROMPT STO 37 "Delta?4" PROMPT 118 116 30 119 STO 20 120 LBL 02 121 RCL 10 122 RCL 10 123 ISG 24 124 STO ST 125 RCL IN 126 RCL IN →HR RCL IND 24 RCL- 16 ISG 24 STO 5T X X(0? SF 05 ST0 38 229 175 XEW 10 CLA RCL 16 "Inst. Located a" F"t Sta.t" XEQ "STA" RCL 17 RCL 17 XEQ 15 175 176 177 178 179 180 230 231 232 233 234 235 RCL IND 24 RCL- 17 X()Y ABS →RÃD 126 127 128 129 130 131 x RCL+ 36 181 235 RCL 236 STO 237 XEQ 238 RTN 239 LBL 240 RCL 241 RCL 241 RCL 242 XY >POL 182 STO 39 FIX 02 "Dist to " ARCL IND 20 H X(0? SF 01 ABS FIX 02 ARCL ST X FS? 01 FC? 01 FC? 01 FC? 01 FC? 01 FC? 01 FC? 01 183 184 11 185 11 39 ī32 186 187 RCL 133 134 ARCL ST X RCL X>Y? 34 AVIEW 188 135 156 20 5T0 5T 243 244 245 246 247 248 GTO 12 189 136 137 138 139 Х RCL-RCL÷ 36 37 190 190 FW 191 F F 192 AVIE 193 CF 6 194 ADV ISG 24 STO ST →DEG RCL Х AVIÊŴ CF 08 33 37 ŘČL 20 X=Y? 140 →REC 249 250 251 RCL- 37 FC? 05 +/-141 195 GTO 06 STOP 142 143 1960LBL 15 197 -198 RCL÷ 37 ADV 252 253 254 STO+ X<>Y RCL+ 144 145 GTO 02 33 RTN 199 →DEG RCL 146 LBL 03 200 201 37 -36 5T0 33 X<>Y 255 256 147 →REC ST0 34 RCL- 37 FC? 05 148 202 RCL 33 256 RCL 33 257 RTN 2580LBL 16 2590LBL 12 2590LBL 12 260 PASSED 261 AVIEW 262 END ST0 34 203 204 205 206 207 149 Χ̈́́́́́́, Ύ́ 150 +7-151 152 153 ĈF 21 "Curve?" AVIEW STO+ 17 X(>Y FC? 05 E.C." SF 21 154 +1 208





output:

Inst. Located at Sta. 11+25.543 @ 503.60 Rt Dist to Sta 1 519.01 Dist to Sta 2 509.07 Dist to Sta 3 523.33

Do the usual proof reading after you are done with the program input. Try the example to check the program.

#### coordinate resection

This same program will do coordinate resection, if you input the north-coordinate as the station and the east-coordinate as the offset.  $3RD_{1132}^{1132}$ 

Answer all of the CURVE? prompts **NO**, and the answer will be the coordinates of the new point, even though they are labled as "station" and offset".

To have more than the two place accuracy, you can fix the display at 04 or 06 places, and then recall the newly computed coordinates directly out of register 16 (north) and 17 (east), where they are stored.



These coordinates could then be added to your coordinate file, and a radial inverse program such as "SPRAY" (book, "HP42S 307.001043 SURVEYING SOLUTIONS", pages 50 and 51) may be used for layout calculations.

#### limitations

This program will not pass the E.C. of the curve. The setup point must be opposite a station which is **part** of the curve or on the back tangent.

#### storing the slope stake data

It is pretty easy to print out the data in the field while you slopestake, just point the calculator at the printer each time you reach a catch point. If you want to STORE the shots as you go, you can do so with the little program to the right.\*

You can put it in right above "STA", and it'll be out of the way. Go to "STA" and scroll up to 00 to begin input. When you've finished, the "END" will separate the two programs.

#### modify "SS"

You'll need two insertions in the program, "SS", to make it work. Go to the program, then go to label 12 and enter **program mode** with **S**. Stroke **s** and the key that is now corresponding to your new menu label "**STOD**".

00 ( 71-Byte Prgm ) 01▶LBL "STOD" 02 ISG 40 03 STO ST X 04 05 CLST FIX 02 06 RCL 31 07 RND 08 ENTER 09 RCL 30 10 RND 11 1E6 12 ÷ 13 X<>Y 14 1E3 15 × 16 17 STO IND 40 18 UIO ST CLST FIY ISG 40 ī9 х 20 21 22 23 RCL 02 RND 23 RND 24 ENTE 25 RCL× 26 ABS 27 1E3 28 ÷ 29 X<>Y ENTER RCLX 29 30 1E3 31 X 32 33 STO IND 40 34 35 ISG 40 STO ST Х 36 RCL 12 37 STO IND 40 38 END

Stroke KEO I O O 3 to go to program step 03, and type in 40 STO 40 and exit by stroking ETT.

223 RTN 2240LBL 12 226 FIX 01 227 CLA 02 XEQ "STOD" 04 40 05 STO 40 06 CLST 07 SF 01

Those insertions should be like the ones shown to the left, for them to work properly. The next thing you need to do is write a program that will recall the data later.

#### the recall data program

We've called this one "GETD", and you should put it into the main menu. You can do this by putting it at the top of "SS".

\*The calculator uses registers 0-40 + 3 registers for each point stored. In order to store 20 catch points you have to size to at least 0101. Go to "SS", scroll up in the usual manner and type in the new program (below). Label "GETD"

1 8	, ,	Label "GETD"
00 ( 204-Byte Prom )	44 AVIEW	can be used to output
Ø1PLBL "GETD" G2 XEO "ECL"	45 ISG 40	the station, offset,
03 XEQ "CL1"	46 510 51 X	cut and distance as
04 "Number of Shots"	48 CLA	woll as the elevation
05 F"?4"	49 FIX 01	of the estab point
05 PRUMPI 07 3	50 RCL IND 40	of the catch point.
08 X	52 FP	Ti Jaco mot
09 40	53 0	It does not
	54 X(>Y	output any of the
12 ÷	56 SF 00	reference data.
13 41	57 X(0?	
14 + 15 STO 40	58 1	When you are
16 DEBL A	57 T 60 1E3	finished slope staking
17 CLST	61 X	for the day, you can
18 RCL IND 40	62 STO 39	turn on the printer
20 IP	64 ES2C 00	and print out the
21 1E3	65 R.4	catch points wich
22 ÷	66 IP	were set, by execut-
23 310 37 24 Du	67 1E3 68 t	ing "GETD". The
25 FP	69 X>0?	only prompt is for the
26 X<0?	70 "FILL "	number of shots.
28 +	71 XN0? 72 "CUT "	
29 1E6	73 ABS	Because "GETD"
30 ×	74 ARCL ST X	routine will only be
31 CLA 32 YEQ "STO"	75 F° 0 °	executed when you
33 F""e "'"	77 ISG 40	stroke the The key
34 FIX 02	78 STO ST X	the output shots are
35 RUL 37 36 YK02	77 HVIEW 80 FIY 02	the one actually set
37 SF 00	81 "Elev = "	the ones actually set,
38 ABS	82 ARCL IND 40	not the trial shots.
39 HRUL ST X 40 FC2 00	84 ADV	Dreaf read the
41 ⊢"_Rt"	85 ISG 40	Proof-read the
42 FS?C.00	86 GTO A	program carefully
43 F" Lt"	87 END	and, 11 you want to
		try it out, do the
		examples again.
		11+80.200 @ 44.90 Rt
The output from	m "GETD" for	FILL 6.3 2 18.9
the two catch point	ts set in the	LICY - 100.00
examples are shown	to the right.	11+99.800 @ 38.69 Lt
		Elev = 111.13

#### **MORE HP42S PROGRAMS**

#### Vertical Curves (booklet, \$8.00)

Calculates CONTINUOUS vertical alignment without changing back and forth between Grade and Curve routines. Also calculates vertical intersections, symmetrical or asymmetrical vertical curves. Solves for station when the elevation is known, or the station can be given, to calculate the elevation.

#### Spiral Curves (booklet, \$8.00)

Calculate the coordinates to any station, or offset to a station, within a spiral system. Options include coordinate output, auto-inverse, or both.

Calculates intersections of the entrance or exit spiral with a circular curve or straight line.

#### Triangle Solutions (booklet, \$8.00)

The 42S version of the most complete triangle solutions program ever available. Solves with any of the following knowns: ASA SAA SAS SSA SSS Area-SS Area-AA Area-SA.

#### **Topography** (booklet, \$8.00)

This one turns your 42S into a manual data collector, complete with a labeling system that you can customize to suit the type of topo work you do.

All shots are stored as finished data, by shot number, for later output. Choice of 3-D coordinates or Station-Offset-Elevation for the output.

#### Urban Survey Programs (book, \$20.00)

Contains programs for stakeout (or design) of street intersections, returns, culs-de-sac, bulbs and knuckles. A special program calculates and prorates blocks from the street intersections (with auto-store and auto-inverse of the points) from the street intersection setups for A.L.T.A. surveys.

Also contains layout programs for curb and gutter, or storm/sanitary sewers, which can store the data and later print out cut sheets before leaving the job site.

> Software by D'Zign P.O. Box 11570, Glendale, CA 91226

\$8.00 -ISBN 0-944889-08-5-