

NOTICE

No express or implied warranty is made by **D'Zign** or the author with regard to the procedures and program material offered or their merchantability or their fitness for any particular purpose. The procedures and program material are made available solely on an "as-is" basis, and the entire risk as to their quality and performance is with the user. Should the procedures or program material prove defective, the user (and not **D'Zign** nor any other party) shall bear any and all cost of all necessary correction and all incidental or consequential damages. **D'Zign** and/or the author shall not be liable for any incidental or consequential damages in connection with or arising out of the furnishing, use, or performance of the keystroke procedures or program material.

HP42S SURVEYING SOLUTIONS

Copyright©1989, 1990, 1993 by Ted J. Kerber

All rights reserved. No part of this work covered by the copyright hereon may be reproduced or used in any form or by any means - graphic, electronic, or mechanical, including photocopying, recording, taping or information storage and retrieval systems - without written permission of the author.

published by DZign Land Survey & Development Tollhouse, California, U.S.A. 1993

ISBN 0-944889-14-X

TECHNICAL ASSISTANCE

The program material, instructions and procedures contained in this book assume that the user has a working knowledge of both surveying *and* the general operation of the HP-42S calculator.

Technical assistance is limited to verification of the results shown in the various examples used in this book.

If you have any questions or suggestions regarding this book, or other **D'Zign** publications, please feel free to call us. The number is (209) 297-8025, and someone is available to answer technical questions between the hours of 8:00 A.M. and Noon, (Pacific Time Zone), Monday through Thursday.

Before calling for help, take a look through "The Most Commonly Asked Questions", on the inside of the back cover.

WARNING

This software and book are both protected by U.S. Copyright Law (Title 17 United States Code). Unauthorized reproduction and/or sales may result in imprisonment of up to one year and fines of up to \$10,000 (17 USC 506). Recent changes in the laws make infringement upon *software copyrights* a felony. Copyright infringers may also be subject to civil liability.

NOTICE

No express or implied warranty is made by **D'Zign** or the author with regard to the procedures and program material offered or their merchantability or their fitness for any particular purpose. The procedures and program material are made available solely on an "as-is" basis, and the entire risk as to their quality and performance is with the user. Should the procedures or program material prove defective, the user (and not **D'Zign** nor any other party) shall bear any and all cost of all necessary correction and all incidental or consequential damages. **D'Zign** and/or the author shall not be liable for any incidental or consequential damages in connection with or arising out of the furnishing, use, or performance of the keystroke procedures or program material.

Table of Contents

introduction	2
angle and bearing conventions - cautions	3
the program, "TRIG"	4
editing "TRIG"	6
"CURVE", a solutions program	9
miscellaneous subroutines	13
coordinate storage	15
the program, "TRAV", for traversing	17
traverse adjustment	33
the program, "INT-X", for intersection solutions	37
miscellaneous utility programs	49
"DUMP" for coordinate output	50
"LOAD", for coordinate input	50
"SPRAY", for radial layout	50
"PRGE", for clearing a file	52
"RP", to set the radius point while traversing	52
" ADJ" for automatic angle adjustment	54
"CLAY", a curve layout program	57
coordinate rotation (transformation)	63
pre-determined areas	77
ultimate sizing	87

INTRODUCTION

Hewlett-Packard has produced a really powerful calculator at a very good price, the HP-42 Scientific Calculator, which lends itself nicely to solving surveying problems. It can not be programmed by insertion of a module, or with a card reader, like the HP-41 series, but it has a really simple system for typing in a program.

the operations index

To find a function for the first time, HP has provided an "Operations Index" on pages 310 through 335 of the instruction manual, which tells you exactly what keystrokes to use to type in the function you want.

Even better, this index gives you the page number that you can refer to if you want to know more about the function you are using. If, while typing in a program, you aren't sure how to input a particular function, simply refer to the Operations Index.

the softkey menus

All of the programs in this book take advantage of the "softkey" menu system built into this calculator. When you want to start a program you stroke **XEQ** and then the softkey corresponding to the program you want, from the menu displayed in the bottom half of the screen.

the programs

The purpose of this book is to provide the user with a good surveying program for everyday use in solving field and office problems. When we began programming for this book we decided to use a point-storage system, since it is a real timesaver, particularly in the field. We have designed a traverse, inverse and sideshot program for traversing that is inter-related to the intersection program and the curve solutions program, so that you can use them as a more flexible system.

This also means a longer program, so we suggest that you approach the programming in stages. You are less apt to have programming errors if you don't try to do the whole job at one sitting.

CONVENTIONS

These programs do not make any distinction between "bearing-azimuth" and "field angle" traversing. Once you are in the TRAVERSE program, you may use any method of traversing which you want to use.



You may traverse from one point to another by input of the bearing and quadrant code (or azimuth), or you may turn an angle to the next point.

The illustration to the left shows the relationship of these angles, referenced to the backsight and foresight.

Bearings are input with quadrant codes and the quadrants are numbered with the same system that has been used by Hewlett-Packard since the first surveying programs for handheld HP's came out.



quadrant codes

The bearing is input AND ENTERED, the quadrant code is then input, and a differ key is stroked.

And, some CAUTIONS: These programs do not recognize sideshots as different from traverse shots. If you use the angle-adjustment, or either the compass or transit adjustment programs, you will get incorrect answers if the traverse contains sideshots. There are ways to keep this from being a problem.

1. Use point numbers for the sideshots that are high enough to be outside the point numbers used for the traverse itself. If you are doing a traverse that will use point numbers 1 through 7, use numbers 11 and up for the sideshots.

2. Calculate the traverse without the sideshots, adjust it, and then do an INVERSE traverse from point to point to point, setting the sideshots as you go. This is quick and simple, because the coordinates are stored by point number in all of these programs.

ŤRIG

You are probably anxious to start programming the traverse program to try it out, but we urge you to start with this program, and follow the sequence we have used in this book. This first program will give you some practice in programming your calculator, and does a job for you that you will find handy later.

There are always times, while calculating a traverse, that you need to work a quick trig problem before you can do the next step ... like calculating $\Delta/2$ to enter the "curve" routine.

If you do that with this calculator you will have lost your place in the program you were running. Later, this program will be related to the traverse program so that it can be called up without losing your place.

degrees, minutes and seconds

Even better, you can perform all of the trig operations without converting to decimal first. This program does the converting for you, and all input and output is in degrees, minutes and seconds.

getting started

We'll do this first program in two stages, which will also give you some editing practice. Begin by stroking the shift key, then the XEQ key. The display will show a menu which will be blank (if you haven't yet input any programs) except for .END. on the left. The keys just below each of the menu portions will correspond to the menu instruction above it. Stroke the key just below the .END. in the display.

Next, stroke the shifted **R/S** key and the display should be as shown to the right.

00▶(0-Byte Prom) 01 .END.

Begin typing in the program steps shown on the next page. The first step, LBL "TRIG", will replace ".END." as step 01. Each of the following steps will be assigned a step number by the calculator as you type in the program steps. Steps 03, 05, 07, 09, 11 and 13 are typed while in **alpha** mode. All of the other functions can be accessed through the keyboard and menus. Consult the Operations Index in your owner's manual if you are not sure which keys to stroke.

O1 NLBL "TRIG"	15 MENU	29€LBL 04
02 SF 21	16 STOP	30 ASIN
03 "SIN"	17▶LBL 01	31 →HMS
*04 KEY 1 GTO 01	18 →HR	32 RTN
O5 "COS"	19 SIN	33▶LBL 05
06 KEY 2 GTO D2	20 RTN	34 ACOS
07 "TAN"	21€LBL 02	35 →HMS
08 KEY 3 GTO 03	22 →HR	36 RTN
09 "ASIN"	23 COS	37▶LBL 06
10 KEY 4 GTO 04	24 RTN	38 ATAN
11 "ACOS"	25€LBL 03	39 →HMS
12 KEY 5 GTO 05	26 →HR	40 RTN
13 "ATAN"	27 TAN	41 END
14 KEY 6 GTO 06	28 RTN	

When all of the steps have been typed in, go back and proof read the program. All of the steps should be the same as shown in the program listing above. If any of them are not, delete the step and re-type it.

try it out

If you stroke the **XEQ** button now, your display should show a menu with "TRIG" as one of the program options (the only option if you didn't already have any programs stored). Stroking the key under "TRIG" will bring up a menu of the structure of the structure

If you use the key which corresponds to these menu labels, instead of those on the keyboard, the trig functions work in degrees, minutes and seconds instead of decimal degrees. Try working a few.

* To access the function, stroke 🗌 PGM.FCN 🔼 🔣

Next, a short editing session. The program, "TRIG", works fine as it is, but we want to expand it to do more.

editing

Editing is done "from the bottom, up". If you go into the program and insert or delete any steps it changes the step number of all of the steps below the step which was added or deleted. If you start at the bottom and work upward you will still be able to find your place.

Stroke the shifted XEQ key (GTO) and then stroke the key under "TRIG" to bring the program to the top of the program memory. Next, stroke the shifted R/S (PRGM) key to go into program mode. You can go to any step in the program by stroking GTO ., followed by the step number (4-digit input is required). Let's start by going to step 16, where a step is to be added. Stroke

xeq • 0 0 1 6

to get there. Insert the step **GTO 98** between steps $17 \text{ GTO 98} \frac{16}{17}$ 16 and 17.

16 STOP 17 LEL 01

Scroll upwards until the program pointer is at 15 MENU, and then insert the step LBL 98.

15 KEY 7 GTO B

17 KEY 9 GTO 99

14 KEY 6 GTO 06

15 MENU

16 LBL 98 15 MENU

Scroll upwards again, to 15 KEY 7 GIU Bprogramstep14, and16 KEY 8 GTO Binsert the three new steps17 KEY 9 GTO 99shown to the left.

Either scroll upwards or stroke GTO .0001, to put the program pointer at step 01 LBL "TRIG", and add the step, LBL A.

O1 |LBL "TRIG" 02€LBL A -02 SE 21

With the additions to the program that have been made, the END that was originally program step 41 is now at step 47. There are still some more program steps to be added to our program, at the bottom.

Go to program step 46, which is just above the END, and add the steps shown below.

47)	LBL B	60 KEY 7 GTO A	73€LBL 08	86 ÷
48	"DMS+"	61 KEY 8 GTO A	74 HMS-	87 →HMS
49	KEY 1 GTO 07	62 KEY 9 GTO 99	75 RTN	88 RTN
50	"DMS-"	63▶LBL 21	76€LBL 09	89€LBL 11
51	KEY 2 GTO 08	64 STOP	77 X<>Y	90 →HR
52	"DMS×"	65 GTO 21	78 →HR	91 →RAD
53	KEY 3 GTO 09	66€LBL 99	79 ×	92 RTN
54	"DMS÷"	67 CLMENU	80 →HMS	93€LBL 12
55	KEY 4 GTO 10	68 EXITALL	81 RTN	94 →DEG
56	"D→R"	69 RTN	82ÞLBL 10	95 →HMS
57	KEY 5 GTO 11	70▶LBL 07	83 X<>Y	96 RTN
58	"R→D"	71 HMS+	84 →HR	
59	KEY 6 GTO 12	72 RTN	85 X<>Y	

Don't forget to proof read the program when you've finished the programming. A minor error at this stage could go unnoticed now, and be giving wrong answers later.

examples

Try out the new routines with this one: Add $25^{\circ}15'30"$ to $13^{\circ}40'20"$, subtract $6^{\circ}15'14"$, multiply by 3 and then divide by two. The keystrokes are shown below.

first angle entered second angle added third angle subtracted multiply by 3 divide by 2



To try out the other two functions, $D \rightarrow R$ and $R \rightarrow D$, try the following:

 Find the length of a curve which has a radius of 500.00' and a central angle of 12°22' (length = the radius times the central angle, in radians). (answer: 107.9195')



2. Find the central angle of a curve with an arc length of 135.20' and a radius of 450.00'. (answer: 17°12'51")
4 5 0 ÷ ***

The trig functions are much easier to use through the program than from the keyboard, and as an additional plus, you will be able to call this program up as a subroutine from other programs. It does happen that you are half-way through a calculation for something else and need to use one of these functions.

fancy output

After you have input the program, "DMS", on page 12 you may want to back up and edit "TRIG". You can have the output read in degrees, minutes and seconds (to the nearest tenth second) by using the subroutine, "DMS".

89•21'28.0"	
SIN COS TAN ASIN ACOS ATAN	

Add the three steps, CLA, XEQ "DMS" and AVIEW to each of the places in the program that produces an angle as output.

Working from the bottom, upward, this would be between steps 95 and 96, 87 and 88, 80 and 81, 74 and 75, 71 and 72, 39 and 40, 35 and 36, 31 and 32.

This change only costs about 56 bytes of memory, but the enhanced output is clearly an angle, and there is less chance of transposing the numbers when using this form.

CURVES

This program is a CURVE SOLUTION program. It may be used as a "stand alone" program for solving circular curves, and is also called up as a subroutine from the traverse program.

the program listing:

O1▶LBL "CURVE"	27 +/-	53 →DEG
O2 CLX	28-2	54 FS? 91
03 CF 05	29 ÷	55 GTO 03
04 SF 21	30 STO 12	56-2
05 CF 90	31 FS? 91	57 RCL× 12
06 CF 91	32 GTO 02	58 ÷
07 "DELTA"	33 STOP	59 STO 11
08 KEY 1 GTO 41	34)LBL 46	60 GTO 02
09 "R"	35 →HR	61)LBL 03
10 KEY 2 GTO 42	36 100	62 RCL÷ 11
11 "L"	37 X<>Y	63 2
12 KEY 3 GTO 43	38 ÷	64 ÷
13 "T"	39 →DEG	65 STO 12
14 KEY 4 GTO 44	40)LBL 42	66 GTO 02
15 "C"		47NI 01 45
10 0	41 X <u?< td=""><td>87VLIC 45</td></u?<>	87VLIC 45
16 KEY 5 GTO 45	41 X <u? 42 SF 03</u? 	68 2
16 KEY 5 GTO 45 17 "D"	41 X <u? 42 SF 03 43 ABS</u? 	68 2 69 ÷
16 KEY 5 GTO 45 17 "D" 18 KEY 6 GTO 46	41 X <u? 42 SF O3 43 ABS 44 STO 11</u? 	68 2 69 ÷ 70 FS? 91
16 KEY 5 GTO 45 17 "D" 18 KEY 6 GTO 46 19 MENU	41 X <u? 42 SF O3 43 ABS 44 STO 11 45 SF 91</u? 	68 2 69 ÷ 70 FS? 91 71 GTO 03
16 KEY 5 GTO 45 17 "D" 18 KEY 6 GTO 46 19 MENU 20 STOP	41 X <u? 42 SF 03 43 ABS 44 STO 11 45 SF 91 46 FS? 90</u? 	68 2 69 ÷ 70 FS? 91 71 GTO 03 72 RCL 12
16 KEY 5 GTO 45 17 "D" 18 KEY 6 GTO 46 19 MENU 20 STOP 21▶LBL 41	41 X <u? 42 SF 03 43 ABS 44 STO 11 45 SF 91 46 FS? 90 47 GTO 02</u? 	68 2 69 ÷ 70 FS? 91 71 GTO 03 72 RCL 12 73 SIN
16 KEY 5 GTO 45 17 "D" 18 KEY 6 GTO 46 19 MENU 20 STOP 21▶LBL 41 22 SF 90	41 X <u? 42 SF 03 43 ABS 44 STO 11 45 SF 91 46 FS? 90 47 GTO 02 48 STOP</u? 	68 2 69 ÷ 70 FS? 91 71 GTO 03 72 RCL 12 73 SIN 74 ÷
16 KEY 5 GTO 45 17 "D" 18 KEY 6 GTO 46 19 MENU 20 STOP 21▶LBL 41 22 SF 90 23 →HR	41 x <u? 42 SF O3 43 ABS 44 STO 11 45 SF 91 46 FS? 90 47 GTO O2 48 STOP 49 ▶LBL O5</u? 	68 2 69 ÷ 70 FS? 91 71 GTO 03 72 RCL 12 73 SIN 74 ÷ 75 STO 11
16 KEY 5 GTO 45 17 "D" 18 KEY 6 GTO 46 19 MENU 20 STOP 21▶LBL 41 22 SF 90 23 →HR 24 X<0?	41 X <u? 42 SF 03 43 ABS 44 STO 11 45 SF 91 46 FS? 90 47 GTO 02 48 STOP 49▶LBL 05 50 FC? 91</u? 	 68 2 69 ÷ 70 FS? 91 71 GT0 03 72 RCL 12 73 SIN 74 ÷ 75 ST0 11 76 GT0 02
16 KEY 5 GTO 45 17 "D" 18 KEY 6 GTO 46 19 MENU 20 STOP 21▶LBL 41 22 SF 90 23 →HR 24 X<0? 25 SF 05	41 x <u? 42 SF O3 43 ABS 44 STO 11 45 SF 91 46 FS? 90 47 GTO O2 48 STOP 49 ►LBL O5 50 FC? 91 51 GTO O7</u? 	68 2 69 ÷ 70 FS? 91 71 GTO 03 72 RCL 12 73 SIN 74 ÷ 75 STO 11 76 GTO 02 77▶LBL 03
16 KEY 5 GTO 45 17 "D" 18 KEY 6 GTO 46 19 MENU 20 STOP 21 ▶LBL 41 22 SF 90 23 →HR 24 X<0? 25 SF 05 26 FS? 05	41 x <u? 42 SF O3 43 ABS 44 STO 11 45 SF 91 46 FS? 90 47 GTO O2 48 STOP 49€LBL 05 50 FC? 91 51 GTO 07 52€LBL 43</u? 	68 2 69 ÷ 70 FS? 91 71 GTO 03 72 RCL 12 73 SIN 74 ÷ 75 STO 11 76 GTO 02 77▶LBL 03 78 RCL÷ 11

79 ASIN	110)LBL 09	141 RCL× 11
80 STO 12	111 → HMS	142 2
81 GTO 02	112 - " D= "	143 ×
82)LBL 44	113 XEQ "DMS"	144 STO 18
83 FS? 91	114 AVIEW	145 ⊢"% C= "
84 GTO 03	115 ADV	146 ARCL ST X
85 RCL 12	116 2	147 AVIEW
86 TAN	117 RCL x 12	148 RCL 11
87 :	118 FS? 05	149 ENTER
88 STO 11	119 +/-	150 ×
89 GTO 02	120 →HMS	151 RCL× 12
90)LBL 03	121 "DELTA= "	152 →RAD
91 RCL÷ 11	122 XEQ "DMS"	153 STO 19
92 ATAN	*123	154 ENTER
93 STO 12	124)LBL 47	155 ENTER
94)LBL 02	125 2	156 RCL 12
95 RCL 11	126 RCL× 12	157 RCL 11
96 " R = "	127 RCL× 11	158 →REC
97 XEQ 04	128 →RAD	159 ×
98 100	129 STO 24	160 -
99 X<>Y	130 -" L= "	161 STO 22
100 ÷	131 ARCL ST X	162 FS? 82
101 →DEG	132 AVIEW	163 GTO 02
102 GTO 09	133 RCL 12	164 CF 03
103)LBL 08	134 TAN	165 1
104 50	135 RCL× 11	166 RCL 12
105 X<>Y	1 36 STO 20	167 COS
106 ÷	137 " T= "	168 -
107 ASIN	138 ARCL ST X	169 RCL× 11
108 2	139 RCL 12	170 " M= "
109 ×	140 SIN	171 ARCL ST X

172	RCL 12	187 RCL 12	202 AVIEW
173	2	188 TAN	203 RTN
174	÷	189 RCL 11	204)LBL 02
175	TAN	190 X≁2	205 FS?C 03
176	RCL× 20	191 ×	206 +/-
177	⊢"'r E= "	192 RCL 19	207 STO+ 05
178	ARCL ST X	193 -	208 RCL 18
179	AVIEW	194 "Fillet"	209 CLMENU
180	STOP	195 CF 90	210 GTO "TRAY"
181	RCL 22	196 CF 91	211 RTN
182	"Segment"	197▶LBL 01	2120LBL 04
183	XEQ 01	198 AD V	213 ARCL ST X
184	RCL 19	199 ⊢"=५"	214 ⊢"⊊"
185	"Sector"	200 ARCL ST X	215 END
186	XEQ 01	201 ⊢" sq ft"	

Once the program is typed in (and proof-read) it is automatically added to the catalogue. Stroking **XEQ** will bring up the program menu, stroking the key which corresponds to **CURVE** will start up the program, showing a menu of **MARE**.

One of the following, the **central angle** (delta), the **radius** or the **degree of curve**, must be known. Any one of these AND one other part of the curve data are all that are needed to solve any circular curve.

The output, regardless of which parts are known, will be as shown to the right.

Before you can try it out, there is a little more work to do. The program uses the subroutine, "DMS", which is part of the next group to be input.

C	R =)= 1	: 50 1 • 2	99. 71	000 33.	90 0 "	
DEL	.T9= [_= [=	21 21 114	і 1 1 8	й'й 662 473)0. 1	0"
	0= M= E=	216 11 12	85 13	396 20 98	, ,	_
Şe⊆ 1,7	14. 14.	t= 256	54	sq	ft	R/S
Sec 54,	tor 541	.53	891	se	l f	t
Eil 882	let 12	65	sq	ft		

These subroutines go into a different part of program memory, and include the last one needed by "CURVE". XEO (GTO) brings up the program menu. Stroking Next, stroke R/S 00 (xxx-Byte 01▶LBL "TRIG" Prgm) (PRGM) and the display will be as shown to the right. Scroll upwards with Δ to position the program pointer at 00, and begin typing in the following programs: 33 ⊢" 34 RTN 35⊅LBL 36 ⊢" 01▶LBL "C 02 F5? 81 "C+" 65 ARCL ST X 66 XEQ 08 67 RCL 03 06 18 UF 29 FIX CI 36 68 69 FP 04 37 100 05 00 RTN 70 71 06 CLA 35 38 LBL х 07 FIX 07 39 ... 02 72 RND **8**0 XTOA 40 RTN FIX 09 CLX 41 LBL 73 08 01 74 74 75 ÇLĄ XEQ 10 R+ 42 " SIDESHOT" FS? 55 01 ABCL 13 43 ARCL ST. Х 11 7ē 12 13 44 77 CLX ALENG 45 PRA *14 78 FIX FIX 04 04 46 CLA 5F 29 H"N= 79 15 SF 29 47 RTN H 48▶LBL 49 F5?C "DMS" 19 16 80 RCL ARCL 17 19 81 RTN ST Z CLA 50 82•LBL 18 01 83 51 52 53 55 55 55 55 19 XEQ IND F"F= ST X ENTER 10 X<>Y 20 21 84 ST0 19 X<Υ? ⊢"ø" 85 ARCL ST Y IP 22 CF 86 AVIEW 29 23 FIX 00 87 RTN R+ 88▶LBL "CL 89 ∑RĘG 00 24 ADV 25 RTN 260LBL 27 F "CL" ARCL ST X 57 90 58 CLΣ ΣRĘG **0**3 91 59 100 11 92 93 CLΣ 28 RTN 60 х 29 LBL й 04 61 ABS 62 63 94 30 F" STO STO 18 24 IP 95 RTN 31 RTN

32▶LBL 05 keystroke tips

Step 57 appends a degree symbol. This is input from the alpha keyboard, through "MATH".

XEQ 01

64

Step 66 and step 76 append the minute and second symbols, respectively, and are both input through the "PUNC" key.

*May be varied to suit user's needs.

Information on these keystrokes can be found in the HP42's User's Manual on pages 295 and 296.

There are some program steps which are just spaces, or spaces appended to what is already in the alpha register. For instance, step 12 **appends** one space, step 27 **appends** 3 spaces and step 30 **appends** 4 spaces.

The addition of the spaces and the "line feed" steps is part of what makes the output read correctly whether there is a printer in use or not.

Step 33 **appends** 5 spaces, step 36 **appends** 6 spaces, and step 39 **appends** 7 spaces. When you proof-read the program it is important to check these steps, even though "there isn't anything there".

So far the subroutines that have been input are two that handle display (C^+ and DMS), and one (CL) which clears registers 00 through 24, which are not used for coordinate storage by the other programs. This next group manipulates angles, output and prompts. Go to the end of "CL" (step 95) and type in the following:

96▶LBL "I>"	111 MENU	126 ⊢" = "
97 CF 29	112 STOP	127 FIX 04
98 FIX 00	113ÞLBL 01	128 SF 29
99 CLA	114 SF 10	129 FS? 10
100 "INV "	115 GTO 03	130 +"?"
101 ARCL 13	116ÞLBL 02	131 FS? 85
102 - "-"	117 CF 10	132 XEQ "DMS"
103 ARCL ST X	118ÞLBL 03	133 FS?C 85
104 AVIEW	119 CLMENU	134 RTN
105 RTN	*120 EXITALL	135 FC? 10
106ÞLBL "YN"	121 RTN	136 ARCL ST X
107 "YES"	122ÞLBL "A0"	137 FC? 10
108 KEY 1 GTO 01	123 "AZ"	138 RTN
109 "NO"	124 SF 85	139 PROMPT
110 KEY 2 GTO 02	125 XEQ 06	140 RTN
*Stroke XEQ ENTE	A , type in EXITALL	and stroke ENTER.

141▶LBL "A1"	173 360	204DLBL 04
142 FS? 89	174 MOD	205 "N "
143 XEQ 17	175 ENTER	206 XEQ 05
144 X<>Y	176 SIN	207 ⊢" ₩"
145 →HR	177 ASIN	208 RTN
146 X<>Y	178 X<0?	209ÞLBL 05
147 ENTER	179 +/-	210 STO 21
148 ENTER	180 →HMS	211 R+
149 2	181 X<>Y	212 STO 20
150 ÷	182 90	213 XEQ "DMS"
151 IP	183 ÷	214 RTN
152 180	184 1	215ÞLBL 06
153 ×	135 +	216 X>0?
154 X<>Y	186 IP	217 RTN
155 LASTX	187 STO 21	218 360
156 ×	188 GTO IND ST X	219 +
157 COS	189ÞLBL 01	220 RTN
158 R+	190 "N "	2211LBL 17
159 ×	191 XEQ 05	222 2
160 -	192 ⊢" E"	223 -
161 FS? 10	193 RTN	224 X>0?
162 RTN	194DLBL 02	225 RTN
163 →HMS	195 °S °	226 4
164 GTO "A0"	196 XEQ 05	227 +
165 "BRG"	197 ⊢" E"	228 RTN
166 XEQ "A0"	198 RTN *	229•LBL •F•
167 →HR	1990LBL 03	230 0.013
168•LBL •B1•	200 "S "	231 LBLF
169 -180	201 XEQ 05	232 CF IND ST X
170 X<>Y	202 F" W"	233 ISG ST X
171 FS? 89	203 RTN	234 GTO "F"
172 +		235 END

Before beginning this last short group of subroutines, stroke the shifted **XEQ** key (GTO), and then the decimal point twice. This will automatically put an end on the programs so far and give you a new starting point. When you enter the program mode you will again see the display

> 00▶(0-Byte Prgm) 01 .END.

Scroll upward once, so that the program pointer is at 00, and type in the program steps to the right.

pout

This program is "Point OUT" and is used to recall stored coordinates. If you input the point number of a **stored** pair of coordinates and execute "POUT" the coordinates will be recalled to the display.

After recall the north coordinate is in the y-register and the east coordinate is in the x-register.

pin

This one stands for "Point IN". If you input a point number and execute "PIN" you will be prompted for the north coordinate with **N** =?. Input the north coordinate and stroke R/S and you will be prompted **E =?**. Input the east coordinate and stroke R/S. The coordinates are stored under immediately that point number.

01 LBL "OUT" 02 RCL 13 03 2 04 x 05 24 06 + 07 ENTER 08 ENTER 09 1 10 -11 RCL IND ST X 12 RCL IND ST Z 13 RTN 14 LBL "IN" 15 RCL 13 16 2 17 × 18 24 19 + 20 X<>Y 21 STO IND ST Y 22 R+ 23 1 24 -25 X<>Y 26 STO IND ST Y 27 RTN 280LBL "PIN" 29 STO 13 30 XEQ "PN" 31 GTO "IN" 32 LBL "POUT" 33 STO 13 34 GTO "OUT" 35 END

After the subroutines at the top of page 17 have been put in, you can try some coordinate storage. Each pair uses two storage registers, or 18 bytes.

sizing

The default size for the number of storage registers available is 25. This means that registers 00 through 24 may be used for storage. For right now, you need to resize to 50, so that you will have some registers available for storing coordinates. (see page 87)

The **SIZE** function is found in the second menu of "MODES". Stroke the shifted +/- key, scroll down once, and stroke the key under SIZE. This brings up a prompt for a four-digit input. Input 0050.

storing coordinates

1.

Input the point number and stroke

prompt: N =?

2. Input the north coordinate and stroke

prompt: E =?

3.

Input the east coordinate and stroke

The coordinate has been stored under its point number.

recalling coordinates

1. Input the point number and stroke

R/S

The north coordinate is in the Y-register and the east coordinate is in the X-register. Later in this book we will be showing you a routine, "LOAD", which calls up "PIN" continuously for input of a group of coordinates.

TRAVERSE

A few more short subroutines to type in, and then we can start on the TRAVERSE program. Go to $C\uparrow$ and scroll upwards once (to 00) to begin input of these programs:

O1▶LBL "PN?"	14▶LBL "CODE"	27 RCL- 23
02 CF 22	15 STO 22	28 →POL
03 " PT NO?"	16 XEQ "POUT"	29 R+
04 PROMPT	17 STO 24	30 →HMS
05 FS? 22	18 R+	31 RTN
06 XEQ 01	19 STO 23	32)LBL "PN"
07 RTN	20 RCL 22	33 CLA
O8)LBL 01	21 FP	34 ⊢"" N =?"
09 1	*22 1E3	35 PROMPT
10 -	23 ×	36 CLA
11 STO 13	24 XEQ "POUT"	37 F"⊊ E =?"
12 R+	25 R.CL- 24	38 PROMPT
13 RTN	26 X<>Y	39 END

This next program isn't a short one, but the odds are, it's the one you've been anxious to get to. Stroke **GTO**.. to start with a clean slate, and you can start typing it in.

a traverse program

00 { 859-Byte Prom } 01⊅LBL_ TRAV STO 13 EXIST KEY 1 NEW KEY 2 "RE # KEY 3 01▶LBL "TR 02 FS?C 82 03 GTO A H GTO 01 03 GTO A 04 ADV C 05 XEQ "F 06 XEQ "F 07 3F 00 08 SF 01 09 SF 09 11 SF 21 12 FS? 55 13 SF 88 14 CF 81 15 CLA 15 CLA 16 CLMENU 17►LBL 32 2_GTO 02 "CL" "F..." З GTO **0**3 MENU FS? RTN PT 04 NO?" PROMPT 01 13 00 ₽2 PIN 00 *To input, stroke E 3

A CALL AND POUT" 00 9 NO?" CODE" 19 28 3 "INT-INT-X" 9 1 0 A1 " 31 31 0 **Ø**7 00 01 00 10 00 09 15 15

148 XEQ 31	204 STD+ 04
149 XEQ "B1"	205⊳LBL 02
150 RVIEW	20 <u>6</u> RCL 02
151 RTN	207 FC7 01
152⊅LBL 09	208 +
153 →HMS	209 RCL 07
154 XEQ "A0"	210 +
155 AVIEW	211 FC?J01
156 XÉQ 31 157 RTN 158₽LBL 23 159 L¥=?" 160 PROMPT	212 ŘCL 03 214 FC? 01 215 + 215 RCL 08
161 HR 162 X()Y 163 HREC 164 X4Y? 165 Y()Y	ŽÍŠ ÍSG 13 219 STO ST X 220 XEQ "C↑" 221 CF 81
166▶ÊBÊ 22	223 XEG ^{"A} IN"
167 XEQ "PN?"	224 F5? 04
168 RCL 00	225 GTO 40
169 XXY	225 GTO 15
170 FS2 01	226 GTO 15
171 GTÓ 33	2280 LBL 17
172 RCL 10	229 X(0?
173 X⟨>Y	230 SF 07
174▶LBL 33	231 FC?C "7
174▶LBL 33	232 YF2C "7
176 STO+ 06	233 XX0?
177 STO 01	234 XEQ 34
178 RDV	235 XEQ "POUT"
179 HD = "	236 1
180 RPCL ST Y	237 5TO- 13
181 FS7 08 182 PRON 183 AVIEW 184 ADV 185 ADFC	238 R+ 239 RCL- 08 240 RCL- 03 241 X()4
186 FC2 01	242 RCL- 02
187 GTO 02	243 RCL- 02
188 STO+ 02	244 XEQ 08
188 STO+ 02	245 RCL 10
189 ENTER	246 RCL 01
191 STO+ 15 192 R+ 193 X<>Y 194 STO+ 03	247 XEW 33 248 RTN 2490EBL 34 250 +/- 251 "PT.NO?"
195 ENTER	252 PROMPT
196 ABS	253 STO 13
197 STO+ 09	254 R↓
198 R↓	255 XEQ "IN"
199 2	256 RCL 13
200 ÷	257 RTN
201 rcl 03	258Þlbl 24
202 -	259 SF 04
203 x	260 Adv

"∑ HD ARCL 309 ADL 13 ADL 13 ADL 13 ADL 13 ADL 13 ADL 14 ADD 15 A 06 GTO 36 GTO 37 GTO 38 1: Х 2" 05 35 38 32 0 0 0 = "t " Ă ŧ, EOSING PT#?" ės ¥ POUT" 04 02 PIN "CURVE" UT" ^WClosure:" AVIEW

H

south azimuth

For our users in Hawaii, Australia and parts of Canada, the program allows for the use of south azimuth. If you want to use this option, simply set flag 89.

The various routines that clear flags do not clear flag 89, so to leave south azmimuth you must clear flag 89 manually.

exit

If you use the traverse program as a way of setting coordinates for various points, instead of just for actual traverses (we all do) the final flag clear routines are bypassed.

01▶LBL "EXIT"	To other programs this will act
02 XEQ "F"	as though you are still interfaced
03 81.088	
04 XEQF	We suggest adding the short
05 CLST	running it automatically by
06 CLA	assigning it to key 09 in all of
07 END	your 'TRAV' menus.

Add the step KEY 9 GTO "EXIT" to each of your menus, just above the "MENU" command (between 271 & 272, 86 & 87 and 68 & 69). This will clear the flags.

getting started

When you stroke **XEO** the program first runs through its clearing routine and then prompts for "**PT NO?**", at the same time displaying the options menu **EXENTION** (1995).

> Input the point number you want to use, and then stroke the key corresponding to the option:

- 1. If the point number is that of an already stored pair of coordinates stroke
- 2. If the coordinates have not yet been stored, stroke

N =?

2a. Input the north coordinate and stroke

R/S

E =?

2b. Input the east coordinate and stroke

3. If this is an existing pair of coordinates, but you want to duplicate them under a new point number for this traverse, stroke

NEW PT NO?

3a.

. Input the new point number you want to assign, and stroke

The **output** will be the point #1 N= 1000.0000 number and coordinates. E= 5000.0000

Stroking (or any key)*brings up the traversing menu

Output for the direction of the courses may be either BEARING or AZIMUTH. The **FIRST** (and only the first) time the traversing menu is displayed stroke either or **TABLE**. Nothing will seem to have happened, but your output mode is now set.

bearing input

Bearings are input in two steps, the bearing angle is entered, then the quadrant code is input.

- 1. Input the bearing, stroke
- 2.

Input the quadrant code, and stroke

azimuth input

Courses may be entered as azimuths instead of bearings (if the bearing is northeast, it saves keystrokes).

1. Input the azimuth and stroke

ENTER

input by point code

The bearing between any two stored coordinate pairs may be called up automatically by using "CODE". This 'code' consists of the two point numbers, entered in the form AAA.bbb, where AAA is the first point number, and bbb

*If the calculator is set to "printer on".

is the second. The second point number **must** be threedigit input.

1. Input the code for the two points, in the form noted above, and stroke

With this method of input the 'whole' bearing is used, rather than a rounded off re-input number.

setting the direction

This initial direction may be the azimuth or bearing toward the point you want to set. That is, it may be the first direction of the traverse.

It may also be a BASIS OF BEARINGS from which an angle or deflection angle is then turned, to set the direction of the first course of the traverse. If the latter, the direction of the basis of bearings should be the direction toward the first point.

direction by inverse

You can also establish the direction of the first course by inversing to the next point.

1. Input the point number of the coordinates you wish to inverse to and stroke

You can begin a traverse from existing points (in storage) by inversing from the backsight to the instrument point, to begin the traverse.

The direction of the course and the menu will be displayed, and you can choose your next move.

distance input

Distances may be input as horizontal distance or slope distance, using the appropriate keystroke.

1. Input the horizontal distance, stroke

or

2.

Input the slope distance, stroke

4=?

2a. Input the vertical or zenith angle, and then stroke

The horizontal distance will be output. Stroke as if you are not using a printer, and the next prompt is displayed:

PT NO?

Except for inversing, you will have this prompt just prior to the output of coordinates, each time. You may assign any point number you want, or just stroke we to get the next consecutive point number.

CAUTION!! If you have used "CODE" for a direction, you must input a point number at the **PT NO**? prompt, or the point number used will be one higher than the bbb portion of the code, by default.

angle input

Angles may be turned as field angles or as deflection angles. For an angle left, stroke the key before stroking the **English** or **Definition** key.

sideshots

The procedure for a sideshot is the same as for any other course, with the exception that you tell the calculator that you are wanting a sideshot.

<u>Signal for a sideshot</u> by stroking
 Input a deflection angle and stroke
 Input a field angle and stroke

or		
4a.	Input a bearing, stroke	
		ENTER
4b.	Input the quadrant code, stroke	1.4.141
or		1.1.1.15
5.	Input an azimuth, stroke	
6.	Input a horizontal distance, stroke	
	•	
OF 7	Input a clone distance stroke	****************
/a.	input a slope distance, stroke	
∡ =?		

7b. Input the vertical or zenith angle and then stroke R/S

PT NO?

• • • • • •

curved sides

It is easy to include a curved side in the traverse. The Δ angle is input as positive if the curve is to the right, and negative if the curve is to the left.

The sign of the **radius** will determine whether or not the area of the curve segment is included in the traverse area. The radius is input as a POSITIVE number to INCLUDE the area, and as a NEGATIVE number to EXCLUDE the area.

Assume that you are at the beginning of the curve, about to do the curve portion. First, establish the direction of the chord

1. Input $\Delta/2$ and deflect (change sign if the curve is to the left) stroke

- **or** 2a.
- Input the bearing of the chord, and stroke

ENTER

2b. Input the quadrant code, stroke

or

3. Input the azimuth for the curve's chord, and then stroke

THEN

4. <u>Signal that you are traversing a curve by</u> stroking

DELTA A LA TALENT DE LA DEL

5. Input the two known parts of the curve, stroking the appropriate keys. If the curve is to the left, Δ must be one of the two known parts in order to signal the direction of the curve. The default is a curve to the right.

> The radius must be one of the known parts if the area is to be excluded, so that it may be entered as a negative number. Default radius is positive, and the segment area is automatically included.

PT NO?

6. The next point set will be the E.C. (end of curve) coordinates*. Input the point number you wish assigned if you do not want the next consecutive number, and stroke

a note on inversing

If you do sideshots and then **inverse** to the next nonsideshot point, the little lable, Inv x-y, will show the point number of the last sideshot in the 'x' position.

If you are printing out the results and want it to show the correct number, manually store the correct number into register 13 before beginning the inverse.

As an example, if you are at point 3, set sideshots 15, 16 and 17, and then want to inverse directly to point 4, stroke 3 sto 1 3 before 4

*A subroutine, "RP", is included in the "OPTIONS" section. If you add this routine to the program, the radius point will also be set.

Traverses may be thought of as either "closed" or "open" traverses. For use with this program, the CLOSED TRAVERSE may be either of two types. What we will call **Type A** is one similar to the one shown to the right.

In this type of traverse, the line from 1 to 2 is $\frac{1}{\sqrt{2}}$ usually a known line which $\frac{1}{\sqrt{2}}$ is included in the traverse.

The two points used would be part of a property or monument line, and the basis of bearings would be the bearing of the line.



This type of traverse also closes back to the original point of beginning, and allows the turning of a closing angle, which is turned at the first (and last) point, foresighting the second point.

What we will consider to be a **Type B** closed traverse is one which begins at one known point and ends at another known point. For this type (below) the basis of bearings is usually obtained by backsighting another known point.





An OPEN traverse may also be considered as being an 'unfinished' traverse, in that it could later be used as a portion of a traverse which will be closed.

More often, a traverse of this type is run as part of a topographic survey, where the traverse is considered accurate enough without correction.

For the CLOSED type of traverse, the angular error is usually distributed equally among the angles, prior to adjustment of the traverse.

An optional program for automatic angular adjustment has been included in this book, and may be added to the traverse program later, if you will be wanting that capability in your traversing routine.

Adjustment routines for either COMPASS adjustment or TRANSIT adjustment have also been included in this book, and you can include either or both of them in your programming. You would usually want to adjust the angles of the traverse prior to using either of the adjustment routines.

We can try a keystroke example using the little traverse shown to the right.	560 4.3
The basis of bearings will be the course 4-1 , and we assume that these are (found) existing points which can be occupied.	=5 <u>300</u> ↓ 150.20' 2 ↓ 120° 4' ° ↓ 20° 4' °
The first two angles will $\frac{1}{2}$ be turned as deflection $\frac{1}{4}$ angles to the right, the last two as angles left.	142.90' 3
Note that this is an example The course with the known b used directly, that is, we con gone to #1 as the first leg of	using a 'basis of bearings'. bearing could also have been ald have started from #4 and the traverse.
Stroke XEQ and the key that corresponds to TRAV	output: N 27*30'00.0* E
prompt: PT NO? keystrokes:	keystrokes: 5 6 • 4 3 0 4
prompt: N =? keystrokes:	output: N 84*13'04.0" E keystrokes:
prompt: E =? keystrokes:	1 5 0 2 11115 prompt: PT NO? keystroke:
output:	output:
#1 N= 300.0000 E= 300.0000	HD = 150.2000 #2 N= 315.1323
keystrokes:	E= 449.4358 keystrokes:

output: keystrokes: S 25 00'08.0" W 1 7 2 keystrokes: prompt: PT NO? 2 0 6 • 5 5 keystroke: R/S prompt: PT NO? keystroke: R/S output: HD = 172.0000output: N= 300.0024 E= 300.0067 #5 HD = 206.5500keystroke: N= 127.9378 F= 362.1367 #3 R/S 🔺 🖬 🖬 🖬 keystrokes: output: 1 0 7 • 0 9 2 6 Z HD= 671.6500 prompt: TYPE? ▲ +/output: This is a closed, type A, traverse so stroke the key N 82"09'18.0" W which corresponds to "A" keystrokes: 1 4 2 • 9 105 output: prompt: PT NO? AREA = 24898.6429 sq ft = 0.5716 acres keystroke: R/S prompt: CLOSING PT#? output: keystrokes: HD = 142.90001 3453 #4 N = 147.4427F = 220.5741output: keystrokes: Closure: S 70"00'06.6" W 7 0 • 2 0 2 6 HD = 0.0072#1 N= 300.0000 F= 300.0000 output: N 27*30'16.0" E Prcn= 1:93818





Because this was a type "B" traverse, no area is output, but a closure is calculated. If this had been an "open" traverse, no closure would be given since it does not close to a known point.

NOTE: If the function you want to use is not in the displayed menu when you need it, you can use \checkmark or \checkmark to go to the other menu. If you are not using a printer while running the program, stroke \bowtie for the next output or prompt.

miscellaneous moves

You can also inverse to **unstored** coordinates by entering the northing, then input the easting and stroke the $\frac{1}{2}$ key before you stroke **T**. The program will prompt for a point number to be assigned, and then store the coordinates.
Once the traverse has been closed it may be adjusted. We have included two programs for traverse adjustment in this book, "COMPass adjustment" and "TRANsit adjustment".

You will probably only want to put in one of these, and which one you use will depend on the equipment you use for traversing. With a good theodolite and EDM (or a total station) Compass Adjustment is most often used.

subroutines

First, two subroutines which are used by either of the adjustment programs. Go to "C+", scroll up to 00 and type in the programs shown to the right.

"INV" performs an inversing routine, and is used by an intersection solutions program and a coordinate transformation program later in this book.

The program "BLK" is also used by the transformation program as well as several others. It identifies a block of consecutive points by point number for coordinates manipulation.

Because these are not routines that you will execute from the keyboard, we have placed them at a point in program memory which keeps them out of the way in the program menu.

01 LBL "INV" 02 RCL-08 03 X<>Y RCL- 07 04 05 +POL 06 STO 07 х⇔ү 360 Ø8 09 X<0? 10 11 12 13 EC? 00 XĒQ FS? 01 14 9<u>9</u> 15 XEQ B1 ҄҄Ѐ҄҄ӵ҄ӌ҄҄нѻ 16 = 17 ARCL 23 18 AVIEW 19 ADV 20 RTN 21▶LBL 01 22 →HMS 23 1 24 "A1" XEQ 25 RTN "BLK 26 LBL "Begin 0? 27 28 29 PROMPT "Last Pt#?" 30 \vdash 31 32 PROMPT 33 34 35 STO 22 X<>Y 36

As always, it is important that you proof-read what you have typed in, before exiting the program.

37

END

Stroke the shifted **XEQ** key and then the key which corresponds to "**TRAV**". Enter program mode by stroking the shifted **R/S** key, scroll upward to program step 00 and type in either "**COMP**" or "**TRAN**", from the program listings.

COMPass adjustment

01▶LBL "COMP"	27 STO 05	53 XEQ "IN"
02 ADV	28▶LBL 02	54 RCL 13
03 "COMPASS ADJUST"	29 RCL 13	55 1
04 FS? 08	30 RCL 22	56 -
05 AVIEW	31 X=Y?	57 XEQ "POUT"
06 ADV	32 GTO 01	58 STO 08
07 0	33 XEQ "OUT"	59 X<>Y
08 STO 11	34 STO 01	60 STO 07
09 STO 14	35 STO 15	61 1
10 STO 15	36 X<>Y	62 STO+ 13
11 XEQ "BLK"	37 STO 00	63 XEQ "OUT"
12 XEQ "POUT"	38 STO 14	64 XEQ "INV"
13 XEQ "C≁"	39 X<>Y	65 RCL 00
14 RD¥	40 RCL- 08	66 STO 07
15 1	41 X<>Y	67 RCL 01
16 STO+ 13	42 RCL- 07	68 STO 08
17 RCL 10	43 →POL	69 XEQ "OUT"
18 RCL 01	44 STO+ 11	70 XEQ "C≁"
19 +/-	45 RCL 11	71 ISG 13
20 →REC	46 RCL× 16	72 STO ST X
21 RCL÷ 06	47 STO+ 14	73 AD V
22 +/-	48 RCL 11	74 GTO 02
23 STO 16	49 RCL× 05	75▶LBL 01
24 X<>Y	50 STO+ 15	76 STOP
25 RCL÷ 06	51 RCL 14	77 END
26 +/-	52 RCL 15	

Typing in the last step, END, will automatically separate the program from "**TRAV**", but still leaves it just to the right of the "TRAV" key in the menu.

TRANsit adjustment

01ÞLBL "TRAN"	28 GTO 01	55 XEQ "IN"
02 ADV	29 XEQ "OUT"	56 RCL 13
03 "TRANSIT ADJUST"	30 ENTER	57 1
04 FS? 08	31 RCL- 08	58 -
05 AVIEW	32 RCL× 03	59 STO 13
06 ADV	33 RCL÷ 09	60 XEQ "OUT"
07 SF 05	34 ABS	61 STO 08
08 SF 06	35 FS? 06	62 X<>Y
09 RCL 02	36 +/-	63 STO 07
10 XK0?	37 STO+ 14	64 1
11 CF 05	38 CLX	65 STO+ 13
12 RCL 03	39 RCL 14	66 XEQ "OUT"
13 X<0?	40 +	67 STO 01
14 CF 06	41 STO 19	68 X<>Y
15 0	42 R+	69 STO 00
16 STO 11	43 ENTER	70 X<>Y
17 STO 14	44 RCL- 07	71 AD¥
18 XEQ "BLK"	45 RCL× 02	72 XEQ "INV"
19 XEQ "POUT"	46 RCL÷ 15	73 RCL 00
20 XEQ "C≁"	47 ABS	74 STO 07
21 AD¥	48 FS? 05	75 RCL 01
22▶LBL 03	49 +/-	76 STO 08
23 1	50 STO+ 11	77 XEQ "OUT"
24 STO+ 13	51 CLX	78 XEQ "C≁"
25 RCL 13	52 RCL 11	79 GTO 03
26 RCL 22	53 +	80▶LBL 01
27 X=Y?	54 RCL 19	81 STOP

For program step #82, type in XEQ END.

If you have decided to input BOTH types of adjustment, you should put in "TRANS" above "COMP". You can eliminate program steps 80 and 81 from "TRANS" and substitute RTN for END as the last step. This lets the two routines share LBL 01 instead of duplicating the steps.

As an example, we have re-run the traverse on page 29, and the output from both types of correction is shown below.

After you have closed the traverse, stroke **XEQ** and then the key corresponding to either "COMP" or "TRAN".

prompt: BEGIN @?

1. Input the beginning point number, then stroke

prompt: LAST PT#?

2. Input the last point number in the traverse, stroke R/S

> COMPASS ADJUST #1 N= 300.0000 H 84 13'04.5" E HD= 150.1984 #2 N= 315.1317 E= 449.4343 S_25 00'09.6" W HD= 206.5516 #3 N= 127.9365 E= 362.1331 N 82 09'19.0" W HD= 142.9013 #4 N= 147.4409 E= 220.5691

N 27 30'14.5" E HD= 171.9986 #5 N= 300.0000

TRANSIT ADJUST #1 N= 300.0000 N 84*13'03.8* E HD= 150.1978 #2 N= 315.1322 E= 449.4336 S 25*00'08.6* W HD= 206.5517 #3 N= 127.9365 E= 362.1332 N 82*09'18.6* W HD= 142.9020 #4 N= 147.4413 E= 220.5686 N 27*30'15.3* E HD= 171.9986

#5 N= 300.0000 E= 300.0000

36

INTERSECTIONS

R/S

The solutions to intersection problems are needed all of the time in surveying. We use an intersection formula to find out where two lines cross, then make that point the new PI or the new lot corner. Or, we need to know how far a point is offset from a given line.

Next to just plain traversing, this is the most used type of calculation in surveying. We've tried to make it easy, with all of the options displayed in the menu at one time.

Any distance input is done with the distance key, and any direction can be input as bearing, azimuth or code.

The "CODE" key may be used to recall a "stored" bearing between two points in storage. The point numbers are input in the form **AAA.bbb**, where **AAA** is the first point number and **bbb** is the second. Three digit input is required for the second point number.

to use the program

Begin by stroking XEQ, and then the key corresponding to INT-X

Begin @ PT#?

1.

Input the beginning point number, stroke

OUTPUT will be the point number and coordinates of the beginning point.

End Pt#?

2. Input the point number of the ending point, then stroke

Save as #?

3. Input the point number you wish to assign to the intersection point, then stroke

The prompts and responses on the previous page are the same for all of the intersection routines. Select the type of intersection you need, and follow the keystroke instructions below.

bearing - bearing

la.	Input the first bearing and stroke
or	Input the quadrant code, stroke
lb.	Input the point code for the bearing you want to extract as the first bearing, and then stroke
or	
lc.	Input the azimuth of the first course and stroke
2a.	Input the bearing of the second line, then stroke
or	Input the quadrant code and stroke
2b.	Input the point code for the bearing you want to extract as the second bearing, and stroke
2c.	Input the azimuth of the second course and stroke

OUTPUT will be the bearing and distance from the beginning point to the intersection, the point number and coordinates of the intersection point, the bearing and distance from the intersection point to the end point, then the point number and coordinates of the last point. bearing - distance Input the bearing of the first course, stroking 1a. ENTER Input the quadrant code, then stroke or Input the point code for the bearing you want 1b. to extract, and stroke or Input the azimuth of the first course, and 1c. then stroke Input the distance for the second line, and 2. stroke OUTPUT will be the bearing and distance from the beginning point to the intersection, the point number and

beginning point to the intersection, the point number and coordinates of the intersection point, the bearing and distance from the intersection point to the end point, then the point number and coordinates of the last point.

Because there are two possible answers with this solution type, a reminder prompt appears

2nd Solution

3. Examine the answers and decide if they are the correct solution. If they are not, go on to the second solution by stroking

Output will be the same as for the first solution with the exception that the first point is not printed out again. The intersection point coordinates in storage will be replaced by the new ones.

distance - distance

1.

2.

Input the first distance, stroke

Input the second distance, and then stroke

OUTPUT will be the bearing and distance from the beginning point to the intersection, the point number and coordinates of the intersection point, the bearing and distance from the intersection point to the end point, then the point number and coordinates of the last point.

2nd Solution YES NO Dealer and the second

3.

If you want the second solution, stroke



If you do not want the second solution, stroke



Output of the second solution is similar to that of the bearing - distance solution, replacing the original coordinates at the intersection point with the new ones.

- offset to a line
- 1a. Input the bearing of the known line (from which the end point is offset) and stroke

ENTER

Input the quadrant code then stroke

or

Input the code for the bearing you want to extract and stroke

or

lc.

Input the azimuth of the line and stroke

Stroke the key which corresponds to

OUTPUT of the answer will be in the same form as the other intersection routines, with the bearings and distances of both lines given.

the programming

2.

The information on the last few pages describes the way the program works, and now we'll look at the programming itself.

As always, there are a couple of related subroutines.



This time you will also add a few steps to the traverse program and set up a storage matrix. That is much easier than it sounds, just do the keystrokes shown to the left.

Go to "INV", enter program mode, and scroll up one notch to step 00 and type in the following:

01	LBL	"B÷A"
02	XEQ	"A1"
03	ר"י,	ı
04	GTO	01
05I	LBL	"A→B"
06	→HR	
07	XEQ	"B1"

08 RCL 21 09 ⊢"ኑ" 10▶LBL 01 11 FS? 38 12 RTN 13 AVIEW 14 RTN

Next, stroke



Enter program mode.

Scroll down until the program pointer is at 04, and insert the two steps shown to the right. 05 FS?C 83 06 GTO 15 And, it's time to type in another long one. Before starting stroke **EXEC** to pack what is already in the calculator. Now go to the permanent .END. by stroking shift, XEQ, .END., and enter program mode. The display should show

00 (0-Byte Prgm) 01**∍**.END.

Stroke Stroke so that the pointer is at 00, and you may begin typing in the program steps listed below.

O1)LBL "INT-X"	23 STOP	45 STO- 02
02 XEQ d	24€LBL d	46 +
03 FS? 83	25 86.099	47 RCLEL
04 XEQ 51	26€LBL H	48 STO 08
05 SF 21	27 CF IND ST X	49 STO- 03
06 CLA	28 ISG ST X	50 RCL 19
07 XEQ 10	29 GTO H	51 → HR
08 CLMENU	30 CLX	52 180
09)LBL 50	31 RTN	53 +
10 "BRNG"	32)LBL 51	54 STO 10
11 KEY 1 GTO F	33 INDEX "SW"	55 STO OO
12 "CODE"	34 RCL 07	56 CLX
13 KEY 2 GTO A	35 STOEL	57 GTO "TRAV"
14 "AZIM"	36 +	58)LBL A
15 KEY 3 GTO B	37 RCL 08	59 XEQ "CODE"
16 "DIST"	38 STOEL	60)LBL B
17 KEY 4 GTO G	39 CLX	61 1
18 "0/S"	40 RTN	62€LBL F
19 KEY 5 GTO D	41▶LBL C	63 SF 10
20 "TRAV"	42 INDEX "SW"	64 XEQ "A1"
21 KEY 6 GTO C	43 RCLEL	65▶LBL e
22 MENU	44 STO 07	66 FC? 95

67 STO 04	97 XEQ OO	127 FS?C 96
68 FS? 95	98 RCL 04	128 GTO 02
69 STO 00	99 RCL- 10	129 XEQ 02
70 CLX	100 SIN	130 RCL 05
71 FS? 95	101 RCL× 11	131 X<> 12
72 SF 97	102 STO 07	132 STO 05
73 SF 95	103▶LBL b	133 XEQ 01
74 EC? 97	104 CF 95	134 GTO 02
75 RTN	105 XEQ 00	135▶LBL 10
76 FS? 97	106 RCL 07	136 CLA
77 GTO a	107 X*2	137 "Begin @ Pt#?"
78 RTN	108 RCL 04	138 - ".
79▶LBL G	109 RCL- 10	139 FC? 83
80 FC? 98	110 RCL 11	140 PROMPT
81 STO 05	111 → REC	141 FC? 83
82 FS? 98	112 FS? 96	142 XEQ "POUT"
83 STO 07	113 GTO 05	143 FS? 83
84 FS? 95	114 R+	144 XEQ "OUT"
85 STO 07	115 X+2	145 STO 01
86 FS? 95	116 -	146 R+
87 GTO Б	117 SQRT	147 STO 06
88 FS? 98	118 R+	148 CF 10
89 SF 99	119 X<>Y	149 R*
90 FS? 99	120 -	150 FC? 83
91 GTO c	121 STO 12	151 XEQ "C*"
92 SF 98	122 LASTX	152 "End Pt#?"
93 CLX	123 R*	153 - ","
94 RTN	124 +	154 PROMPT
95▶LBL D	125€LBL 05	155 STO 16
96 SF 96	126 STO 05	156 XEQ "POUT"

157	STO 03	187 RCL- 04	217 XEQ 01
158	R+	188 SIN	218)LBL 02
159	STO 02	189 ÷	219 CF 10
160	"Save as #?"	190 STO 05	220 RCL 04
161	ו יי וי וי	191 GTO D2	221 RCL 05
162	PROMPT	192)LBL c	222 → REC
163	STO 15	193 CF 95	223 XEQ 03
164	CF 95	194 XEQ 00	224 ADV
165	SF 10	195 RCL 05	225 RCL 04
166	FIX O4	196 →POL	226 RCL 05
167	CLX	197 X*2	227 → REC
168	RTN	198 RCL 07	228 RCL+ 06
169	LBL 00	199 X*2	229 STO 08
170	RCL 03	200 -	230 X<>Y
171	RCL- 01	201 RCL÷ 11	231 RCL+ 01
172	RCL D2	202 RCL÷ 05	232 STO 09
173	RCL- 06	203 2	233 RCL 15
174	XEQ O3	204 ÷	234 STO 13
175	STO 10	205 ACOS	235 R+
176	$\mathbf{X} < > \mathbf{Y}$	206 RCL 10	236 XEQ "IN"
177	STO 11	207 X<>Y	237 XEQ "OUT"
178	RTN	208 -	238 XEQ "C*"
179	LBL a	209 STO 12	239 RCL 02
180	CF 95	210 LASTX	240 RCL 03
181	XEQ OO	211 RCL+ 10	241 RCL- 09
182	RCL OO	212 STO 04	242 X<>Y
183	RCL- 10	213 XEQ 02	243 RCL- 08
184	SIN	214 RCL 12	244 XEQ 03
185	RCL× 11	215 X<> 04	245 RCL 16
186	RCL OD	216 STO 12	246 STO 13

247 RCL 02	261 →HMS	275 AVIEW
248 RCL 03	262 SF 88	276 XEQ "YN"
249 ADV	263 XEQ "A≁B"	277 SF 21
250 XEQ "C*"	264 CF 88	278 FS?C 10
251 RTN	265 FIX 03	279 RTN
252 GTO 50	266 ⊢"Dist = "	280 STOP
253)LBL 03	267 ARCL 14	281)LBL 04
254 → POL	268 AVIEW	282 X>0?
255 STO 14	269 FIX 04	283 RTN
256 X<>Y	270 RTN	284 360
257 XEQ 04	271)LBL 01	285 +
258 FS? 10	272 CLMENU	286 RTN
259 RTN	273 "2nd Solution"	287 .END.
260 ADV	274 CF 21	

As always, it's important to proof-read the program before trying it out.

Then try the keystroke examples on the following pages, to get the feel of the different routines.

NOTE: Distance-Distance and Bearing-Distance solutions can "blow" if the angle of intersection is close to 90°! From 89°58'55" to 90°00'00" the sine is 1 to the nearest 7 places, and the cosine is 0 at 90°, not allowing division, since the calculator is programmed to not divide if the number in the x-register is 0.

Quite often, when this happens, the correct answer lies half-way between the answers output as the 1st and 2nd solutions. If both solutions lie in the same quadrant and the coordinates are very close in both results, try using the mean northing and easting by averaging the coordinates.



Next, try an example of the **offset** routine, using the same illustration for this example.

keystrokes:



prompt: Begin @ Pt#?

keystrokes:



output:

N= 150.0000 E= 175.0000

prompt: End Pt#?

#1

keystrokes:

2 R/S

prompt: Save as #? keystrokes:

3 R/S

display: 0.0000

Since the bearing that we want (from 1 to 3) is still stored from the last example, let's just call it up from storage:

keystrokes:



When the display clears to 0.0000 and the prompt bar appears, indicate that this is an OFFSET:

keystroke:

output:

N 15°30'30.0° E Dist = 36.070 #3 N= 184.7571 E= 184.6444 S 74°29'30.0° E Dist = 223.493 #2 N= 125.0000 E= 400.0000

For a last example, which also uses the 'second solution', do the <u>distance</u>-<u>distance</u> intersection, using the same coordinates as in the illustration, and the distances which were output in the first example.

Answer the beginning prompts with the same point numbers as in the other two examples, and then input the first distance

keystrokes:



When the display clears to 0.0000 and the prompt bar appears, input the second distance

keystrokes:



The output which follows is not the correct answer for the directions we are going:

▋▓₽₽₽

output: S 2•49'40.4" E Dist = 235.467	keystroke:
#3 N= −85.1803	output: _{N 15} •30'29.8" E
E= 186.6170	Dist = 235.467
N 45°25'59.6" E	#3 N= 376.8941
Dist = 299.513	E= 237.9586
#2 N= 125.0000	S 32"45'10.2" E
E= 400.0000	Dict - 299 512
prompt: 2nd Solution	#2 N=+125.0000 E= 400.0000

If you are not using a printer while working this routine, you **must** continue to stroke the **R/S** key after output, until a new prompt appears or the display clears.

interfacing with "TRAV"

You will have noticed that "**TRAV**" is also displayed in your prompt bar. You cannot go directly to the traverse program from this program unless you originally started out there.

What you CAN do is go to the intersection program from the traverse program, and then return to the traverse.



OPTIONS

DECISIONS, DECISIONS, DECISIONS!!

We have arrived at a point where you have to decide how to configure your calculator.

point storage

If you have input all of the programs so far, you should be able to store about 210 points, and you have a good basic set of programs for most traverse problems.

From here on, each program you add is a trade for point storage. Decide which programs you really need and how many stored points you actually need for YOUR To help with this normal work. we will tell you how many points each of the following programs will replace.

a recommendation

Adding the routine to the right to the traverse program, and changing the two steps shown, will replace 19 registers, but allows you to use "TRIG", " $A \rightarrow B$ " and " $B \rightarrow A$ " without leaving the traverse program. Typing in the programs on the next page adds three valuable programs to your set.

The new routine should go directly above LBL 29 in the traverse program, the other two steps replace existing steps. If you did not do the modification for the intersection program, the step numbers will be 2 smaller.

```
921LBI 60
                              93 CLMENU
                              94 "SPRAY"
                              95 KEY 1 GTO "SPRAY"
                              96 "LOAD"
                              97 KEY 2 GTO "LOAD"
                              98 "DUMP"
                              99 KEY 3 GTO "DUMP"
                              100 "TRIG"
                              101 KEY 4 GTO 61
                              102 "B→A"
                              103 KEY 5 GTO 62
                              104 "A→B"
                              105 KEY 6 GTO 63
                              106 KEY 7 GTO 31
                              107 KEY 8 GTO 15
                              108 MENU
                              109 RTN
                              110 LBL 61
                              111 SF 83
                              112 XEQ "TRIG"
                              113 GTO 15
                              114 LBL 62
                              115 XEQ "B→A"
                              116 GTO 15
                              117 LBL 63
                              118 XEQ "A→B"
                              119 GTO 15
Replace 70 KEY 7 GTO 31 with 70 KEY 7 GTO 60
Replace 89 KEY 8 GTO 15 with 89 KEY 8 GTO 60
```

We feel that you'll get a lot of use out of these three short programs, particularly "SPRAY", which is used for radial stakeout.

ØIÞLBL "DUMP"	26 CF 00	JI XC/Y
02 XEQ "BLK"	27 "Inst @?"	52 XK0?
03 X<>Y	28 ⊢"∿"	53 XEQ 01
04 1	29 PROMPT	54 →HMS
05 -	30 XEQ "POUT"	55 ⊢" AZ: "
06 1E3	31 STO 08	56 XEQ "DMS"
07 ÷	32 R+	57 ⊢"५ HD: "
08 +	33 STO 07	58 ARCL 23
09 STO 13	34 "Inst 🖻 "	59 AVIEW
10▶LBL B	35 XEQ 09	60 ADV
11 XEQ "OUT"	36 FS? 55	61 GTO A
12 XEQ "C≁"	37 AVIEW	62ÞLBL 01
13 ISG 13	38 AD¥	63 360
14 GTO B	39▶LBL A	64 +
15 RTN	40 CLA	65 RTN
TANERI "LOOD"	41 "Pt #? % "	66ÞLBL 09
IOFEDE LOHD		
17 KEY 9 GTO 10	42 PROMPT	67 FIX 00
17 KEY 9 GTO 10 18 "Point #?%"	42 PROMPT 43 XEQ "POUT"	67 FIX 00 68 CF 29
17 KEY 9 GTO 10 18 "Point #?%" 19 PROMPT	42 PROMPT 43 XEQ "POUT" 44 CLR	67 FIX 00 68 CF 29 69 ARCL 13
17 KEY 9 GTO 10 18 "Point #?%" 19 PROMPT 20 XEQ "PIN"	42 PROMPT 43 XEQ "POUT" 44 CLR 45 XEQ 09	67 FIX 00 68 CF 29 69 ARCL 13 70 FIX 04
17 KEY 9 GTO 10 18 "Point #?%" 19 PROMPT 20 XEQ "PIN" 21 GTO "LOAD"	42 PROMPT 43 XEQ "POUT" 44 CLA 45 XEQ 09 46 RCL- 03	67 FIX 00 68 CF 29 69 ARCL 13 70 FIX 04 71 SF 29
17 KEY 9 GTO 10 18 "Point #?%" 19 PROMPT 20 XEQ "PIN" 21 GTO "LOAD" 22▶LBL "SPRAY"	42 PROMPT 43 XEQ "POUT" 44 CLR 45 XEQ 09 46 RCL- 08 47 X<>Y	67 FIX 00 68 CF 29 69 ARCL 13 70 FIX 04 71 SF 29 72 RTN
17 KEY 9 GTO 10 18 "Point #?%" 19 PROMPT 20 XEQ "PIN" 21 GTO "LOAD" 22▶LBL "SPRAY" 23 KEY 9 GTO 10	42 PROMPT 43 XEQ "POUT" 44 CLR 45 XEQ 09 46 RCL- 08 47 X<>Y 48 RCL- 07	67 FIX 00 68 CF 29 69 ARCL 13 70 FIX 04 71 SF 29 72 RTN 73▶LBL 10
17 KEY 9 GTO 10 18 "Point #?%" 19 PROMPT 20 XEQ "PIN" 21 GTO "LOAD" 22▶LBL "SPRAY" 23 KEY 9 GTO 10 24 SF 21	42 PROMPT 43 XEQ "POUT" 44 CLR 45 XEQ 09 46 RCL- 08 47 X<>Y 48 RCL- 07 49 →POL	67 FIX 00 68 CF 29 69 ARCL 13 70 FIX 04 71 SF 29 72 RTN 73▶LBL 10 74 CLMENU
17 KEY 9 GTO 10 18 "Point #?%" 19 PROMPT 20 XEQ "PIN" 21 GTO "LOAD" 22▶LBL "SPRAY" 23 KEY 9 GTO 10 24 SF 21 25 XEQ "CL"	42 PROMPT 43 XEQ "POUT" 44 CLR 45 XEQ 09 46 RCL- 08 47 X<>Y 48 RCL- 07 49 →POL 50 STO 23	67 FIX 00 68 CF 29 69 ARCL 13 70 FIX 04 71 SF 29 72 RTN 73▶LBL 10 74 CLMENU 75 EXITALL

All three may be accessed directly from your traverse program, using the new menu (page 49). A short description of each follows.

dump

#1 #2	N= 1000.0000 E= 5000.0000 N= 1254.0000 E= 5100.0000	When you stroke with you are prompted for the first and last point numbers you wish to output.
#3 #1	N= 902.0000 E= 4825.0000 N= 865,0000	The calculator will print out a complete list (left) of all of the coordinates within that block of stored coordinates.

The printout can be made on the infra-red printer or through your computer, if you are using one of Rush Systems' "hookups". With the hookup, save a little time by setting the "delay" to 0 on your calculator first.

load

This one runs a closed loop on "PIN" for input of coordinates. When you execute this program you will get a new prompt for point number immediately after input of each coordinate pair, eliminating the need for executing "PIN" each time when you want to input a group of coordinates.

spray

When this program is executed		
it first prompts for the point number of the instrument's	Inst @ 2	
location, then prompts for the	1 AZ: 201 29'22.6 HD: 272.9762	н
inversing to each of the points.	3 AZ: 217 59 5.4 HD: 446.6867	н
The output is as shown to the right ("Inst $@ X$ " is only output if a printer is being used).	4 AZ: 214-09'47.9 HD: 470.1245	n

Inverse to the backsight first, setting that azimuth in the gun when you backsight. Turn the azimuth of each of the other points to lay them out.

If you want to lay out a group of unstored points from a provided "dump sheet", simply input them with "LOAD" and then inverse them with "SPRAY".

purging a file

This is another handy utility program, and it's practically free, using only 21 bytes of program space.

Use it to clear a block of stored coordinates when you need to	01)LBL "PRGE"
make room for new calculations.	02 STO 13
Input the loadel form for the	03▶LBL F
block of points you want to clear.	04 CLST
and THEN execute "PRGE" (short	05 XEQ "IN"
for PuRGE).	06 ISG 13
The block of coordinates is	07 GTO F
cleared by storing 0 into each of	08 END

the storage registers.

Before clearing the coordinates, you might want to print them out, so that you have a permanent record of them. Use "DUMP" for this. Incidentally, if you want more places shown in the output, you can change the output with FIX 06 or FIX 08 before executing "DUMP" (See pg. 12).

setting the radius point

The footnote on page 26 mentioned this program; it adds the radius point to the output when you traverse a curve. It's a trade for about 5 stored points if you add it. Because it is NOT a routine you will be calling up directly, you can add it anywhere in the middle of program memory.

Also, because it doesn't have any local labels, it isn't necessary to have it as a separate program, and it can be tacked on to any of the other subroutines.

insert 210 FS? 82 211 XEQ "RP" here 209 STO+ 05 210 RCL 18 211 CLMENU 212 CTO " Before starting to type in "RP", modify the program, "CURVE" as shown to the left by adding in two additional program steps. The subroutine is actually called from this program while you are traversing a curve.

00 { 79-Byte Prom } 01€LBL "RP" - 11 + 21 STO 13 22 R+ 12 RCL 11 02 CLMENU 23 XEQ "IN" 03 RCL 00 13 →REC 04 RCL 12 14 RCL+ 07 24 XEQ "OUT" 25 ADV 15 RCL+ 02 05 FS? 05 06 +/- $16 \times Y$ 26 "Radius Pt:" 07 -17 RCL+ 08 27 FS? 55 08 90 18 RCL+ 03 28 AVIEW 19 "Rad. Pt#?4" 29 XEQ "C*" 09 FS?C 05 10 +/-20 PROMPT 30 RTN The routine is run automatically, but there are a couple of things that you must remember to do. DELTA= 29-29-2 L= 174.5329 T= 88,1635 C= 173.6482 When the prompt "Rad. Pt#?" appears, you MUST input a point number before stroking the RUN button. Radius F #2 N= 128.9899 769.8463 When the program returns to the traverse routine and prompts for HD = 173.6482a point number after output of N = 450.3837#3 the chord, you MUST input a point number.

You can not just stroke the RUN button for the next consecutive point number. Output is as shown above.

additional programming

The pages which follow contain additional programs which you may add as options to what you already have in your calculator. The number of stored points traded by adding these programs is as follows:

Curve LAYout	•	•	•	•	·	•	•	•	.±29	points
Coordinate ROT ation .	•	•	•	•	•	•	•	•	.±39	points
PREdetermined Areas	•	•	•	•					.±33	points

automatic angle adjustment

After a traverse is closed, but before adjustment by compass or transit method, the angles should be balanced.

If you will refer back to the traverse example on page 30, you'll note that the original basis of bearings was N 27°30'00" E.

After turning the angles through the traverse we ended up with the same line, but it now shows the bearing as N 27°30'16" E, indicating that we have 16" too much angle in the traverse.

When you divide the 16" by the 4 traverse points, you get an angular error of 4" per turn.

While this is an acceptable amount of angular error, it still needs to be adjusted out. That's what this program does.

#1 N= 300.0000 E= 300.0000 N 27 30'00.0" E HD = 150.2000N = 315.1323F = 449 4358#2 S 25"00'08.0" W HD = 206.5500#3 N = 127.9378F = 362.1367N 82"09'18.0" W HD = 142.9000N= 147.4427 E= 220.5741 #4 N 27"30'16.0" E HD = 172.0000#5 N= 300.0024 F= 300.0067

The program actually recalls, then adjusts, each bearing in the traverse. More, having adjusted the bearing (or azimuth), it goes on to use the new bearing to recalculate (and store) the coordinates of each traverse point.

Go to 314▶LBL 38 This subroutine is called up directly from the closure routine in the traverse 315 XEQ "∠ADJ" program. One step (see left) has to be added to the traverse program.

Stroke shift, XEQ (GTO), TRAV then shift XEQ 38. Enter program mode, and the program pointer should be at "LBL 38". The step number may be different, depending on which options you've already installed, but the important thing is that the new step be the first step in LABEL 38.

Type in the new step, and we'll go on to type in the subroutine.

The program can go anywhere into the middle of the subroutine stack. Go to any of the subroutines that starts with program step 01, scroll up to 00, and begin the input.

01▶LBL "∡RDJ"	24 STO 14	47 XEQ "OUT"
02 RCL 13	25 R+	48 STO 08
03 STO 24	26 STO 07	49 R+
04 1	27 STO 16	50 STO 07
05 +	28⊅LBL A	51 RCL 16
06 STO 22	29 RCL 22	52 RCL 14
07 CF 22	30 RCL 13	53 XEQ "IN"
08 "Error/Turn?%"	31 X=Y?	54 1
09 PROMPT	32 GTO B	55 STO+ 12
10 FC? 22	33 XEQ "POUT"	56 STO+ 13
11 RTN	34 RCL- 08	57 GTO A
12 1E4	35 X<>Y	58▶LBL B
13 ÷	36 RCL- 07	59 RCL 23
14 →HR	37 → POL	60 XEQ "POUT"
15 +/-	38 X<>Y	61 STO 08
16 STO 11	39 RCL 11	62 R↓
17 CLX	40 RCL× 12	63 STO 07
18 STO 12	41 +	64 RCL 24
19 "Beginning Pt#?%"	42 X<>Y	65 XEQ "POUT"
20 PROMPT	43 →REC	66 RCL- 08
21 STO 23	44 STO+ 16	67 STO 03
22 XEQ "POUT"	45 X<>Y	68 R+
23 STO 08	46 STO+ 14	69 RCL- 07
		70 STO 02

Now, type in XEQ END, for program step 71. This assures that you won't branch to the wrong "LABEL A" or "LABEL B" by separating this program from the others.

In order to angle adjust a type "B" traverse such as the one on pages 31 and 32, it would be necessary to occupy point #3 = #4(existing) and turn a closing angle to the known course to determine the angular error.

With this routine installed, part of the traverse closure program will prompt:

Error/Turn?

If you DO NOT want to adjust the angles, return to the closure by stroking

If you DO want to adjust the angles, input the number of **seconds** of error per turn, and then stroke

R/S

Beginning Pt#?

This prompt will appear if you ARE adjusting the angles. Input the point number used for the first traverse point, and stroke

Closure: The N 31*03'29.4* W HD = 0.0007 trav #1 N= 300.0000 the E= 300.0000 the closs

The calculator will do the adjusting of the angles **and** coordinates, then continue with the closure. For the traverse example from pages 29 and 30, the angle adjustment has reduced the closure error to 0.0007', with ten times the precision of the original example.

additional HP-42S programming

Programming Examples and Techniques Hewlett-Packard. Supplements the 42S owner's manual.

Synthetic Programming on the HP-42S EduCALC Technical Notes (TN#24) by Richard Nelson. Free (send a 25¢ stamp with your request) from

> EduCALC Mail Store 27953 Cabot Road Laguna Niguel, CA 92677

Individual solutions booklets (available summer 1989) by **D'Zign**. Titles will include:

Vertical Alignment EDM Slope Staking Topography Alignment and Offsets Spiral Curves Urban Surveys

CURVE LAYOUT

This program makes short work of calculating the layout of curves. Corrected chords are output if the curve is to be staked along an offset by the chord and deflection method, and adjusted tangent distances and offsets are output if you want to stake an offset by the tangent-offset method.

the subroutine, "STA"

shown to the right.

OF NU DU LUCTOR	There is one subroutine to be input for				
MIPLBL "SIH"	this program, shown to the left. Since				
02 CF 29	it is not a routine you would normally				
03 FIX 00	call directly from the keyboard, it can				
04 STO 21	go at the end portion of the program				
05 1E2	catalogue.				
06 ÷	5				
07 ENTER	Go to "INV", enter the program mode,				
08 IP	and then scroll upward to step 00 to				
09 "';"	begin typing in the program steps				
10 ARCL ST X	shown.				
11 -					
12 ⊢"+"	This subroutine changes a number,				
13 FIX 03	XXXX.xx, into the 'station' form,				
14 1E2	XX+XX.xx. This enhances the output				
15 ×	and makes for one less chance to mistake				
16-10	a number for something else.				
17 X>Y?	n a				
18 ⊢"0"	"Station 1,234.56" does not read as a				
19 ARCL ST Y	station to most surveyors, while 12+34.56				
20 RCL 21	is immediately recognized as a station				
21 SE 29	even if it isn't labeled "station".				
22 FIX 04	The star UEQU (05 and 14) is is not with				
23 RTN	the "E " key just to the left of the clear				
kov Stroko F 2	and then the idivided (step 05) on itimed				
(stop 14) kov to	and then the divide (step 05) of times				
(step 14) key to	complete the entry.				
editing "CURVE"					
Since this program also uses					
"CURVE" as a subroutine, you					
have to do some	quick editing.				
a	148 FS? 95				
GO tO "CURVE",	then go to step 149 GTO "CLAY"				
147 and insert th	e two new steps				

The new steps inserted into "CURVE" will send program execution back to the layout program after the curve data has been calculated.

The main program, "Curve LAYout", should be near the top of program memory, for easy access. Go to "COMP" or "TRAN", (whichever you input), and scroll upward to 00. Begin input of the program steps shown below.

O1 LBL "CLAY"	25 CLMENU	49 GTO 02
02 FS?C 95	26 "B.C."	50)LBL 05
03 GTO 00	27 KEY 1 GTO 01	51 STO 08
04 CF 02	28 "P.I."	52 RCL- 24
05 CF 03	29 KEY 3 GTO 03	53 STO 06
06 CF 04	30 "E.C."	54 RCL+ 20
07 CF 06	31 KEY 5 GTO 05	55 STO 14
08 CF 07	32 MENU	56€LBL 02
09 SF 08	33 "Known Station?"	57 RCL 06
10 SF 09	34 PROMPT	58 STO 07
11 SF 95	35)LBL 01	59 XEQ "STA"
12 GTO "CURVE"	36 STO 06	60 ⊢" B.C.4"
13)LBL 00	37 RCL+ 20	61 AVIEW
14 ADV	38 STO 14	62 RCL 14
15 1	3 9 RCL 06	63 XEQ "STA"
16 STO 16	40 RCL+ 24	64 ⊢" P.I. y "
17 0	41 STO 08	65 AVIEW
18 STO 15	42 GTO D2	66 RCL 08
19 STO 09	43▶LBL 03	67 XEQ "STA"
20 RCL 11	44 STO 14	68 ⊢" E.C.५"
21 → RAD	45 RCL- 20	69 AVIEW
22 2	46 STO 06	70)LBL 04
23 ×	47 RCL+ 24	71 CLMENU
24 STO 05	48 STO 08	72 " 3% LC"

73 KEY 2 GTO A	103)LBL F	133 ×
74 "∡&SC"	104 CLA	134 RCL× 16
75 KEY 4 GTO B	105 XEQ "STA"	135 RTN
76 "T 0/S"	106 AVIEW	136)LBL 03
77 KEY 6 GTO C	107 RCL- 07	137 FIX 03
78 MENU	108)LBL 08	138 →HMS
79 CLA	109 RCL 08	139 "Chd = "
SO PROMPT	110 RCL- 07	140 FC? 09
81)LBL A	111 X<>Y	141 ARCL ST Z
82 SF 03	112)LBL 10	142 FS? 09
83 GTO 10	113 SF 07	143 ARCL ST Y
84)LBL B	114)LBL 09	144 AVIEW
85 CF 09	115 STO+ 07	145 "Def.∠ = "
86 SF 03	116 XEQ 02	146 FS? 05
87 GTO 10	117 RCL 07	147 +/-
88)LBL C	118 FC? 07	148 0
89 CF 09	119 XEQ 20	149 X<>Y
90 CF 08	120 RCL- 06	150 X <y?< td=""></y?<>
91 SF 04	121 XEQ 02	151 360
92)LBL 10	122 RCL 10	152 HMS+
93 CLMENU	123 FS? 03	153 XEQ "DMS"
94 "0/S"	124 GTO 03	154 AVIEW
95 KEY 1 GTO D	125 FS? 04	155 CLA
96 "INTVL"	126 GTO 04	156 FS? 02
97 KEY 3 GTO E	127)LBL 02	157 GTO 15
98 "STA"	128 RCL÷ 05	158 GTO 10
99 KEY 5 GTO F	129 STO 10	159)LBL 04
100 MENU	130 SIN	160 FIX 03
101 CLA	131 RCL× 11	161 X<>Y
102 PROMPT	132 2	162 → REC

163 X<>Y 164 FS? 05 165 +/-166 RCL 15 167 + 168 X<>Y 169 "Dist = " 170 ARCL ST X 171 = 40/S = 1172 ARCL ST Y 173 AVIEW 174 FS? 02 175 GTO 15 176 GTO 10 177€LBL E 178 STO 09 179 SF 02

180 RTN 181 LBL D 182 STO 15 183 FIX 02 184 X<O? 185 SF 06 186 FC? 05 187 +/-188 RCL+ 11 189 RCL÷ 11 190 STO 16 191 RCL 15 192 ABS 193 "Offset = " 210 0 194 ARCL ST X 195 FC? 06 196 ⊢"' RT"

197 FS? 06 198 F"' LT" 199 AVIEW 200 ADV 201 FIX 04 202 GTO 10 203 LBL 15 204 RCL 08 205 RCL 09 206 RCL+ 07 207 X<Y? 208 GTO F 209 ADV 211 STO 09 212 CF 02 213 GTO 10 214 END

To use the curve layout program stroke XEQ, then the key which corresponds to "CLAY". This brings up the first prompt bar [14.6] at the structure of the struct

1. Input the two known parts of the curve, the same as when you use the curve calculation program, "CURVE"

Output will be the curve data for the curve, through the output of the chord.

Known Station?

2. Input the station at the B.C., P.I. or E.C. and stroke the key which corresponds to the station input.

Output will be the stations of the B.C., P.I. and E.C., followed by the prompt bar for selection of the type of layout you want, **Example 1989** 1989.

- 3a. For deflection and LONG chord,
- 3b. For deflection and SHORT chord,
- 3c. For tangent-offset solution, stroke

- 4. If the curve is to be staked along an offset to centerline, input the offset distance (stroke the +/- key if the offset is to the left of centerline) and stroke
- 5. If you want to calculate stations at constant intervals, input the interval distance and then stroke

Input the first station for which you want a solution, stroke

Output will be the station and either the deflection/chord or tangent/offset solution to the station.

If you have selected an interval, the program will continue through the curve without further input. When the interval stations have been completed the program will again display the prompt bar, allowing you to input additional stations which were not on even interval stations (inlet locations, etc.).

The example shown to the right is the solution for a curve with a radius of 500.00' and a central angle of $30^{\circ}00'00''$, solved for deflection and long chord, along an offset of 10.00' left.

6.

An additional station at 11+61.27 was calculated for the location of the centerline of a driveway.

As always, if you are not using a printer continue to stroke the **R/S** key for additional output or the next prompt.

You might want to try the same curve to see if you get these answers. If you don't, you should re-proof the program listing for incorrect steps. R = 500 0000 D= 11'27'33.0" DELTA= 30'00'00'0' T= 133'9746 C= 258'8190 10+00.000 B.C. 11+33.975 P.I. 12+61.799 E.C. 0ffset = 10.00' LT 10+50.000 Chd = 251'53.2" 11+60.000 Chd = 101 830 Def.4 = 5'43'46.5" 11+50.000 Chd = 103'830 Def.4 = 5'43'46.5" 11+50.000 Chd = 202.643 Def.4 = 11'27'33.0" 12+50.000 Chd = 202.643 Def.4 = 14'19'26.2" 11+61.270 Chd = 163'783 Def.4 = 9'14'24.3"

62

COORDINATE ROTATION

Coordinate transformation, or bearing rotation, is used to change a traverse from one "grid system" to another. A field traverse may be run without knowing the real basis of bearings, by beginning with an assumed bearing.

All of the normal adjustments can be made and the traverse worked with, new points calculated within the traverse, and so on.

When a basis of bearings becomes known (we finally got the description from the client), the bearings of the traverse may be rotated to match the "deed" bearings.

angle convention

The difference between the assumed (old) bearing along a known line and the deed (new) bearing of the same line is the ROTATION ANGLE. This program accepts the rotation angle as POSITIVE FOR CLOCKWISE and NEGATIVE FOR COUNTERCLOCKWISE.

Except when "blocks" of coordinates have been run, you have the option of reviewing or restoring the coordinates to the old system at any time. This program also allows two types of output, with or without the rotated courses also being shown, and the courses may be output as either azimuths or bearings.

input options

There are two types of setup input possible; if the rotation angle is known or if two points in each system are known. The instructions for input of the required information for each of the systems is shown on the following pages. Once the information has been input for either system, the solution steps for transformation of the points are the same for both systems (see solutions).

renumber option

A unique feature within this program allows you to transform points and renumber them at the same time, leaving the original coordinates as they were, in the old system. This can be handy for calculating the location of similar buildings on different lots.

rotation angle known

Call the program up by stroking

Rotation $\measuredangle = ?$

1.

Input the rotation angle, in degrees, minutes and seconds. If the angle is counterclockwise, change sign with the +/- key, then stroke

Scale Factor?

2.

If the scale factor is 1:1, it is not necessary to input anything. If it is <u>not</u> 1, input the new factor before stroking

Rotation Pt#?

3.

Input the point number of the rotation point, stroke

OUTPUT will be the point number and coordinates (if the printer is being used, "Rotating @ #x" will be output also).

New Coord's? YES NO. 1997

- 4a. If the coordinates of the rotation point are the same in the new system as in the old, stroke
- 4b. If there are different coordinates for this point in the new system, stroke

R/S

If the answer to the last prompt was "yes" you will also receive the following prompts:

N =? 4b-1. Input the new north-coordinate, stroke R/S E =? 4b-2. Input the new east-coordinate, stroke R/S Next Point? Stroking any key (beginning input of the next point number) shows the prompt bar. GO TO "OPTIONS" two points in each system known When the prompt, Rotation \measuredangle =?, is displayed, 1. no input is necessary. Just stroke R/S Rotation Pt#? 2. Input the point number of the pivot point, stroke R/S New Coord's? 445 NO If the rotation point will have new coordinates 3. in the new system stroke 🗰 . If the coordinates are the same in both systems, stroke If the answer was "yes" you will receive the following prompts: N =?

4a.	Input the new north-coordinate, stroke					
E =?	_					
4b.	Input the new east-coordinate, stroke					
Second Poi	nt?					
5.	Input the point number of the second known point and stroke					
NEW X	N † E					
6a.	Input the new north-coordinate of the second point and stroke					
6b.	Input the new east-coordinate of the second point and stroke					
Next Po	int? Stroking any key will bring up the prompt bar.					
OPTIONS						
At this point in the program you decide on the output you want. This can be just the new coordinates for the transformed points, or you can also calculate the directions and distances between the new coordinates.						
1.	If you want the distances and BEARINGS output, stroke					
2.	If you want the distances and AZIMUTHS output, stroke					

You can transform a BLOCK of coordinates automatically, and use either of the above options at the same time.

1. After selection of the output type (above) input the block 'code', **AAA.bbb**, where AAA is the first point number and bbb is the second (three-digit input for the second number). Stroke

Type?

2. With practice you can reverse some of the stored points by stroking →OLD, but for normal transformation to the new system stroke

OUTPUT will be automatic, transforming all of the points within the block before stopping.

You can change the point numbers as the points are rotated if you stroke **This** option will NOT work if you are rotating a BLOCK of coordinates, and requires input of each point. You may not return to the "old" system while using this option either.

After input of the OLD point number in response to the "Next Point?" prompt, and stroking **NEX**, you will receive the prompt

NEW PT#?

1. Input the number you want the point to have in the NEW system and stroke

R/S

OUTPUT will be the transformed coordinates under the new point number.

SOLUTIONS

Next Point?

- 1. Input the point number of the point which you wish to transform. (NOTE: the point numbers input for setup have not yet been transformed.
- 2a. To transform from the "old" system to the "new" system, input the point number and stroke
- 2b. To transform from "new" system to "old" stroke

The "old" system coordinates will be displayed (or printed out) but are not stored again under the point number.

Store?

2**b-**1.

Answer NO if you do not want to restore the point with the "old" coordinates, YES if you do.

If your answer is yes, the message "STORED" will be seen, briefly, in the display.

Next Point?

Continue repeating solution step 2a and/or 2b as needed.

the program listing

This program uses 700 bytes of programming. This is the equivalent of about 39 point numbers. The program should be input at a place where it is easy to find when you stroke the XEQ key, so why not just put it in at the .END.? Stroke shift, XEQ .END. and enter program mode.

00 (700-Byte Prgm)	03 XEQ "CL"	06 1			
O1▶LBL "C.ROT"	04 SF 21	07 STO 05			
02 XEQ "F…"	05 SF 10	08 CF 22			
09	"Rotation $\measuredangle = ?4$ "	39	STO 05	69	CLMENU
----	-----------------------------------	----	-----------------------------	----	-----------------------
10	PROMPT	40	$\mathbf{X} <> \mathbf{Y}$	70	XEQ "YN"
11	CLA	41	XEQ 05	71	FC? 10
12	FC? 22	42	STO 04	72	RTN
13	GTO 02	43	"NEW "	73	R ≁
14	+/-	44	XEQ 07	74	GTO 08
15	→ HR	45	⊢"N ↑ E५"	75	LBL A
16	STO 04	46	FIX O4	76	SF 01
17	CF 22	47	PROMPT	77	CF 02
18	"Scale Factor?4"	48	RCL- 03	78	XEQ DO
19	PROMPT	49	$\mathbf{X} < > \mathbf{Y}$	79	FS? 03
20	CLA	50	RCL- 02	80	RCL 13
21	FS? 22	51	+ POL	81	STO 16
22	STO 05	52	STOX 05	82	XEQ "POUT"
23	XEQ O3	53	X <> Y	83	RCL- 01
24	XEQ 14	54	XEQ 05	84	X <> Y
25	GTO a	55	STO- 04	85	RCL- 00
26	RTN	56	GTO a	86	→ POL
27	LBL 02	57	LBL OO	87	RCL × O5
28	XEQ 03	58	FC? 03	88	X<>Y
29	XEQ 14	59	RTN	89	RCL- 04
30	"Second Point?%"	60	ISG 13	90	X <> Y
31	PROMPT	61	RTN	91	+ RE C
32	CLA	62	CF 03	92	RCL+ 02
33	XEQ "POUT"	63	GTO a	93	X < > Y
34	RCL- 01	64	LBL 14	94	RCL+ 03
35	X<>Y	65	CF 21	95	CLA
36	RCL- 00	66	" New Coord's?"	96	FS? 04
37	+ POL	67	AVIEW	97	XEQ 20
38	1 / X	68	SF 21	98	XEQ "IN"

99 FS? 09	129 "OLD "	159 RCL 16
100 XEQ 09	130 FS? 55	160 STO 13
101 XEQ "OUT"	131 AVIEW	161 R+
102 STO 08	132 STO 16	162 XEQ "IN"
103 X<>Y	133 XEQ "POUT"	163 CF 21
104 STO 07	134 RCL- 03	164 " STORED 4"
105 X<>Y	135 X<>Y	165 AVIEW
106 CF 10	136 RCL- D2	166 SF 21
107 " New"	137 →POL	167 GTO a
108 FS? 55	138 RCL÷ 05	168 STOP
109 AVIEW	139 X<>Y	169▶LBL 03
110 XEQ "C*"	140 RCL+ 04	170 "Rotation Pt#?4"
111▶LBL a	141 X<>Y	171 PROMPT
112 FS? 03	142 →REC	172 CLA
113 GTO 01	143 RCL+ OO	173 CF 29
114 XEQ 04	144 X<>Y	174 FIX OO
115 "Next Point?"	145 RCL+ 01	175 "Rotating @ #"
116 PROMPT	146 CF 10	176 ARCL ST X
117 CLA	147 XEQ "C+"	177 ⊢"⊊"
118 FS? 02	148 ADV	178 FS? 55
119 GTO B	149 CF 21	179 AVIEW
120 FS? 01	150 " STORE?"	180 XEQ "POUT"
121 GTO A	151 AVIEW	181 STO 01
122 STOP	152 SF 21	182 STO 07
123DLBL B	153 CLMENU	183 STO 03
124 CF 01	154 XEQ "YN"	184 R+
125 SF 02	155 FC? 10	185 STO 00
126 XEQ OD	156 CLX	186 STO 08
127 FS? 03	157 FC? 10	187 STO 02
128 RCL 13	158 GTO a	188 FS? 55

218 "→OLD" 247 X>O? 189 XEQ 11 219 KEY 2 GTO B 248 RTN 190 RTN 191)LBL 06 220 "BLK" 249 360 221 KEY 3 GTO 06 250 + 192 SF 03 222 "INV•A" 193 1 251 RTN 223 KEY 4 GTO 10 2520LBL 07 194 -224 "INV•B" 253 FIX 00 195 STO 13 225 KEY 5 GTO 12 254 ARCL 13 196 CF 21 226 "RE #" 197 " Type?" 255 ⊢" " 198 AVIEW 227 KEY 6 GTO 16 256 RTN 199 SF 21 257)LBL 09 228 MENU 258 XEQ "OUT" 229 FS? 03 200 XEQ 04 201 RTN 230 GTO 15 259 XEQ "INV" 231 RTN 202)LBL 01 260 RTN 261 LBL 11 232)LBL 08 203 FS? 02 204 GTO B 233 XEQ "PN" 262 R* 205 FS? 01 234 STO 03 263 CF 10 264 XEQ "C↑" 206 GTO A 235 STO 07 265 ADV 236 R+ 207 LBL 10 266 RTN 208 SF 09 2**37** STO 02 209 CF 00 238 STO 08 267)LBL 16 268 SF 04 210 GTO 04 239 RTN 269 RTN 211 LBL 12 240)LBL 15 270 LBL 20 212 SF 09 241 FS? 02 213 SF 00 271 " NEW PT#?" 242 GTO B 214 LBL 04 272 PROMPT 243 FS? 01 215 CLMENU 244 GTO A 273 STO 13 216 "NEW" 274 R+ 245 RTN 217 KEY 1 GTO A 2460LBL 05 275 .END.



The small traverse shown above will be used for the keystroke examples. Before beginning use "LOAD" (or "PIN") to input the coordinates in the "old" system, so that they are in memory.

In this first example we will rotate the bearings 5° to the left. We will also use the **auto-inverse** option to output the new bearings and distances as the points are rotated.

Stroke	prompt: Rotation Pt#?
XEO THE Prompt: Rotation	keystrokes: 1 R/S
keystroke: 5 ≁_ R⁄S	output: _{Rotating} 0 #1 #1 ½= :000.0000
prompt: Scale Factor? keystroke:	E= 150.0000 prompt: New Coord's?
R/S	keystroke:

prompt: Next Point? As an example of how the points may be restored to keystrokes: the "old" system, stroke 2 120 2 output: N 3°31'50.8" E HD = 101.1187 output: 0∟D #2 N= 200.0090 F= 115.0000 N= 200.9268 F= 106.2273 prompt: STORE? YES NO prompt: Next Point? keystroke: keystrokes: 3 . STORED . . . output: 5 53"10'47.4" HD = 127.4755 prompt: Next Point? New #3 N= 124.5301 E= 208.2741 Go ahead and change points #3 and #4 back to the old system, and you'll be ready to try the second example prompt: Next Point? without having to re-input keystrokes: the coordinates. 4 This is an example of the output: 541°50'51.4" W HD = 109.6586 type where the coordinates of two points are known in each system, and uses New #4 N= 42.8430 E= 135.1152 "new" coordinates 200/200 for #1 and 300/215 for #2. Run this one with prompt: Next Point? AZIMUTH inverse. keystrokes: keystrokes: XEQ output: N 31°33'54,2" HD = 67.0820 prompt: Rotation $\measuredangle = ?$ keystroke: New #1 N= 100.0000 E= 100.0000 R/S prompt: Rotation Pt#? prompt: Next Point?

of







PREDETERMINED AREAS

There are two types of solution routines for solving for a predetermined amount of area. These are used to "part the land", or cut off a specific quantity of property from a larger parcel.

The illustration (below) shows a typical use of the type of solution called **Line Through A Point**. A parcel boundary has been run (points 1 through 4) and the area calculated.

To divide it into two equal parcels, first set two arbitrary points, 5 and 6 (6 is the half-way point along the base 1-4) and calculate the area of one parcel.

In this case, the area of the parcel 1, 2, 5, 6, 1 was run, and the shaded portion represents the remainder needed to have each parcel contain $\frac{1}{2}$ of the original area.

In this example, point number 6 is used as hinge point, and a line from 6 is intersected with the line from #5 to #3 to form a triangle that contains the required amount of area.

Input would be point #5, the bearing of the line from 5 to 3, point 6 and the area needed.



Two Sides Parallel is the second of the routines, and defines the boundary of a trapezoidal parcel whose area is predetermined.

If the requirement is that the area be one-half of the original parcel, but with the dividing line parallel to one of the lines of the original parcel, we would use this type of solution.



Input required for this method would be point #2, the bearing of line 2-3, point #1, the bearing of line 1-4, and the required area. The bearings are input in the direction **away** from the known points.

the trade

Adding this program to your set will replace about 30 points in storage usage. In addition to the main program there are a couple of short subroutines to be added. We'll start with those.

```
125 GTO 02
              If you are going to add "PRE-A" to your
              program file, the program steps shown
126 LBL "BR"
              to the left are the ones that will be doing
127 "4Brg "
               the labeling of the output.
128 XEQ 01
               A lot of program steps can be saved by
129 GTO "81"
              inserting them into the subroutine stack,
1300LBL "DS"
               because they use the same processing
131 CF 29
               labels as some of the other subroutines.
132 FIX 00
               Go to program "A0", enter program
133 ARCL 13
               mode, and scroll down two steps so that
134 ⊢" Dist"
               the pointer is at 124 SF 85. Begin typing
               in the new steps (shown to the left).
135 GTO 02
1361LBL 01
               After they have been entered, scroll
137 CF 29
               down once. Step 141 should be XEQ 06.
138 FIX 00
               It wouldn't hurt to proof-read the new
139 ARCL 13
                        Make sure that step 134 is
               steps.
1400LBL 02
               "append, space, Dist".
```

the program listing

This program can fit in nicely between "INT-X" and "CURVE" in the main menu.

00 (532-Byte Pro	jm }	
O1▶LBL "PRE-A"	13•LPL 03	25 XEQ "BR"
02 XEQ "F…"	14 SF 10	26 STO 02
03 XEQ "CL"	15 SF 00	27)LBL 05
04 CLMENU	16 "1st Pt#?%"	28 "2nd Pt#?%"
05 CF 21	17 PROMPT	29 PROMPT
O6 "Triangle?"	18 STO 15	30 STO 16
D7 AVIEW	19 XEQ "POUT"	31 1E3
08 SF 21	20 STO D1	32 ÷
D9 XEQ "YN"	21 X<>Y	33 RCL+ 15
10 FS? 10	22 STO DD	34 XEQ "CODE"
11 GTO D3	23 FC? D1	35 →HR
12 SF 01	24 GTO 05	36 STO 23

37 RCL 16	67 RCL 06	97 ARCL 17
38 XEQ "POUT"	68 ×	98 XEQ 04
39 STO D4	69 ÷	99 XEQ 22
40 X<>Y	70 2	100 RCL 05
41 STO 03	71 ×	101 COS
42 XEQ "BR"	72 STO 09	102 ACOS
43 STO 05	73 RCL 15	103 RCL 23
44 "Next Pt#?4"	74 STO 13	104 +
45 PROMPT	75 RCL 05	105 →HMS
46 STO 17	76 RCL 06	106 RCL 09
47 1	77 →REC	107 XEQ 06
48 +	78 RCL 09	108 ARCL 17
49 STO 22	79 -	109 -"-"
50▶LBL 08	80 +/-	110 ARCL 16
51 "Req'd Area?y"	81 →POL	111 XEQ 04
52 PROMPT	82 X<>Y	112 XEQ 22
53 STO 08	83 RCL 05	113 FC? 00
54 FS? D1	84 +	114 STOP
55 GTO D1	85 COS	115 RCL 07
56 FC? OD	86 +/-	116 RCL 05
57 GTO 02	87 ACOS	117 -
58 XEQ 00	88 RCL 23	118 RCL 09
59 RCL 05	89 X<>Y	119 → REC
60 -	90 -	120 RCL 03
61 STO 05	91 →HMS	121 +
62)LBL 02	92 X<>Y	122 X<>Y
63 RCL 08	93 CF 10	123 RCL 04
64 RCL 05	94 XEQ 06	124 +
65 SIN	95 ARCL 15	125 RCL 17
66 ABS	96 - "-"	126 STO 13

127 R+	157 PI	187 RCL 08
128 XEQ "IN"	158 →DEG	188 2
129 XEQ "OUT"	159 RCL 07	189 ×
130 FIX 04	160 RCL- 02	190 X<>Y
131 ADV	161 COS	191 ÷
132 XEQ "C*"	162 ACOS	192 STO 09
133 STOP	163 -	193 RCL 11
134€LBL 00	164 STO 11	194 SIN
135 360	165€LBL 02	195 ÷
136 RCL 01	166 RCL 06	196 STO 24
137 RCL 04	167 X*2	197 RCL 11
138 -	168 RCL 11	198 RCL 23
139 RCL 00	169 COS	199 X<>Y
140 RCL 03	170 LASTX	200 -
141 -	171 SIN	201 →HMS
142 →POL	172 ÷	202 X<>Y
143 STO 06	173 RCL 12	203 XEQ 06
144 R+	174 COS	204 ARCL 15
145 X<0?	175 LASTX	205 ⊦"-"
146 +	176 SIN	206 ARCL 17
147 STO 07	177 ÷	207 XEQ 04
148 RTN	178 +	208 XEQ 22
149)LBL 01	179 STO 10	209 XEQ 07
150 FC? 00	180 RCL× 08	210 RCL 09
151 GTO D2	181 2	211 RCL 12
152 XEQ OD	182 ×	212 SIN
153 RCL- 05	183 -	213 ÷
154 COS	184 SQRT	214 STO 10
155 ACOS	185 STO 14	215 RCL 12
156 STO 12	186 RCL+ O6	216 RCL 23

217	+	240	RCL	17	263	R≁
218	+ HMS	241	STO	13	264	XEQ "A→B"
219	$\mathbf{X} < > \mathbf{Y}$	242	RCL	00	265	RTN
220	XEQ O6	243	RCL	01	2661	LBL 07
221	ARCL 22	244	XEQ	" I N "	267	RCL 23
222	⊢"-"	245	XEQ	"OUT"	268	+ HMS
223	ARCL 16	246	ADV		269	RCL 14
224	XEQ D4	247	XEQ	"C † "	270	XEQ O6
225	XEQ 22	248	ISG	13	271	ARCL 17
226	FC? 00	249	STO	ST X	272	⊢""
227	GTO 03	250	RCL	03	273	ARCL 22
228	RCL D2	251	RCL	04	274	XEQ D4
229	RCL 24	252	XEQ	" I N "	275	XEQ 22
230	→REC	253	XEQ	" OUT "	276	RTN
231	STO+ 00	254	AD∨		2771	LBL 04
232	$\mathbf{X} <> \mathbf{Y}$	255	XEQ	"C↑"	278	ASTO 13
233	STO+ 01	256	ADV		279	CLA
234	RCL 05	257	RTN		280	RTN
235	RCL 10	2581	LBL	22	281	LBL D6
236	→REC	259	CF :	10	282	CLA
237	STO+ 03	260	XEQ	"DS"	283	FIX DO
238	$\mathbf{X} <> \mathbf{Y}$	261	⊢"գ		284	CF 29
239	ST0+ 04	262	AVIE	ΞW	285	END

choosing the type

The type of solution to be used is selected by your response to the first prompt:

Triangle?

If you want to use the LINE THROUGH A POINT routine, answer . If you want the TWO SIDES PARALLEL routine, stroke



two sides parallel 1st Pt#? Input the point number of the first point 1. R/S Brg 1 = ?2. Input the bearing from the first point ENTER Input the quadrant code, in the direction away from the point, and stroke R/S 2nd Pt#? Input the point number of the second fixed 3. point and stroke R/S Brg 2 = ?Input the bearing of the line radiating from 4. the second fixed point and stroke ENTER Input the quadrant code, in the direction away from the point, and stroke R/S Next Pt#? 5. Input the next UNUSED point number. This point number will be assigned to the point along the line defined by bearing 1. The next highest point number will be assigned to the point along bearing 2. Stroke R/S Req'd Area? 6. Input the required area and stroke R/S OUTPUT will be the distances and bearings of the three lines, followed by the coordinates of the two new points.





ultimate sizing

After you have input all of the programs you are planning to use, you can re-size the calculator to hold the maximum number of coordinate pairs. Each pair of coordinates occupies two registers, so you want to size with as many registers as you can.

- Size to 0025. 1.
- 2.

Check the available memory (hold down the key under MEM, in CATALOG), and jot down the number.

This is the number of **bytes** available. Divide by 9 (each register uses 9 bytes) and add 23 to this new number.

3.

Re-size to the number you just calculated.

4.

To calculate the number of points you can store, divide the number you jotted down by 18 and subtract 1.

adding more programs

If, at a later date, you decide to add more programs to what you now have in the calculator, re-size to 0025 before beginning, and then repeat the process above after you are done.

MORE HP42S PROGRAMS

We have a number of new booklets, and another book, of programs for the HP42S in the works! Here are some of the titles:

Vertical Alignment (booklet, \$10.00)

Calculates CONTINUOUS vertical alignment without changing back and forth between Grade and Curve routines. Calculates vertical intersections, symmetrical or asymmetrical vertical curves. Solves for station when the elevation is known, or the station can be given, to calculate the elevation.

Spiral Curves (booklet.

Calculate 1 Joordinates to any station, or offset to a **PRIN**, within a spiral system. Options include **OF** hate output, auto-inverse

Calculates intersections of the entrance or exit spiral with a circular curve or straight line.

Topography (booklet, \$10.00)

This one turns your 42S into a manual data collector, complete with a labeling system that you can customize to suit the type of topo work you do. All shots are stored as finished data, by shot number, for later output. Choice of 3-D coordinates or Station-Offset-Elevation for the output.

EDM Slope Staking (booklet, \$10.00)

Set up anywhere near an alignment and slope stake it. Sets slope stakes from the remote instrument location directly. Includes a three-point resection program for finding the instrument's location by either station-offset or coordinates. All data needed to mark the stake is output (or may be stored), and there is a subroutine for setting the reference stake.

Alignment/Offsets (booklet, \$10.00)

Follows any alignment's circular curves and tangents, letting you calculate the coordinates or radial ties to any station or offset to a station. Coordinate output, auto-inverse, or both.

Triangle Solutions (booklet, \$10.00)

The 42S version of the most complete triangle solutions program ever available. Solves with any of the following knowns: ASA SAA SAS SSA SSS Area-SS Area-AA Area-SA.

keep in touch

As always, we're anxious to make programs available to surveyors who need them. Make sure that we have your name and address on file so that we can send you the 42S Newsletters as they are published. These newsletters contain useful hints and additional programming.



The Most Commonly Asked Questions

The following questions and answers were compiled from the calls and letters we've received in the past 4+ years that we've been publishing solution books for the HP42S calculator, and are included here in the event that your question is one of them.

Q: How do you type in the **END**?

A: There are a number of ways . . . one easy way is to stroke XEO ENTER and type it in, using the alpha keys. Because you stroked XEO first, the calculator will recognize that this in not an alpha input, and substitute the actual function when you stroke ENTER again. You may input *any* function by this method.

You may also take advantage of the built-in *function catalog*, stroke $\square \blacksquare$ (catalog), and then the \blacksquare menu key. You may scroll up or down with the \blacksquare or \blacksquare keys, and *all* of the calculator's functions are in there. When you reach the one you want, just stroke the key under the menu item.

Q: How do you type in the **indirect** calls, such as step 138 in the CURVE program on page 10?

A: The indirect calls are made by stroking \square . In the case of the call above, first stroke \square 6 (flags), then \blacksquare , to bring up the prompt CF_-, then stroke \square . Some of the indirect calls give a secondary prompt, requiring another \square .

Q: How do I type in a ARCL command?
A: Enter alpha mode before stroking RCI or STO . . .

\$25.00 U.S. 2173 ISBN 0-944889-14-X -