

Support Contacts

Contact the Hewlett Packard calculators Service and Support web site at:

www.hp.com/calculators/service/index.html

or use the following contact details:


- Australia +61 3 8877 8000
- Canada +1 970 392 1001
- France +33 (0)1 64 86 72 22
- Singapore 1 800 271 3337
- Spain +34 917 820 111
- UK +44 (0) 121 749 7913
- USA +1 970 392 1001

The Storage Compartment

The storage compartment holds the cables and this card.

To open the storage compartment:

1. Turn the ODU upside-down.
2. Press both of the storage door snaps inwards to release the door.




Part Number: F1212-90002

Hewlett-Packard Australia Limited
A.C.N. 004 394 763

347 Burwood Highway
Burwood East, Vic. 3151
Telephone (03) 9210 5555



Using the Overhead Display Unit (ODU)



- 1 Upward screen position button
- 2 Downward screen position button
- 3 Contrast Knob
- 4 Battery indicator LED
- 5 Connector

Overhead Display Unit

Using the Overhead Display Unit (ODU)

1. Select the right cable and attach it to your calculator.


For 48-series calculators, use the cable that attaches to the memory card slot. Attach the cable to the first plug-in card slot, that is, the slot closest to the calculator's display screen.

For all other models, use the cable that attaches to the calculator's serial port.
2. Connect the cable to the ODU.
3. Turn on the calculator and the ODU.
4. On the ODU, use the buttons to adjust the screen position, and turn the knob to adjust the contrast.

Cleaning the ODU

Use only a damp cloth to clean the ODU.

WARNING: Do not use a solvent or detergent to clean the ODU.



Changing the Battery

The ODU uses a standard 9-volt battery, PP3 or equivalent. You need to replace the battery when the indicator LED indicates that it is low. Typically, a battery lasts for approximately two years. To replace the battery:

1. Turn the ODU upside-down.
2. Remove the eight screws, including the screws inside two of the feet.
3. Remove the back of the ODU.
4. Replace the battery.
5. Replace the back and the screws.

Warranty

HP Overhead Display Unit

Warranty period: 12 months

1. HP warrants to you, the end-user customer, that HP hardware, accessories and supplies will be free from defects in materials and workmanship after the date of purchase, for the period specified above. If HP receives notice of such defects during the warranty period, HP will, at its option, either repair or replace products which prove to be defective. Replacement products may be either new or like-new.
2. HP does not warrant that the operation of HP products will be uninterrupted or error free. If HP is unable, within a reasonable time, to repair or replace any product to a condition as warranted, you will be entitled to a refund of the purchase price upon prompt return of the product.
4. HP products may contain remanufactured parts equivalent to new in performance or may have been subject to incidental use.
5. Warranty does not apply to defects resulting from (a) improper or inadequate maintenance or calibration, (b) software, interfacing, parts or supplies not supplied by HP, (c) unauthorized modification or misuse, (d) operation outside of the published environmental specifications for the product, or (e) improper site preparation or maintenance.
6. HP MAKES NO OTHER EXPRESS WARRANTY OR CONDITION WHETHER WRITTEN OR ORAL TO THE EXTENT

ALLOWED BY LOCAL LAW, ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY SET FORTH ABOVE. Some countries, states or provinces do not allow limitations on the duration of an implied warranty, so the above limitation or exclusion might not apply to you. This warranty gives you specific legal rights and you might also have other rights that vary from country to country, state to state, or province to province.

7. TO THE EXTENT ALLOWED BY LOCAL LAW, THE REMEDIES IN THIS WARRANTY STATEMENT ARE YOUR SOLE AND EXCLUSIVE REMEDIES. EXCEPT AS INDICATED ABOVE, IN NO EVENT WILL HP OR ITS SUPPLIERS BE LIABLE FOR LOSS OF DATA OR FOR DIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL (INCLUDING LOST PROFIT OR DATA), OR OTHER DAMAGE, WHETHER BASED IN CONTRACT, TORT, OR OTHERWISE. Some countries, States or provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

FOR CONSUMER TRANSACTIONS IN AUSTRALIA AND NEW ZEALAND: THE WARRANTY TERMS CONTAINED IN THIS STATEMENT, EXCEPT TO THE EXTENT LAWFULLY PERMITTED, DO NOT EXCLUDE, RESTRICT OR MODIFY AND ARE IN ADDITION TO THE MANDATORY STATUTORY RIGHTS APPLICABLE TO THE SALE OF THIS PRODUCT TO YOU.

Disclaimer

This manual and any examples contained herein are provided as is and are subject to change without notice. Except to the extent prohibited by law, Hewlett-Packard Company makes no express or implied warranty of any kind with regard to this manual and specifically disclaims the implied warranties and conditions of merchantability and fitness for a particular purpose and Hewlett-Packard Company shall not be liable for any errors or for incidental or consequential damage in connection with the furnishing, performance or use of this manual and the examples herein.

© Hewlett-Packard Company 1999. All rights reserved.

INFORMATION TO USER

Pursuant to Part 15.21 of the FCC Rules, any changes or modifications to this equipment, not expressly approved by Hewlett Packard company, may void the user's authority to operate this equipment.

Connections to Peripheral Devices

To maintain compliance with FCC Rules and Regulations, use only cable accessories provided.

REGULATORY INFORMATION USA

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This calculator generates, uses and can radiate radio frequency energy and may interfere with radio and television reception. In the unlikely event that this equipment does cause interference to radio or television reception, try the following:

- reorient or relocate the receiving antenna
- increase separation between the calculator and the receiver
- consult your dealer or an experienced radio/TV technician for help.

CANADA

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003.