


**HEWLETT-PACKARD**

**HP-41C**

**USERS'  
LIBRARY SOLUTIONS**

**Heating, Ventilating &  
Air Conditioning**



## **NOTICE**

The program material contained herein is supplied without representation or warranty of any kind. Hewlett-Packard Company therefore assumes no responsibility and shall have no liability, consequential or otherwise, of any kind arising from the use of this program material or any part thereof.

## INTRODUCTION

This HP-41C Solutions book was written to help you get the most from your calculator. The programs were chosen to provide useful calculations for many of the common problems encountered.

They will provide you with immediate capabilities in your everyday calculations and you will find them useful as guides to programming techniques for writing your own customized software. The comments on each program listing describe the approach used to reach the solution and help you follow the programmer's logic as you become an expert on your HP calculator.

### KEYING A PROGRAM INTO THE HP-41C

There are several things that you should keep in mind while you are keying in programs from the program listings provided in this book. The output from the HP 82143A printer provides a convenient way of listing and an easily understood method of keying in programs without showing every keystroke. This type of output is what appears in this handbook. Once you understand the procedure for keying programs from the printed listings, you will find this method simple and fast. Here is the procedure:

1. At the end of each program listing is a listing of status information required to properly execute that program. Included is the SIZE allocation required. Before you begin keying in the program, press **[XEQ] ALPHA SIZE [ALPHA]** and specify the allocation (three digits; e.g., 10 should be specified as 010).

Also included in the status information is the display format and status of flags important to the program. To ensure proper execution, check to see that the display status of the HP-41C is set as specified and check to see that all applicable flags are set or clear as specified.

2. Set the HP-41C to PRGM mode (press the **[PRGM]** key) and press **[ ] [GTO] [ ] [ ]** to prepare the calculator for the new program.
3. Begin keying in the program. Following is a list of hints that will help you when you key in your programs from the program listings in this handbook.
  - a. When you see " (quote marks) around a character or group of characters in the program listing, those characters are ALPHA. To key them in, simply press **[ALPHA]**, key in the characters, then press **[ALPHA]** again. So "SAMPLE" would be keyed in as **[ALPHA]"SAMPLE"[ALPHA]**.
  - b. The diamond in front of each LBL instruction is only a visual aid to help you locate labels in the program listings. When you key in a program, ignore the diamond.
  - c. The printer indication of divide sign is /. When you see / in the program listing, press **[+]**.
  - d. The printer indication of the multiply sign is  $\ddot{\times}$ . When you see  $\ddot{\times}$  in the program listing, press **[X]**.
  - e. The  $\vdash$  character in the program listing is an indication of the **[APPEND]** function. When you see  $\vdash$ , press **[ ] [APPEND]** in ALPHA mode (press **[ ]** and the K key).
  - f. All operations requiring register addresses accept those addresses in these forms:

nn (a two-digit number)

IND nn (INDIRECT: **[ ]**, followed by a two-digit number)

X, Y, Z, T, or L (a STACK address: **[ ]** followed by X, Y, Z, T, or L)

IND X, Y, Z, T or L (INDIRECT stack: **[ ] [ ]** followed by X, Y, Z, T, or L)

Indirect addresses are specified by pressing **[ ]** and then the indirect address. Stack addresses are specified by pressing **[ ]** followed by X, Y, Z, T, or L. Indirect stack addresses are specified by pressing **[ ] [ ]** and X, Y, Z, T, or L.

#### Printer Listing

```
01 ♦LBL "SAM  
PLE"  
02 "THIS IS  
A"  
03 "I-SAMPLE  
"  
04 AVIEW  
05 6  
06 ENTER↑  
07 -2  
08 /  
09 ABS  
10 STO IND  
L  
11 "R3="  
12 ARCL 03  
13 AVIEW  
14 RTN
```

#### Keystrokes

<b>[ ]</b> <b>[LBL]</b> <b>[ALPHA]</b> SAMPLE <b>[ALPHA]</b>	
<b>[ALPHA]</b> <b>THIS IS A</b> <b>[ALPHA]</b>	
<b>[ALPHA] [ ] [APPEND]</b> SAMPLE	
<b>[ ]</b> <b>AVIEW</b> <b>[ALPHA]</b>	
6	
<b>[ENTER]</b>	
2 <b>[CHS]</b>	
<b>[+]</b>	
<b>[XEQ] ALPHA ABS ALPHA</b>	
<b>[STO] [ ] [ ] L</b>	
<b>[ALPHA] R3= [ ] [ARCL] 03</b>	
<b>[ ]</b> <b>AVIEW</b>	
<b>[ALPHA]</b>	
<b>[ ]</b> <b>RTN</b>	

#### Display

```
01 LBLT SAMPLE  
02T THIS IS A  
03T I-SAMPLE  
04 AVIEW  
05 6  
06 ENTER ↑  
07 -2  
08 /  
09 ABS  
10 STO IND L  
11T R3=  
12 ARCL 03  
13 AVIEW  
14 RTN
```

## TABLE OF CONTENTS

1.	OVERALL HEAT TRANSFER COEFFICIENT .....	1
	Sums convective and conductive coefficients to obtain the overall heat transfer coefficient.	
2.	INSULATION BREAK EVEN ANALYSIS .....	6
	Given economic and engineering parameters, computes the years to break even on an insulation investment.	
* 3.	AIR FLOW IN CIRCULAT DUCTS .....	11
	Can be used to analyze existing ducts or size new ducts.	
4.	AIR DUCT CONVERSION .....	19
	Converts from round ducts to equivalent rectangular ducts or from rectangular ducts to equivalent round ducts.	
* 5.	EQUATIONS OF STATE .....	25
	Relates pressure, temperature, volume, and amount of a gas using either the ideal gas law or the Redlich- Kwong model of real gas behavior.	
* 6.	BLACK BODY THERMAL RADIATION .....	33
	Computes thermal radiation as a function of temperature and wavelength for black bodies.	
* 7.	PSYCHROMETRIC PROPERTIES .....	40
	Computes properties of moist air based on temperature, pressure and either wet bulb temperature, relative humidity, or vapor pressure.	
* 8.	HEAT EXCHANGERS .....	49
	Correlates heat transfer for counterflow, parallel flow, parallel-counterflow and crossflow heat exchangers.	
9.	DECIBEL ADDITION AND SUBTRACTION .....	65
	Adds and subtracts sound levels in decibels.	
10.	TEMPERATURE CONVERSIONS .....	69
	Converts interchangeably between Kelvin, Fahrenheit, Celsius, and Rankin.	

\* These programs require one memory module.

## OVERALL HEAT TRANSFER COEFFICIENTS

This program sums convective and conductive coefficients to obtain the overall heat transfer coefficient for walls.

Equations:

$$U = \frac{1}{R_0 + R_1 + R_2 + \dots + R_n + \frac{1}{h_0} + \frac{1}{h_1} + \frac{1}{h_2} + \dots + \frac{1}{h_n} + \frac{x}{k_0} + \frac{x}{k_1} + \frac{x}{k_2} + \dots + \frac{x}{k_n} + \frac{1}{C_0} + \frac{1}{C_1} + \frac{1}{C_2} + \dots + \frac{1}{C_n}}$$

where:

Q is the heat transfer

U is the overall heat transfer coefficient

$\Delta T$  is the temperature difference across the wall

R is the thermal resistance of a layer in the wall

h is the convective resistance at a surface of the wall

x is the thickness of a conductive layer

k is the thermal conductivity of a substance


C is the thermal conductance of a layer

Reference:

Threlkeld, James L.; Thermal Environmental Engineering; Prentice-Hall, Inc. 1970

Example:

What is the overall heat transfer coefficient for the wall below? What is the heat transfer for a 20°F temperature difference?



Layer	Coefficient	Symbol	Units
Inside Air	1.46	h	B/(hr) (ft <sup>2</sup> ) (°F)
Plaster	5	k	B/(hr) (ft <sup>2</sup> ) (°F/in)
Insulation	11	R	(hr) (ft <sup>2</sup> ) (°F)/BTU
Concrete	12	h	BTU/(hr) (ft <sup>2</sup> ) (°F/in)
Brick	36	C	BTU/(hr) (ft <sup>2</sup> ) (°F)
Outside Air	6	h	BTU/(hr) (ft <sup>2</sup> ) (°F)

Keystrokes:

[///] [FIX] 4  
[XEQ] [ALPHA] HEAT [ALPHA]  
1.46 [A]  
.5 [ENTER ↑] 5 [B]  
11 [D]  
5 [ENTER ↑] 12 [B]  
36 [C]  
6 [A]  
[R/S]  
20 [x]

Display:

H X↑K C R CL	
U=0.0807	
1.6134	(Btu/(ft <sup>2</sup> )(hr))

# User Instructions

# Program Listings

01♦LBL "HEA T"	Initialize program.	51	
02♦LBL E			
03 ADV			
04 SF 27			
05 CLST			
06♦LBL 01			
07 "H X↑K C R CL"			
08 PROMPT		60	
09 ADV			
10 "U="			
11 ARCL X	Output U.		
12 SF 21			
13 AVIEW			
14 GTO 01			
15♦LBL A			
16 "H"			
17 XEQ 00			
18 1/X		70	
19 GTO 02			
20♦LBL B	Add convective coefficient.		
21 "X="			
22 ARCL Y			
23 FS? 55			
24 PRA			
25 "K"			
26 XEQ 00			
27 /			
28 GTO 02			
29♦LBL C		80	
30 "C"	Add conductance.		
31 XEQ 00			
32 1/X			
33 GTO 02			
34♦LBL D			
35 "R"			
36 XEQ 00			
37♦LBL 02			
38 RCL Y			
39 X#0?		90	
40 1/X	Add resistance.		
41 +			
42 1/X			
43 GTO 01			
44♦LBL 00			
45 "T="			
46 ARCL X			
47 FS? 55			
48 PRA			
49 RTN		00	

# REGISTERS, STATUS, FLAGS, ASSIGNMENTS

DATA REGISTERS			STATUS				
00		50	SIZE	ANY	TOT. REG.	15	USER MODE
05		55	ENG	FIX	SCI	ON X	OFF
10		60	DEG	RAD	GRAD		
15		65	FLAGS				
20		70	#	INIT S/C	SET INDICATES	CLEAR INDICATES	
25		75					
30		80					
35		85					
ASSIGNMENTS							
40		90	FUNCTION	KEY	FUNCTION	KEY	
45		95					

## INSULATION BREAK EVEN ANALYSIS

This program calculates the number of years necessary for insulation to pay for itself based on heating costs. Inflation and the cost of money are accounted for.

Equations:

$$\text{YEARS} = \frac{-\ln \left( 1 - \frac{\$/\text{FT}^2 (\%INT - \%INF)}{\text{Yearly Savings}} \right)}{\ln \left( 1 + \frac{\%INT - \%INF}{1 + \%INF} \right)}$$

$$\text{YEARLY SAVINGS} = \left( U - \frac{1}{(1/U + R)} \right) (\text{DEGDY}) (24) (\$/\text{BTU})$$

where:

**YEARS** is the number of years before insulation pays for itself.

**\$/FT<sup>2</sup>** is the cost of the insulation on a square foot basis.

**%INT** is the current lending rate to obtain insulation.

**%INF** is the expected inflation rate for the heat source being considered.

**U** is the overall heat transfer coefficient for the surface being considered with no insulation installed, Btu/(hr)(ft<sup>2</sup>)(°F).

**R** is the thermal resistance of the insulating material, (hr)(ft<sup>2</sup>)(°F)/BTU.

**DEGDY** is the number of degree days for the area being considered.

See the ASHRAE GUIDE AND DATA BOOK for degree day information.

**\$/BTU** is the current cost of heat per Btu.

Example:

A home in Seattle, Washington, (5145 degree days per year) is to have walls insulated with either R11 or R19 insulation costing 0.25 or 0.40 dollars per square foot respectively. The heat transfer coefficient for the un-insulated walls is 0.28 Btu/(hr)(ft<sup>2</sup>)(°F). Natural gas at a cost of  $3.66 \times 10^{-6}$  \$/Btu is the heat source. Financing is available at 11% and energy is expected to inflate at 15% per year. How many years will it take for the two insulation choices to pay for themselves?

Keystrokes:	(SIZE > 009)	Display:
[//]	[FIX] 2	
[XEQ]	[ALPHA] INSUL [ALPHA]	U=?
.28	[R/S]	\$/BTU=?
3.66	[EEX] [CHS] 6 [R/S]	% INT=?
11	[R/S]	% INF=?
15	[R/S]	DEGDY=?
5145	[R/S]	R=?
11	[R/S]	\$/FT2=?
.25	[R/S]	YEARS=2.81
[R/S]*		R=?
19	[R/S]	\$/FT2
.4	[R/S]	YEARS=3.95
[R/S]*		R=?

\*Press [R/S] if you are not using a printer.

# User Instructions

# Program Listings

<pre> 01♦LBL "INS UL" 02 ADV 03 0 04 STO 00 05 "U" 06 XEQ "IN" 07 "\$/BTU" 08 XEQ "IN" 09 "%INT" 10 XEQ "IN" 11 "%INF" 12 XEQ "IN" 13 "DEGDY" 14 XEQ "IN" 15♦LBL 01 16 5 17 STO 00 18 "R" 19 XEQ "IN" 20 "\$/FT2" 21 XEQ "IN" 22 RCL 01 23 RCL 01 24 1/X 25 RCL 06 26 + 27 1/X 28 - 29 RCL 05 30 * 31 RCL 02 32 * 33 24 34 * 35 RCL 03 36 RCL 04 37 - 38 X=0? 39 GTO 00 40 100 41 / 42 STO 08 43 / 44 RCL 07 45 X&lt;&gt;Y 46 / 47 CHS 48 LN1+X 49 CHS </pre>	<p>Input values.</p>	<pre> 50 RCL 08 51 RCL 04 52 100 53 / 54 1 55 + 56 / 57 LN1+X 58 / 59♦LBL 03 60 ADV 61 "YEARS" 62 XEQ "0" 63 ADV 64 GTO 01 65♦LBL 00 66 RDN 67 RCL 07 68 RCL 04 69 % 70 + 71 X&lt;&gt;Y 72 / 73 GTO 03 74♦LBL "IN" 75 CF 22 76 1 77 ST+ 00 78 RCL IND 00 79 "F=" 80 ASTO Y 81 "F?" 82 CF 21 83 AVIEW 84 SF 21 85 CLA 86 ARCL Y 87 STOP 88 STO IND 00 89 FS? 22 90 FC? 55 91 RTN 92 ARCL X 93 PRA 94 RTN 95♦LBL "0" 96 "F=" 97 ARCL X 98 AVIEW </pre>	<p>Output years.</p>
	<p>Calculate savings.</p>		<p>Special case where inflation equals interest.</p>
	<p>Calculate years.</p>		<p>Input subroutine.</p>
			<p>Output subroutine</p>

# REGISTERS, STATUS, FLAGS, ASSIGNMENTS

DATA REGISTERS				STATUS				
00	DATA PRINTER	50		SIZE	009	TOT. REG.	37	USER MODE
	U			ENG		FIX		ON OFF
	\$/BTU			DEG		RAD		GRAD
	%INT							
05	%INF			FLAGS				
	DEGDY	55		INIT	# S/C	SET INDICATES	CLEAR INDICATES	
	R							
	\$/FT2				<th></th> <th></th> <td></td>			
10	(%INT-%INF)/100				<th></th> <th></th> <td></td>			
					<th></th> <th></th> <td></td>			
					<th></th> <th></th> <td></td>			
					<th></th> <th></th> <td></td>			
15					<th></th> <th></th> <td></td>			
					<th></th> <th></th> <td></td>			
					<th></th> <th></th> <td></td>			
					<th></th> <th></th> <td></td>			
20					<th></th> <th></th> <td></td>			
					<th></th> <th></th> <td></td>			
					<th></th> <th></th> <td></td>			
					<th></th> <th></th> <td></td>			
25					<th></th> <th></th> <td></td>			
					<th></th> <th></th> <td></td>			
					<th></th> <th></th> <td></td>			
					<th></th> <th></th> <td></td>			
30					<th></th> <th></th> <td></td>			
					<th></th> <th></th> <td></td>			
					<th></th> <th></th> <td></td>			
					<th></th> <th></th> <td></td>			
35					<th></th> <th></th> <td></td>			
					<th></th> <th></th> <td></td>			
					<th></th> <th></th> <td></td>			
					<th></th> <th></th> <td></td>			
				ASSIGNMENTS				
40				FUNCTION	KEY	FUNCTION	KEY	
45					<th></th> <th></th> <td></td>			
					<th></th> <th></th> <td></td>			
					<th></th> <th></th> <td></td>			
					<th></th> <th></th> <td></td>			

## AIR FLOW IN CIRCULAR DUCTS

(Requires one memory module)

This program can be used to compute the pressure difference, velocity or volumetric flow rate for air in circular, metal, HVAC ducts.

**Equations:**

$$v^2 = \frac{dP/\rho}{2 \left( f \frac{L}{D} + \frac{K_T}{4} \right)}$$

For laminar flow ( $Re < 2300$ )

$$f = 16/Re$$

For turbulent flow ( $Re > 2300$ )

$$\frac{1}{\sqrt{f}} = 1.737 \ln \frac{D}{\epsilon} + 2.28 - 1.737 \ln \left( 4.67 \frac{D}{\epsilon Re \sqrt{f}} + 1 \right)$$

is solved by Newton's method.

$$\frac{1}{\sqrt{f}_0} = 1.737 \ln \frac{D}{\epsilon} + 2.28$$

is used as an initial guess in the iteration.

$$\mu = 1.101 \times 10^{-6} (T)^{1.5} / (T+200) \text{ (N}\cdot\text{s/m}^2\text{)}$$

$$\rho = 1.201 \left( \frac{P}{29.92} \right) \left( \frac{530}{T} \right) \text{ (kg/m}^3\text{)}$$

where:

$Re$  is the Reynolds number, defined as  $\rho D v / \mu$ ;

$D$  is the pipe diameter;

$\epsilon$  is the dimension of irregularities in the conduit surface

$f$  is the Fanning friction factor for conduit flow;

$dP$  is the pressure difference along the conduit;

$\rho$  is the density of the fluid;

$\mu$  is the viscosity of the fluid;

$L$  is the conduit length;

$v$  is the average fluid velocity;  
 $K_T$  is the total of the applicable fitting coefficients in table 1;  
 $T$  is the air temperature in degrees ranking.  
 $P$  is the air pressure in inches of mercury.

Table 1  
Fitting Coefficients

Fitting	K
90° elbow	0.4-0.9
Standard 45° elbow	0.35-0.42
Tee, through side outlet	1.5
Tee, straight through	.4
180° bend	1.6
Entrance to circular pipe	0.25-0.50
Sudden expansion	$(1 - A_{up}/A_{dn})^2*$
Acceleration from $v = 0$ to $v = v_{\text{entrance}}$	1.0

#### Remarks:

For rectangular ducts, use the duct conversion program of this solution book.

This program assumes incompressible flow, thus accuracy will degenerate as velocity increases above 12,000 feet per minute.

No algorithm gives reliable outputs for transition flow ( $2300 < Re < 4000$ ). If this condition is encountered, the program will halt displaying "TRANSITION". You may press [R/S] and the program will continue to an answer but the answer may have little or no relation to reality.

#### References:

Welty, Wicks, Wilson; *Fundamentals of Momentum, Heat and Mass Transfer*, John Wiley and Sons, Inc., 1969.

Baumeister, Mark's Standard Handbook For Mechanical Engineers, Seventh Edition, McGraw-Hill, 1967, p. 12-136.

\* $A_{up}$  is the upstream area and  $A_{dn}$  is the downstream area.

Example 1:

What pressure drop will force 6000 cubic feet per minute of 70°F air through 100 feet of 20 inch straight conduit. The atmospheric pressure is 29 inches of mercury.

Keystrokes: (SIZE > 018)

Display:

[//] [FIX]

[XEQ] [ALPHA] AIRDUCT [ALPHA]

T,F=?

70 [R/S]

INHG=?

29 [R/S]

L,FT=?

100 [R/S]

$\Sigma K=?$

0 [R/S]

D,IN=?

20 [R/S]

SELECT KEY: dP V Q

[C]

Q,CFM=?

6000 [R/S]

INH20=0.41

[R/S]\*

V,FPM=2750.73

[R/S]\*

D,IN=?

\* Press [R/S] if you are not using a printer.

Example 2:

The flow rate in Example 1 is to be increased to 15,000 cubic feet per minute by increasing the conduit diameter. What diameter is necessary?

Keystrokes:

Display:

First run Example 1. You should have the "D,IN=?" prompt in the Display. Guess a diameter of 30 inches.

30 [R/S]

SELECT KEY: dP V Q

[A]

INH20=?

[R/S]

V,FPM=3,551.69

[R/S]\*

Q,CFM=17,430.93

[R/S]\*

D,IN=?

The 30 inch duct will be adequate but try a 28 inch duct.

28 [R/S]

SELECT KEY: dP V Q

[A] [R/S]

V,FPM=3,401.48

[R/S]\*

Q,CRM=14,542.07

[R/S]\*

D,IN=?

Since duct is available only in even size use 30 inch duct.

# User Instructions

SIZE: 018

STEP	INSTRUCTIONS	INPUT	FUNCTION	DISPLAY
1.	Load program			
2.	Initialize program		[XEQ] AIRDUCT	T,F=?
3.	Key in air temperature in degrees			
	Fahrenheit.	T	[R/S]	INHG=?
4.	Key in average atmospheric pressure in			
	inches of mercury.	P <sub>atm</sub>	[R/S]	L,FT=?
5.	Key in length of duct in feet	L	[R/S]	ΣK
6.	Key in sum of fitting coefficients from			
	Table 1.	ΣK	[R/S]	D,IN=?
7.	Key in duct diameter in inches	D	[R/S]	SELECT KEY:
				dP V Q
8.	If you know pressure difference, press			
	[A]		[A]	INH20=?
	If you know velocity, press [B]		[B]	V,FPM=?
	If you know volumetric flow rate press			
	[C]		[C]	Q, CFM=?
9.	Key in known selected in step 8 and			
	calculate remaining unknowns.	known	[R/S]	UNKNOWN <sub>1</sub>
			[R/S]*	UNKNOWN <sub>2</sub>
			[R/S]*	D,IN=?
10.	For a new diameter, or step 8 input, go to			
	step 7. For a new case go to step 2. In			
	either case, key in only values which			
	change.			
*	Press [R/S] if you are not using a printer.			

# Program Listings

01♦LBL "AIR DUCT" 02 ADV 03 0 04 STO 00 05 "T,F" 06 XEQ "IN" 07 "INHG" 08 XEQ "IN" 09 RCL 01 10 460 11 + 12 STO 10 13 RCL X 14 1.5 15 Y↑X 16 1.101 E- 6 17 * 18 RCL Y 19 200 20 + 21 / 22 STO 16 23 RCL 02 24 29.92 25 / 26 530 27 RCL 10 28 / 29 * 30 1.201 31 * 32 STO 17 33 762 E-7 34 STO 03 35 3 36 STO 00 37 "L,FT" 38 .3048 39 ST/ 04 40 XEQ "IN" 41 .3048 42 ST* 04 43 1 44 ST+ 00 45 "ΣK" 46 XEQ "IN" 47♦LBL 15 48 4 49 STO 00	Calculate and store viscosity, density and surface irregularities.	50 "D, IN" 51 .0254 52 ST/ 05 53 XEQ "IN" 54 .0254 55 ST* 05 56 SF 27 57 "SELECT KEY: 58 CF 21 59 AVIEW 60 SF 21 61 PSE 62♦LBL 01 63 "dP V Q" 64 PROMPT 65 GTO 01 66♦LBL A 67 6 68 STO 00 69 248.8 70 ST/ 07 71 "INH20" 72 XEQ "IN" 73 248.8 74 ST* 07 75 SF 03 76 XEQ 09 77♦LBL 03 78 RND 79 STO 15 80 XEQ 08 81 RND 82 RCL 15 83 X<>Y 84 X=Y? 85 GTO 03 86 XEQ "Re" 87 "V, FPM" 88 RCL 08 89 196.9 90 * 91 GTO 00 92♦LBL C 93 ? 94 STO 00 95 "Q, CFM" 96 XEQ 11 97 * 98 * 99 STO 08	Input D. Define keys. Input pressure difference. Compute velocity. Input flow rate.
	Input L.		
	Input sum of fitting coefficients.		

# Program Listings

100 XEQ "IN"		151 STO 07	
101 XEQ 11		152 RTN	
102 *		153♦LBL 09	
103 /		154 ADV	
104 STO 08		155 RCL 16	
105 XEQ 10	Calculate pressure drop.	156 RCL 17	
106 XEQ "Re"		157 /	
107 "INH20"		158 STO 09	Guess 1/ $\sqrt{f}$ .
108 RCL 07		159 RCL 05	
109 248.8		160 RCL 03	
110 /		161 /	
111 XEQ "0"		162 STO 10	
112 "V, FPM"		163 LN	
113 RCL 08		164 1.737	
114 196.9		165 STO 11	
115 *		166 *	
116 XEQ "0"		167 2.28	
117 ADV		168 +	
118 GTO 15		169 STO 12	
119♦LBL B	Input velocity.	170 STO 13	
120 7		171 FS? 03	
121 STO 00		172 GTO 07	
122 "V, FPM"		173♦LBL 08	Special case for low velocity flow.
123 5.08 E-3		174 16	
124 ST/ 08		175 RCL 08	
125 XEQ "IN"		176 RCL 05	
126 5.08 E-3		177 *	
127 ST* 08		178 RCL 09	
128 XEQ 10	Calculate pressure drop.	179 /	
129 XEQ "Re"		180 STO 14	
130 "INH20"		181 2300	
131 RCL 07		182 X<=Y?	
132 248.8		183 GTO 02	
133 /		184 RDN	
134♦LBL 00		185 /	
135 XEQ "0"		186 SQRT	
136 "Q, CFM"		187 1/X	
137 XEQ 11		188 STO 13	
138 *		189 GTO 07	
139 *		190♦LBL 02	
140 XEQ "0"		191 RCL 12	
141 ADV		192 RCL 13	
142 GTO 15		193 -	
143♦LBL 10		194 4.67	Turbulent flow friction factor.
144 CF 03		195 RCL 10	
145 XEQ 09		196 *	
146 RCL 08		197 RCL 14	
147 X↑2		198 /	
148 *		199 RCL 13	
149 RCL 17		200 *	
150 *		201 1	

# Program Listings

202 +		252 2300	
203 STO 00		253 RCL 14	
204 LN		254 X<=Y?	
205 RCL 11		255 RTN	
206 *		256 4000	
207 -		257 X>Y?	
208 RCL 00		258 PROMPT	
209 1/X		259 RTN	
210 CHS		260♦LBL 11	
211 1		261 RCL 08	
212 +		262 RCL 05	
213 RCL 11		263 X↑2	
214 *		264 PI	
215 RCL 13		265 *	
216 /		266 4	
217 1		267 /	
218 +		268 2119	
219 /		269 RTN	
220 ST+ 13		270♦LBL "IN"	
221 RCL 13		271 CF 22	
222 /		272 1	
223 ABS		273 ST+ 00	
224 1 E-3		274 RCL IND	
225 X<=Y?		00	
226 GTO 02		275 "T="	
227♦LBL 07	Compute velocity.	276 ASTO Y	
228 RCL 13		277 "T?"	
229 1/X		278 CF 21	
230 X↑2		279 AVIEW	
231 RCL 04		280 SF 21	
232 *		281 CLA	
233 RCL 05		282 ARCL Y	
234 /		283 STOP	
235 RCL 06		284 STO IND	
236 4		00	
237 /		285 FS? 22	
238 +		286 FC? 55	
239 ST+ X		287 RTN	
240 RCL 07		288 ARCL X	
241 RCL 17		289 PRA	
242 /		290 RTN	
243 X<>Y		291♦LBL "O"	
244 FC? 03		292 "T="	
245 RTN		293 ARCL X	
246 /		294 AVIEW	
247 SQRT			
248 STO 08			
249 RTN			
250♦LBL "Re"	Check for		
251 "TRANSIT	transition.		
ION"		00	

## **REGISTERS, STATUS, FLAGS, ASSIGNMENTS**

## AIR DUCT CONVERSION

This program converts a round, metal, HVAC, air duct to an equivalent rectangular air duct. The inverse conversion is also provided.

Equations:

$$D = \frac{1.3 (ab)^{0.625}}{(a + b)^{0.25}}$$

where:

a is the depth (or width) of a rectangular duct in inches.

b is the width (or depth) of a rectangular duct in inches.

D is the approximate diameter for an equivalent round duct.

Reference:

Wolfe, James M.; Air Duct Conversion; HP-67/97 Users' Library Program 03046D.  
 Baumeister, Mark's Standard Handbook for Mechanical Engineers, Seventh Edition,  
 McGraw Hill, 1967, p. 12-137

Example 1:

A duct measuring 15 inches by 8 inches is to be replaced with a round duct.  
 What diameter duct is required?

Keystrokes: (SIZE 003)

Display:

[///] [FIX] 2

a=?

[XEQ] [ALPHA] REC-RND [ALPHA]

b=?

15 [R/S]

D=12.00

8 [R/S]

a=?

[R/S]\*

**Example 2:**

A duct sizing program computes a diameter of 30 inches for a duct. Clearances only allow 24 inches in the vertical direction. What horizontal dimension is necessary for a rectangular duct?

Keystrokes: (SIZE > 003)

Display:

[///] [FIX] 2

D=?

[XEQ] [ALPHA] RND-REC [ALPHA]

a=?

30 [R/S]

b=32

24 [R/S]

D=?

[R/S]\*

\*Press [R/S] if you are not using a printer.

# User Instructions

STEP	INSTRUCTIONS	INPUT	FUNCTION	DISPLAY
1.	Load program.			
2.	For circular to rectangular conversions,			
	go to step 3b.			
3.	Initialize for rectangular to circular			
	conversion.		[ XEQ ] REC-RND	a=?
4.	Key in depth.	a	[ R/S ]	b=?
5.	Key in width and calculate diameter.	b	[ R/S ]	D=
			[ R/S ]*	a=?
6.	For a new case go to step 4a. Key in only values which change. For the inverse conversion, go to step 3b.			
3b.	Initialize for circular to rectangular conversion		[ XEQ ] RND-REC	D=?
4b.	Key in diameter	D	[ R/S ]	a=?
5b.	Key in the depth or width and calculate the other dimension	a	[ R/S ]	b=
			[ R/S ]*	D=?
6b.	For a new case, go to step 4b. Key in only values which change. For the inverse conversion, go to step 3.			
*	Press [ R/S ] if you are not using a printer.			

# Program Listings

<pre> 01♦LBL "REC -RND" 02♦LBL 01 03 ADV 04 0 05 STO 00 06 "a" 07 XEQ "IN" 08 "b" 09 XEQ "IN" 10 ADV 11 RCL 01 12 * 13 .625 14 Y↑X 15 RCL 01 16 RCL 02 17 + 18 SQRT 19 SQRT 20 / 21 1.3 22 * 23 "D" 24 .5 25 + 26 INT 27 XEQ "O" 28 GTO 01 29♦LBL "RND -REC" 30♦LBL 02 31 ADV 32 0 33 STO 00 34 "D" 35 XEQ "IN" 36 "a" 37 XEQ "IN" 38 RCL 02 39 RCL 01 40 * 41 RCL 02 42 ST+ X 43 RCL 01 44 - 45 / 46 STO 00 47 ADV 48♦LBL 03 </pre>	Input a and b.	Calculate D.	Input D and a.	Guess b based on wetted perimeter.	49 RCL 00 50 RCL 02 51 * 52 .625 53 Y↑X 54 1.3 55 * 56 RCL 00 57 RCL 02 58 + 59 SQRT 60 SQRT 61 RCL 01 62 * 63 - 64 RCL 00 65 -.375 66 Y↑X 67 RCL 02 68 .625 69 Y↑X 70 * 71 .8125 72 * 73 RCL 02 74 RCL 00 75 + 76 -.75 77 Y↑X 78 RCL 01 79 * 80 4 81 / 82 - 83 / 84 ST- 00 85 RCL 00 86 / 87 ABS 88 .25 89 X<=Y? 90 GTO 03 91 RCL 00 92 .5 93 + 94 INT 95 "b" 96 XEQ "O" 97 GTO 02 98♦LBL "IN" 99 CF 22	Iterate by Newton's method to find b.	Output b.	Input subroutine.
--	----------------	--------------	----------------	------------------------------------	--	---------------------------------------	-----------	-------------------

# Program Listings

100 1		51	
101 ST+ 00			
102 RCL IND			
00			
103 "T= "			
104 ASTO Y			
105 "T? "			
106 CF 21			
107 AVIEW			
108 SF 21		60	
109 CLA			
110 ARCL Y			
111 STOP			
112 STO IND			
00			
113 FS? 22			
114 FC? 55			
115 RTN			
116 ARCL X			
117 PRA		70	
118 RTN			
119♦LBL "0"	Output subroutine		
120 "T= "			
121 ARCL X			
122 AVIEW			
30		80	
40		90	
50		00	

# REGISTERS, STATUS, FLAGS, ASSIGNMENTS

DATA REGISTERS			STATUS					
00	Data pointer/b	50	SIZE	003	TOT. REG.	35		
	a/D		ENG		SCI	USER MODE		
	b/a		DEG		RAD	ON OFF		
05		55	FLAGS					
			#	INIT S/C	SET INDICATES	CLEAR INDICATES		
10		60						
15		65						
20		70						
25		75						
30		80						
35		85						
40		90	ASSIGNMENTS					
			FUNCTION	KEY	FUNCTION	KEY		
45		95						

## EQUATIONS OF STATE

(Requires one memory module)

This program provides both ideal gas and Redlich-Kwong equations of state. Given four of the five state variables, the fifth is calculated. For the Redlich-Kwong solution, the critical pressure and temperature of the gas must be known. They are not needed for ideal gas solutions.

Values of the Universal Gas Constants

Value of R	Units of R	Units of P	Units of V	Units of T
8.314	N-m/g mole-K	N/m <sup>2</sup>	m <sup>3</sup> /g mole	K
83.14	cm <sup>3</sup> -bar/g mole-K	bar	cm <sup>3</sup> /g mole	K
82.05	cm <sup>3</sup> -atm/g mole-K	atm	cm <sup>3</sup> /g mole	K
0.7302	atm-ft <sup>3</sup> /lb mole-°R	atm	ft <sup>3</sup> /lb mole	°R
10.73	psi-ft <sup>3</sup> /lb mole-°R	psi	ft <sup>3</sup> /lb mole	°R
1545	psf-ft <sup>3</sup> /lb mole-°R	psf	ft <sup>3</sup> /lb mole	°R

Critical Temperatures and Pressures

Substance	T <sub>c</sub> , K	T <sub>c</sub> , °R	P <sub>c</sub> , ATM
Ammonia	405.6	730.1	112.5
Argon	151	272	48.0
Carbon dioxide	304.2	547.6	72.9
Carbon monoxide	133	239	34.5
Chlorine	417	751	76.1
Helium	5.3	9.5	2.26
Hydrogen	33.3	59.9	12.8
Nitrogen	126.2	227.2	33.5
Oxygen	154.8	278.6	50.1
Water	647.3	1165.1	218.2
Dichlorodifluoromethane	384.7	692.5	39.6
Dichlorofluoromethane	451.7	813.1	51.0
Ethane	305.5	549.9	48.2
Ethanol	516.3	929.3	63
Methanol	513.2	923.8	78.5
n-Butane	425.2	765.4	37.5
n-Haxane	507.9	914.2	29.9
n-Pentane	469.5	845.1	33.3
n-Octane	568.6	1023.5	24.6
Trichlorofluoromethane	471.2	848.1	43.2

**Equations:**

**Ideal gas:**

$$PV = nRT$$

**Redlich-Kwong:**

$$P = \frac{nRT}{(V - b)} - \frac{a}{T^{1/2} V (V + b)}$$

$$a = 4.934 b nRT_c^{1.5}$$

$$b = 0.0867 \frac{nRT_c}{P_c}$$

**where:**

P is the absolute pressure;

V is the volume;

n is the number of moles present;

R is the universal gas constant;

T is the absolute temperature;

$T_c$  is the critical temperature;

$P_c$  is the critical pressure.

**Remarks:**

P, V, n and T must have units compatible with R.

At low temperatures or high pressures, the ideal gas law does not represent the behavior of real gases.

No equation of state is valid for all substances or over an infinite range of conditions. The Redlich-Kwong equation gives moderate to good accuracy for a variety of substances over a wide range of conditions. Results should be used with caution and tempered by experience.

Solutions for V, n, R and T, using the Redlich-Kwong equation, require an iterative technique. Newton's method is employed using the ideal gas law to generate the initial guess. Iteration time is generally a function of the amount of deviation from ideal gas behavior. For extreme cases, the routine may fail to converge entirely, resulting in "DATA ERROR".

**Example 1:**

0.63 g moles of air are enclosed in a 25,000 cm<sup>3</sup> space at 1200 K. What is the pressure in bars? Assume ideal gas behavior.

**Keystrokes:**

[XEQ] [ALPHA] SIZE [ALPHA] 015	
[XEQ] [ALPHA] ID [ALPHA]	P?
0 [R/S]	V?
25000 [R/S]	N?
0.63 [R/S]	R?
83.14 [R/S]	T?
1200 [R/S]	P=2.51

**Display:****Example 2:**

The specific volume of a gas in a container is 800 cm<sup>3</sup>/g mole. The temperature will reach 400 K. What will the pressure be, according to the Redlich-Kwong relation?

$$\begin{aligned}P_c &= 48.2 \text{ atm} \\T_c &= 305.5 \text{ K} \\R &= 82.05 \text{ cm}^3 - \text{atm/g mole-K}\end{aligned}$$

**Keystrokes:**

[XEQ] [ALPHA] RK [ALPHA]	TC?
305.5 [R/S]	PC?
48.2 [R/S]	P?
0 [R/S]	V?
800 [R/S]	N?
1 [R/S]	R?
82.05 [R/S]	T?
400 [R/S]	P=36.29

**Display:**

# User Instructions

SIZE: 015

# Program Listings

<pre> 01♦LBL "ID" 02 0 03 SF 00 04 GTO 00 05♦LBL "RK" 06 1 07 CF 00 08 "TC?" 09 PROMPT 10 STO 13 11 "PC?" 12 PROMPT 13 STO 14 14♦LBL 00 15 SF 02 16 CF 01 17 FIX 2 18 "P?" 19 PROMPT 20 5 21 XEQ 00 22 "V?" 23 PROMPT 24 6 25 XEQ 00 26 "N?" 27 PROMPT 28 7 29 XEQ 00 30 "R?" 31 PROMPT 32 8 33 XEQ 00 34 "T?" 35 PROMPT 36 CF 02 37 9 38♦LBL 00 39 CF 01 40 STO 01 41 RDH 42 STO IND 01 43 X#0? 44 GTO 01 45 RT↑ 46 STO 10 47 1 48 STO IND 01 49♦LBL 01 </pre>	Initialization	<pre> 50 FS? 02 51 RTH 52 GTO IND 10 53♦LBL 05 54 "P=" 55 GTO 00 56♦LBL 06 57 "V=" 58♦LBL 00 59 RCL 07 60 RCL 08 61 * 62 RCL 09 63 * 64 RCL 05 65 RCL 06 66 * 67 / 68 STO IND 10 69 GTO 00 70♦LBL 07 71 SF 01 72 "N=" 73 GTO 01 74♦LBL 08 75 SF 01 76 "R=" 77 GTO 01 78♦LBL 09 79 "T=" 80 SF 01 81♦LBL 01 82 RCL 05 83 RCL 06 84 * 85 RCL 07 86 / 87 RCL 08 88 / 89 RCL 09 90 / 91 STO IND 10 92♦LBL 00 93 FS? 00 94 GTO 10 95 XEQ 01 96 GTO 00 97♦LBL 02 </pre>	Calculate unknown
---	----------------	--	-------------------

# Program Listings

98 FS? 01	-----	145 *	
99 XEQ 01		146 X↑2	
100♦LBL 00	If ideal, display	147 /	
101 RCL 00		148 RCL 00	
102 RCL 09		149 RCL 09	
103 *		150 *	
104 RCL 06		151 RCL 04	
105 RCL 12	Calculate using Redlich-Kwong equations	152 X↑2	
106 -		153 /	
107 STO 04		154 -	
108 /		155 RTN	
109 RCL 11		156♦LBL 09	
110 RCL 09		157 RCL 00	$\frac{\partial P}{\partial T}$
111 SQRT		158 RCL 04	
112 /		159 /	
113 STO 02		160 RCL 02	
114 RCL 06		161 2	
115 /		162 /	
116 LASTX		163 RCL 09	
117 RCL 12		164 /	
118 +		165 RCL 06	
119 STO 03		166 /	
120 /		167 RCL 03	
121 -		168 /	
122 RCL 05		169 +	
123 -		170 RTN	
124 XEQ IND		171♦LBL 07	
10		172♦LBL 08	$\frac{\partial P}{\partial n}$ or $\frac{\partial P}{\partial R}$
125 /		173 RCL 09	
126 ST- IND		174 RCL 06	
10		175 *	
127 RCL IND		176 RCL 04	
10		177 X↑2	
128 /		178 /	
129 ABS		179 RCL 06	
130 1 E-4		180 ENTER↑	
131 X<=Y?		181 +	
132 GTO 02		182 RCL 12	
133 RCL IND		183 +	
10		184 RCL 00	
134 GTO 10		185 /	
135♦LBL 06		186 RCL 06	
136 RCL 06		187 /	
137 ENTER↑		188 RCL 03	
138 +	$\frac{\partial P}{\partial V}$	189 X↑2	
139 RCL 12		190 /	
140 +		191 RCL 02	
141 RCL 02		192 *	
142 *		193 -	
143 RCL 03		194 RCL 00	
144 RCL 06		195 *	

# Program Listings

196 RCL IND		51	
197 /			
198 RTN			
199+LBL 05			
200 LASTX			
201 +			
202 STO 05			
203 GTO 10			
204+LBL 01	Calculate a, b	60	
205 RCL 07			
206 RCL 08			
207 *			
208 STO 00			
209 .0867			
210 RCL 14			
211 /			
212 X<>Y			
213 RCL 13			
214 *		70	
215 *			
216 STO 12			
217 LASTX			
218 *			
219 RCL 13			
220 SQRT			
221 *			
222 4.934			
223 *			
224 STO 11			
225 RTN		80	
226+LBL 10	Display		
227 ARCL X			
228 AVIEW			
229 STOP			
230 .END.			
40		90	
50		00	

# REGISTERS, STATUS, FLAGS, ASSIGNMENTS

DATA REGISTERS			STATUS		
NR	NAME	DECIMAL	SIZE 015 TOT. REG. 61 USER MODE		
			ENG	FIX 2 SCI	ON OFF X
			DEG	RAD GRAD	
00	NR	50			
	temp storage index				
	a/T <sup>1/2</sup>				
	(V + b)				
	(V - b)				
05	P	55			
	V				
	n		00	Ideal	Redlich-Kwong
	f		01	Calc a, b	
	T		02	Inputting data	Calculate
10	control	60			
	a				
	b				
	T <sub>c</sub>				
	P <sub>c</sub>				
15		65			
20		70			
25		75			
30		80			
35		85			
ASSIGNMENTS					
40		90	FUNCTION	KEY	FUNCTION
					KEY
45		95			

## BLACK BODY THERMAL RADIATION

(Requires one memory module)

Bodies with finite temperatures emit thermal radiation. The higher the absolute temperature, the more thermal radiation emitted. Bodies which emit the maximum possible amount of energy at every wavelength for a specified temperature are said to be black bodies. While black bodies do not actually exist in nature, many surfaces may be assumed to be black for engineering considerations.




Figure 1.

### Notes:

A half minute or more may be required to obtain  $E_b(0-\lambda)$  or  $E_b(\lambda_1-\lambda_2)$  since the integration is numerical.

Sources differ on values for constants. This could yield small discrepancies between published tables and program outputs.

Figure 1 is a representation of black body thermal emission as a function of wavelength. Note that as temperature increases, the area under the curves (total emissive power  $E_b(0-\infty)$ ) increases. Also note that the wavelength of maximum emissive power  $\lambda_{\max}$  shifts to the left as temperature increases.

This program calculates the wavelength of maximum emissive power for a given temperature, the temperature for which a given wavelength would be the wavelength of maximum emissive power, the total emissive power over all wavelengths, the emissive power at a particular wavelength, the emissive power from zero to a specified wavelength, and the emissive power between specified wavelengths.

Equations:

$$\lambda_{\max} T_{\lambda_{\max}} = c_3$$

$$E_{b(0-\infty)} = \sigma T^4$$

$$E_{b\lambda} = \frac{2\pi c_1}{\lambda^5 (e^{c_2/\lambda T} - 1)}$$

$$E_{b(0-\lambda)} = \int_0^\lambda E_{b\lambda} d\lambda$$

$$= 2\pi c_1 \sum_{k=1}^{\infty} -T/k c_2 e^{-\frac{k c_2}{T \lambda}} \left[ \left(\frac{1}{\lambda}\right)^3 + \frac{3T}{\lambda^2 k c_2} \right. \\ \left. + \frac{6}{\lambda} \left(\frac{T}{k c_2}\right)^2 + 6 \left(\frac{T}{k c_2}\right)^3 \right]$$

$$E_{b(\lambda_1 - \lambda_2)} = E_{b(0-\lambda_2)} - E_{b(0-\lambda_1)}$$

where:

$\lambda_{\max}$  is the wavelength of maximum emissivity in microns;

T is the absolute temperature in °R or K;

$E_{b(0-\infty)}$  is the total emissive power in Btu/hr-ft<sup>2</sup> or Watts/cm<sup>2</sup>;

$E_{b\lambda}$  is the emissive power at  $\lambda$  in Btu/hr-ft<sup>2</sup>-μm or Watts/cm<sup>2</sup>-μm;

$E_{b(0-\lambda)}$  is the emissive power for wavelengths less than  $\lambda$  in Btu/hr-ft<sup>2</sup> or Watts/cm<sup>2</sup>;

$E_{b(\lambda_1 - \lambda_2)}$  is the emissive power for wavelengths between  $\lambda_1$  and  $\lambda_2$  in Btu/hr-ft<sup>2</sup> or Watts/cm<sup>2</sup>.

$$c_1 = 1.8887982 \times 10^7 \text{ Btu-μm}^4 / \text{hr-ft}^2 \\ = 5.9544 \times 10^3 \text{ W-μm}^4 / \text{cm}^2$$

$$c_2 = 2.58984 \times 10^4 \text{ μm-}^\circ\text{R} = 1.4388 \times 10^4 \text{ μm-K}$$

$$c_3 = 5.216 \times 10^3 \text{ μm-}^\circ\text{R} = 2.8978 \times 10^3 \text{ μm-K}$$

$$\sigma = 1.713 \times 10^{-9} \text{ Btu/hr-ft}^2 \cdot {}^\circ\text{R}^4 = 5.6693 \times 10^{-12} \text{ W/cm}^2 \cdot \text{K}^4$$

$$\sigma_{\text{exp}} = 1.731 \times 10^{-9} \text{ Btu/hr-ft}^2 \cdot {}^\circ\text{R}^4 = 5.729 \times 10^{-12} \text{ W/cm}^2 \cdot \text{K}^4$$

References: HP-67/97 Users' Library Program.

Example:

What percentage of the radiant output of a lamp is in the visible range (0.4 to 0.7 microns) if the filament of the lamp is assumed to be a black body at 2400K?

Keystrokes: (SIZE ≥ 009)

[USER]	(set USER mode)
[XEQ] [ALPHA] BB [ALPHA]	UNITS?
SI [R/S]	TEMP?
2400 [R/S]	WAVELENGTH?
.4 [R/S]	SOLVE
[F]	WV LNTH 2?
.7 [R/S]	EbL-L=4.9679
[C]	EbTOT=188.094
[÷]	0.0264
100 [x]	2.6412

Display:

# User Instructions

# Program Listings

01♦LBL "BB"		47 RCL 06	
02 CLRG	Initialize and prompt for units	48 /	Calculate T( $\lambda_{max}$ )
03 CF 22		49 "TEMP="	
04 "UNITS?"		50 ARCL X	
05 RDN		51 PROMPT	
06 PROMPT		52♦LBL C	Calculate E <sub>b</sub>
07 ROFF		53 RCL 05	total
08 ASTO X		54 X↑2	
09 GTO IND		55 X↑2	
X		56 RCL 04	
10♦LBL "SI"		57 *	
11 5954.4	Store units	58 "EbTOT="	
12 STO 01		59 ARCL X	
13 14388		60 PROMPT	
14 STO 02		61♦LBL D	Calculate E <sub>bλ</sub>
15 2897.8		62 RCL 01	
16 STO 03		63 ENTER↑	
17 5.6693 E		64 +	
-12		65 PI	
18 STO 04		66 *	
19 GTO 00		67 RCL 06	
20♦LBL "EN"		68 5	
21 18887982		69 Y↑X	
22 STO 01		70 /	
23 25998.4		71 RCL 02	
24 STO 02		72 RCL 06	
25 5216		73 /	
26 STO 03		74 RCL 05	
27 .171312		75 /	
E-08		76 E↑X	
28 STO 04		77 1	
29♦LBL 00		78 -	
30 "TEMP?"		79 /	
31 PROMPT		80 "EbL="	
32 STO 05		81 ARCL X	
33 "WAVELEN		82 PROMPT	
GTH?"		83♦LBL E	Calculate E <sub>b</sub> (0- $\lambda$ )
34 PROMPT		84 0	
35 STO 06		85 STO 08	
36 "SOLVE"		86 STO 07	
37 PROMPT		87♦LBL 01	
38♦LBL A		88 RDN	
39 RCL 03		89 CLX	
40 RCL 05		90 RCL 08	
41 /		91 RCL 02	
42 "WL MAX=		92 RCL 05	
"		93 /	
43 ARCL X		94 -	
44 PROMPT		95 STO 08	
45♦LBL B		96 3	
46 RCL 03		97 X<>Y	

# Program Listings

<pre> 98 / 99 RCL 06 100 X↑2 101 / 102 LASTX 103 1/X 104 RCL 06 105 / 106 - 107 6 108 RCL 06 109 / 110 RCL 08 111 X↑2 112 / 113 - 114 6 115 RCL 08 116 X↑2 117 / 118 RCL 08 119 / 120 + 121 RCL 08 122 RCL 06 123 / 124 E↑X 125 * 126 RCL 08 127 / 128 ST+ 07 129 RCL 07 130 / 131 1 E-05 132 X&lt;=Y? 133 GTO 01 134 RDN 135 CLX 136 RCL 07 137 ENTER↑ 138 + 139 PI 140 * 141 RCL 01 142 * 143 FS?C 00 144 RTN 145 "Eb0-L=" 146 ARCL X 147 PROMPT 148♦LBL F </pre>	<p>Calculate  <math>E_b(\lambda_1 - \lambda_2)</math></p>	<pre> 149 "WV LNTH 2? " 150 PROMPT 151 ENTER↑ 152 ENTER↑ 153 SF 00 154 XEQ E 155 X&lt;&gt;Y 156 RCL 06 157 STO 00 158 RDN 159 STO 06 160 SF 00 161 XEQ E 162 - 163 ABS 164 RCL 00 165 STO 06 166 RDN 167 "EbL-L=" 168 ARCL X 169 PROMPT 170 .END. </pre>	<p>80</p> <p>90</p> <p>00</p>
---	---	--	-------------------------------

# REGISTERS, STATUS, FLAGS, ASSIGNMENTS

DATA REGISTERS				STATUS			
#	NAME	DECIMAL POSITION	HEX POSITION	SIZE		TOT. REG.	USER MODE
				ENG	DEG	57	ON X OFF
00	$\lambda$	50					
	$C_1$						
	$C_2$						
	$C_3$						
	$\sigma$						
05	T	55					
	$\lambda, \lambda'$						
	sum			00		Used	
	$kC_2/T$			22		Used	
10		60					
15		65					
20		70					
25		75					
30		80					
35		85					
ASSIGNMENTS							
				FUNCTION	KEY	FUNCTION	KEY
40		90					
45		95					

## PSYCHROMETRIC PROPERTIES

(Requires one memory module)

Given pressure, drybulb temperature and either wet bulb temperature or relative humidity or vapor pressure, this program computes wet bulb temperature, dew point temperature, vapor pressure, humidity ratio, relative humidity, enthalpy and specific volume.

Either English or SI units may be used in problem solution.

Variable	English Units	SI Units
Temperature	°F	°C
Pressure	psi	kPa
Humidity Ratio	lb <sub>m</sub> /lb <sub>m</sub> dry air	kg/kg dry air
Relative Humidity	%	%
Enthalpy	Btu/lb <sub>m</sub> dry air	kJ/kg dry air
Specific Volume	ft <sup>3</sup> /lb <sub>m</sub> dry air	dm <sup>3</sup> /kg dry air

Temperatures may range from -40°F (-40°C) to 300 °F (150°C). For temperatures less than the ice point, vapor is assumed in equilibrium with ice.

Total pressure may range from 1.0 psi (7.0 kPa) to 50.0 psi (345.0 kPa).

Relative humidity may range between 0.0 and 100%.

Specific humidity must be less than 0.2.

If limits are exceeded program will halt with alpha diagnostic in Display.

Equations:

$$w = \frac{c_{p,a}(t_{wb} - t_{db}) + \omega_{sat,wb}(h_{g,wb} - h_{f,wb})}{h_{v,db} - h_{f,wb}}$$

$$c_{p,a} = 0.240 \text{ Btu/lb}_m \text{ °F} = 1.0048 \text{ kJ/kg °C}$$

$$h_v = h_g = a + bt \quad a = 1061.0 \text{ Btu/lb}_m = 2501.0 \text{ kJ/kg}$$

$$b = 0.445 \text{ Btu/lb}_m \text{ °F} = 1.8631 \text{ kJ/kg °C}$$

IF  $t \geq 32^{\circ}\text{F}$  or  $0^{\circ}\text{C}$

THEN  $h_f = (t - c)d$

$$c = 32^{\circ}\text{F} = 0^{\circ}\text{C}$$

$$d = 1\text{Btu/lb}_m \text{ °F} = 4.1868 \text{ kJ/kg °C}$$

IF  $t \geq 32^{\circ}\text{F}$  or  $0^{\circ}\text{C}$  THEN  $h_f = h_i = [(t-c)0.467 + e]d$   
 $e = -143.956^{\circ}\text{F} = -79.97556^{\circ}\text{C}$

$$H = c_p, a t_{db} + W h_{v, db}$$

$$W = \frac{R_{air}}{R_{vapor}} = \frac{PV}{P - PV} = \frac{R_{air}}{R_{vapor}} = 0.622$$

(also used to calculate  $P_{vapor}$ )

$$P_{sat} = f e^{g/(t+h)}$$

$t$  = temperature,  $^{\circ}\text{F}$  or  $^{\circ}\text{C}$

$e = 2.718282$

IF  $t \geq 32^{\circ}\text{F}$  or  $0^{\circ}\text{C}$  THEN  $f = 2.04466 \cdot 10^6 \text{ psi} = 1.40974 \cdot 10^7 \text{ kPa}$   
 $g = -7071.3^{\circ}\text{F} = -3928.5^{\circ}\text{C}$   
 $h = 385^{\circ}\text{F} = 231.667^{\circ}\text{C}$

IF  $t \geq 32^{\circ}\text{F}$  or  $0^{\circ}\text{C}$  THEN  $f = 5.24506 \cdot 10^8 \text{ psi} = 3.61633 \cdot 10^9 \text{ kPa}$   
 $g = -11071^{\circ}\text{F} = -6150.6^{\circ}\text{C}$   
 $h = 460^{\circ}\text{F} = 273.33^{\circ}\text{C}$

$$V = \frac{R_{air} T}{P_{total} - P_{vapor}}$$

$$REL = P_{vapor}/P_{sat, db}$$

where:

- P is the total pressure.
- PV is the vapor pressure
- $t_{db}$  is the dry bulb temperature.
- $P_{sat}$  is the saturation pressure.
- $t_{wb}$  is the wet bulb temperature.
- $t_{dp}$  is the dew point temperature.
- W is the humidity ratio.
- REL is the relative humidity.
- h is the enthalpy.
- V is the specific volume.

Reference:

**Example 1:**

$P = 101.325 \text{ kPa}$ ,  $T_{wb} = 20^\circ\text{C}$   $T_{db} = 25^\circ$

Keystrokes: (SIZE > 010)

Display:

[//] [FIX] 4	
[XEQ] [ALPHA] PSYCHSI [ALPHA]	P=?
101.325 [R/S]	Tdb=?
25 [R/S]	PSAT=3.1762
[R/S]*	SELECT KEY: TWb REL PV
[A]	TWb=?
20 [R/S]	TdP=17.6023
[R/S]*	PV=2.0166
[R/S]*	W=0.0126
[R/S]*	REL=63.4931
[R/S]*	H=57.2983
[R/S]*	V=860.7494
[R/S]*	P=?

\*Press [R/S] if you are not using a printer.

**Example 2:**

$P = 25 \text{ psi}$ ,  $T_{db} = 70.0^\circ\text{F}$ ,  $PV = 0.182 \text{ psi}$

Keystrokes:

Display:

[//] [FIX] 4	
[XEQ] [ALPHA] PSYCHE [ALPHA]	P=?
25 [R/S]	Tdb=?
70 [R/S]	PSAT=0.3640
[R/S]*	SELECT KEY: TWb REL PV
[E]	PV=?
.182 [R/S]	TWb=60.8398
[R/S]*	TdP=50.5726
[R/S]*	PV=0.1820
[R/S]*	W=0.0046
[R/S]*	REL=49.9988
[R/S]*	H=21.7817
[R/S]*	V=7.8987
[R/S]*	P=?

\*Press [R/S] if you are not using a printer.

# User Instructions

				SIZE: 010
STEP	INSTRUCTIONS	INPUT	FUNCTION	DISPLAY
1.	Load program			
2.	Initialize program for English units, or SI units.		[XEQ] PSYCHE [XEQ] PSYCHSI	P=?
3.	Key in total pressure.	P	[R/S]	Tdb=?
4.	Key in dry bulb temperature.	Tdb	[R/S]	PSAT=
			[R/S]*	SELECT KEY:
				TWb REL PV
5.	Press [A] if you know wet bulb temperature, [C] if you know relative humidity, or [E] if you know vapor pressure, then go to 6a, 6b, or 6c.		[A] [B] [C]	TWb=? REL=? PV=?
6a.	Key in wet bulb temperature and start calculation.	TWb	[R/S]	
6b.	Key in relative humidity and start calculation.	REL	[R/S]	TWb=
6c.	Key in vapor pressure and start calculation	PV	[R/S]	TWb=
7.	See outputs of:  Dew Point temperature, Vapor Pressure, Humidity Ratio, Relative Humidity, Enthalpy, Specific Volume		[R/S]* [R/S]* [R/S]* [R/S]* [R/S]* [R/S]*	TdP= PV= W= REL= H= V=
8.	For a new case using the same units, go to step 3. Key in only values which change.		[R/S]*	P=?
*	Press [R/S] if you are not using a printer			

# Program Listings

<pre> 01♦LBL "PSY CHSI" 02 SF 00 03 GTO 00 04♦LBL "PSY CHE" 05 CF 00 06♦LBL 00 07 0 08 STO 00 09 ADV 10 "P" 11 XEQ "IN" 12 "Tdb" 13 XEQ "IN" 14 XEQ F 15 ADV 16 "PSAT" 17 XEQ "O" 18 STO 06 19 ADV 20 "SELECT KEY: " 21 CF 21 22 AVIEW 23 SF 21 24 PSE 25♦LBL 22 26 SF 27 27 "TWb RE L PV" 28 PROMPT 29 GTO 22 30♦LBL A 31 2 32 STO 00 33 "TWb" 34 XEQ "IN" 35 XEQ F 36 XEQ 03 37 "TWb HIG H" 38 X&lt;0? 39 PROMPT 40 XEQ 04 41 "TWb LOW " 42 X&lt;0? 43 PROMPT 44 STO 07 45 .2 </pre>	<p>Initialize for SI units.</p> <p>Initialize for English units.</p> <p>Input T and <math>T_{db}</math>.</p> <p>Calculate <math>P_{sat}</math>.</p> <p>Prompt user to select key [A], [C], or [E].</p> <p>Input <math>T_{wb}</math>.</p>	<pre> 46 "SPC HUM &gt;=.2" 47 X&lt;=Y? 48 PROMPT 49 RDN 50 RCL 01 51 * 52 RCL 07 53 .622 54 + 55 / 56 "TWb&gt;Tdb " 57 XEQ 05 58 ADV 59 GTO 18 60♦LBL C 61 3 62 STO 00 63 "REL" 64 XEQ "IN" 65 ADV 66 RCL 02 67 STO 03 68 XEQ F 69 X&lt;&gt;Y 70 % 71 STO 08 72 GTO 00 73♦LBL E 74 RCL 02 75 STO 03 76 ? 77 STO 00 78 "PV" 79 XEQ "IN" 80 "VP&gt;Tdb" 81 ADV 82 XEQ 05 83 RCL 08 84♦LBL 00 85 XEQ 03 86 "VP&gt;P" 87 X&lt;0? 88 PROMPT 89 STO 07 90 .2 91 "W&gt;.2" 92 X&lt;=Y? 93 PROMPT 94 FS? 00 </pre>	<p>Input relative humidity.</p> <p>Input vapor pressure.</p>
--	--	--	--

# Program Listings

```

95  80
96  FC?  00
97  140
98  STO  09
99  CF  02
100♦LBL 01
101  RCL 09
102  FS?C 02
103  CHS
104  ST- 03
105  2
106  ST/ 09
107  RCL 03
108  XEQ  F
109  XEQ  03
110  X<0?
111  GTO  01
112  XEQ  04
113  RCL  07
114  -
115  X<0?
116  SF  02
117  ABS
118  1 E-5
119  X<=Y?
120  GTO  01
121  GTO  08
122♦LBL 06
123  FC?  00
124  .445
125  FS?  00
126  1.8631
127  *
128  FC?  00
129  1061
130  FS?  00
131  2501
132  +
133  X<>Y
134  32
135  FS?  00
136  CLX
137  -
138  X<0?
139  XEQ  07
140  FC?  00
141  1
142  FS?  00
143  4.1868
144  *
145  -

```

	Calculate $T_{wb}$ .
Calculate enthalpy difference.	

```

146  RTN
147♦LBL 07
148  .467
149  *
150  FC?  00
151  -143.956
152  FS?  00
153  -79.9755
6
154  +
155  RTN
156♦LBL 05
157  STO  08
158  RCL  06
159  /
160  1
161  X<>Y
162  X>Y?
163  PROMPT
164  1 E2
165  *
166  STO  04
167  RTN
168♦LBL 08
169  RCL  03
170  "TWb"
171  XEQ  "0"
172♦LBL 18
173  RCL  08
174  X=0?
175  GTO  09
176  32
177  FS?  00
178  CLX
179  XEQ  F
180  X>Y?
181  GTO  00
182  RCL  08
183  FS?  00
184  1.40974
E7
185  FC?  00
186  2.04466
E6
187  /
188  LN
189  1/X
190  FS?  00
191  -3928.5
192  FC?  00
193  -7071.3

```

	Relative humidity calculation.
Print results.	

# Program Listings

194 *		243 2.04466	
195 FS? 00		E6	
196 231.667		244 *	
197 FC? 00		245 RTN	
198 385		246♦LBL 00	Saturation pressure for sub-icepoint conditions.
199 -		247 RDN	
200 GTO 11		248 FS? 00	
201♦LBL 00		249 273.33	
202 RCL 08		250 FC? 00	
203 FS? 00		251 460	
204 5.24506		252 +	
E8		253 FS? 00	
205 FC? 00		254 -6150.6	
206 3.61633		255 FC? 00	
E9		256 -11071	
207 /		257 X<>Y	
208 LN		258 /	
209 1/X		259 E↑X	
210 FS? 00		260 FS? 00	
211 -6150.6		261 5.2406 E	
212 FC? 00		8	
213 -11071		262 FC? 00	
214 *		263 3.61633	
215 FS? 00		E9	
216 273.33		264 *	
217 FC? 00		265 RTN	
218 460		266♦LBL 03	
219 -		267 "WSAT OR VP=P"	
220 GTO 11		268 .622	
221♦LBL F		269 X<>Y	Calculate specific humidity from vapor pressure.
222 32		270 *	
223 FS? 00		271 RCL 01	
224 CLX		272 LASTX	
225 X>Y?		273 -	
226 GTO 00		274 X=0?	
227 RDN		275 PROMPT	
228 FS? 00		276 /	
229 231.667		277 RTN	
230 FC? 00		278♦LBL 04	
231 385		279 RCL 03	
232 +		280 RCL 03	
233 FS? 00		281 XEQ 06	
234 -3928.5		282 *	
235 FC? 00		283 RCL 03	
236 -7071.3		284 RCL 02	
237 X<>Y		285 -	
238 /		286 FC? 00	
239 E↑X		287 .24	
240 FS? 00		288 FS? 00	
241 1.40974		289 1.0048	
E7			
242 FC? 00			

# Program Listings

290 *	341 "V"	
291 +	342 XEQ "0"	
292 RCL 03	343 GTO 00	
293 RCL 02	344♦LBL "IN"	
294 XEQ 06	345 CF 22	
295 /	346 1	
296 RTN	347 ST+ 00	
297♦LBL 11	348 RCL IND	
298 "TdP"	00	Input subroutine.
299 XEQ "0"	349 "T="	
300♦LBL 09	350 ASTO Y	
301 RCL 08	351 "T?"	
302 "PV"	352 CF 21	
303 XEQ "0"	353 AVIEW	
304 RCL 07	354 SF 21	
305 "W"	355 CLA	
306 XEQ "0"	356 ARCL Y	
307 RCL 04	357 STOP	
308 "REL"	358 STO IND	
309 XEQ "0"	00	
310 RCL 02	359 FS? 22	
311 FC? 00	360 FC? 55	
312 .24	361 RTN	
313 FS? 00	362 ARCL X	
314 1.0048	363 PRA	
315 *	364 RTN	
316 32	365♦LBL "0"	
317 FS? 00	366 "T="	Output subroutine
318 ST- X	367 ARCL X	
319 RCL 02	368 AVIEW	
320 XEQ 06	80	
321 RCL 07		
322 *		
323 +		
324 "H"		
325 XEQ "0"		
326 RCL 02		
327 FC? 00		
328 459.67		
329 FS? 00		
330 273.15	90	
331 +		
332 FC? 00		
333 .3701		
334 FS? 00		
335 286.7		
336 *		
337 RCL 01		
338 RCL 08		
339 -		
340 /	00	

# REGISTERS, STATUS, FLAGS, ASSIGNMENTS

DATA REGISTERS				STATUS			
Reg	Name	Value		INIT S/C			
				SIZE	TOT. REG.	USER MODE	
00	Data Pointer	50		ENG	FIX	SCI	ON X OFF
	P			DEG	RAD	GRAD	
05	Tdb			FLAGS			
	TWb			#	INIT S/C	SET INDICATES	CLEAR INDICATES
10	Used			00		SI	English
	VP	55		21		Stop on view	
15	PSAT			27		User mode	
	W						
20	PV						
	Used						
25		60					
30		65					
35		70					
40		75					
45		80		ASSIGNMENTS			
				FUNCTION	KEY	FUNCTION	KEY
		85					
		90					
		95					

## HEAT EXCHANGERS

(Requires one memory module)

This program allows analysis of counterflow, parallel flow, parallel-counterflow, and crossflow heat exchangers.

Figure 1:




Figure 2:




Figure 3:





Figure 4:



Equations:

Heat exchanger effectiveness  $E$  is the ratio of actual heat transfer to maximum possible heat transfer.

$$E = \frac{Q}{C_{\min} (T_{hin} - T_{cin})} = \frac{C_h (T_{hin} - T_{ho})}{C_{\min} (T_{hin} - T_{cin})} = \frac{C_c (T_{co} - T_{cin})}{C_{\min} (T_{hin} - T_{cin})}$$

where:

$Q$  is the actual heat transfer.

$T_{hin}$  and  $T_{cin}$  are the inlet temperatures of the hot and cold fluids respectively.

$T_{ho}$  and  $T_{co}$  are the outlet temperatures of the hot and cold fluids respectively.

$C_h$  and  $C_c$  are the heat capacities of the hot and cold fluids, respectively,  
e.g.,  $C_h = m_h \times c_{ph}$ , where  $m_h$  is the flow rate and  $c_{ph}$  is the specific heat capacity of the hot fluid.

$C_{\min}$  and  $C_{\max}$  (which are used later) are the smaller and larger values of  $C_h$  and  $C_c$ .

Effectiveness can be related to the product of the surface area of the heat exchanger and the overall heat transfer coefficient for specific geometries. This product is designated AU. The geometries considered in this pac have the following correlations:

Counterflow (see figure 1)

$$E = \frac{\frac{1 - e^{-\frac{AU}{C_{\min}}}}{1 - e^{-\frac{AU}{C_{\min}}}} \left( 1 - \frac{C_{\min}}{C_{\max}} \right)}{1 - (C_{\min}/C_{\max})e^{-\frac{AU}{C_{\min}}}} \left( 1 - \frac{C_{\min}}{C_{\max}} \right)$$

For  $C_{\min}/C_{\max} = 1$

$$E = \frac{AU/C_{\min}}{1 + AU/C_{\min}}$$

Parallel Flow (see figure 2)

$$E = \frac{\frac{1 - e^{-\frac{AU}{C_{\min}}}}{1 + C_{\min}/C_{\max}} (1 + C_{\min}/C_{\max})}{1 + C_{\min}/C_{\max}}$$

For  $C_{\min}/C_{\max} = 0$ ,  $C_{\min}$  is set to 1.

Parallel-Counterflow (well mixed with an even number of tube passes; see Figure 3)

$$E = \frac{2}{\left(1 + \frac{C_{\min}}{C_{\max}}\right) + \sqrt{1 + \left(\frac{C_{\min}}{C_{\max}}\right)^2 \left[ \frac{1 + e^{-x}}{1 - e^{-x}} \right]}}$$

where:

$$x = \frac{AU}{C_{\min}} \quad \sqrt{1 + \left(\frac{C_{\min}}{C_{\max}}\right)^2}$$

Crossflow (both fluids unmixed; see figure 4)

No exact expression exists for this case, but the following is a very good approximation. Note that an iterative solution is required for AU.

$$E = 1 - e \left( e^{\left( -\frac{AU}{C_{min}} \frac{C_{max}}{C_{min}} y \right)} - 1 \right) \left( \frac{C_{max}}{C_{min}} \frac{1}{y} \right)^{0.22}$$

where:

$$y = \left[ \frac{C_{min}}{AU} \right]^{0.22}$$

References:

W.M. Kays and A.L. London, *Compact Heat Exchangers*, National Press, 1955  
 Eckert and Drake, *Heat and Mass Transfer*, McGraw-Hill.

Remarks:

For cases where the inlet and outlet temperatures of one of the fluids are equal(change of phase), use zero for the heat capacity of that fluid.

The solution for AU in the crossflow configuration takes significantly longer than other solutions because of the iterative technique required.

The program must be allowed to solve for all values (AU, Q,  $T_{co}$ ,  $T_{ho}$ , and E). It is quite possible for the heat balance equations to yield physically meaningless solutions for a particular configuration. However, the message "2ND LAW ERR" will be displayed if the 2nd law of thermodynamics has been violated during the calculation of AU or Q.

This program is organized into five routines. The first routine performs heat balance calculations and acts as a controller for the four configuration subroutines. Each configuration subroutine has two sections that calculate AU and E for that heat exchanger. You should first load the controller, then load the configuration of interest as a separate program.

You may wish to write your own configuration routines. A routine for a configuration must be in the following format:

```

LBL ACON
•
•
•
(calculates AU for this configuration)
•
•
RTN
•
•
LBL ECON
•
•
•
(calculates E for this configuration)
•
•
END

```

**Example:**

A liquid at  $168^{\circ}\text{F}$  is to be cooled to  $117^{\circ}\text{F}$ . The liquid has a heat capacity of  $0.42 \text{ Btu/LBM-}^{\circ}\text{F}$  and flows at  $7700 \text{ LBM/hr}$ . Cooling water (heat capacity =  $1.00$ ) is available at  $4800 \text{ lbm/hr}$  at  $50^{\circ}\text{F}$ . For counterflow, crossflow, parallel-counterflow, and parallel flow heat exchangers with overall coefficients of  $55 \text{ Btu/hr-ft}^2-{}^{\circ}\text{F}$  what areas are required?

Keystrokes: (SIZE  $\geq 023$ )

Display:

[//] [FIX] 4

Load main routine and counterflow subroutine.

[XEQ] [ALPHA] HEATX [ALPHA]

TC IN=?

50 [R/S]

TH IN=?

168 [R/S]

MC=?

4800 [R/S]

MH=?

7700 [R/S]

CPC=?

1 [R/S]

CPH=?

.42 [R/S]

SELECT KEY: E AU Q TC TH

Since the temperature of the outgoing fluid is known, press the [E] key.

[E]

THO=?

117 [R/S]

E=0.4322

[R/S]\*

AU=2,198.7662

[R/S]\*

Q=164,933.9999

[R/S]\*

TCO=84.3612

[R/S]\*

SELECT KEY: E AU Q TC TH

Keystrokes:	Display:
Since A = AU/U, calculate A.	
2198.7662 [ENTER] 55 [:]	39.9776
Load crossflow subroutine.	
[XEQ] [ALPHA] HEATX [ALPHA]	TC IN=?
[R/S]	TH IN=?
[R/S]	MC=?
[R/S]	MH=?
[R/S]	CPC=?
[R/S]	CPH=?
[R/S]	SELECT KEY: E AU Q TC TH
[E]	THO=?
[R/S]	E=0.4322
[R/S]*	AU=2,353.6675
[R/S]*	Q=164,934.0000
[R/S]*	TCO=84.3613
[R/S]	SELECT KEY: E AU Q TC TH
2353.6675 [ENTER] 55 [:]	42.7940

An analogous procedure will yield areas of  $42.2776 \text{ ft}^2$  and  $45.1494 \text{ ft}^2$  for parallel-counterflow and parallel exchanges respectively.

# User Instructions

				SIZE: 023
STEP	INSTRUCTIONS	INPUT	FUNCTION	DISPLAY
1.	Load program and then:		[GTO] ..	
2.	Load configuration subroutine corresponding to your heat exchanger geometry		[XEQ] HEATX	TC IN=?
3.	Input inlet temperature of cold fluid	$T_{cin}$	[R/S]	TH IN=?
4.	Input inlet temperature of hot fluid	$T_{hin}$	[R/S]	MC=?
5.	Input mass flow rate of cold fluid	$m_c$	[R/S]	MH=?
6.	Input mass flow rate of hot fluid	$m_h$	[R/S]	CPC=?
7.	Input specific heat of cold fluid	$c_{pc}$	[R/S]	CPH=?
8.	Input specific heat of hot fluid	$c_{ph}$	[R/S]	SELECT KEY
				E AU Q TC TH
9.	Select the known value:  heat exchanger effectiveness		[A]	E=?
	area-heat transfer coefficient product		[B]	AU=?
	heat transfer		[C]	Q=?
	outlet temperature of cold fluid		[D]	TCO=?
	outlet temperature of hot fluid		[E]	THO=?
	input the known value.	E	[R/S]	
		AU	[R/S]	
		Q	[R/S]	
		TCO	[R/S]	
		THO	[R/S]	
	The four variables other than the one you input will be output. The output order			E=
	will vary depending on which value was input. If the 2nd law of thermodynamics		[R/S]*	AU=
	is violated, the message "2ND LAW ERR"		[R/S]*	Q=
	will be displayed.		[R/S]*	TCO=
			[R/S]*	THO=
			[R/S]*	SELECT KEY

# User Instructions

# Program Listings

## Heat Exchanger - Main Routine

01♦LBL "HEA TX" 02 2 03 STO 00 04 "TC IN" 05 XEQ "IN" 06 "TH IN" 07 XEQ "IN" 08 14 09 STO 00 10 "MC" 11 XEQ "IN" 12 "MH" 13 XEQ "IN" 14 "CPC" 15 XEQ "IN" 16 RCL 15 17 * 18 STO 05 19 "CPH" 20 XEQ "IN" 21 RCL 16 22 * 23 STO 06 24 "CON" 25 ASTO 22 26♦LBL 06 27 CF 02 28 CF 03 29 CF 04 30 CF 05 31 CF 06 32 CF 21 33 SF 27 34 "SELECT KEY: 35 AVIEW 36 SF 21 37 PSE 38♦LBL 00 39 ADV 40 "E AU Q TC TH" 41 PROMPT 42 GTO 00 43♦LBL A 44 SF 02 45 9 46 STO 00 47 SF 01 48 "E"	Input values.  Select last input.  Input E.	49 XEQ "IN" 50 ADV 51 GTO 16 52♦LBL B 53 SF 03 54 10 55 STO 00 56 "AU" 57 XEQ "IN" 58 ADV 59 GTO 01 60♦LBL C 61 SF 04 62 11 63 STO 00 64 "Q" 65 XEQ "IN" 66 ADV 67 GTO 05 68♦LBL D 69 SF 05 70 12 71 STO 00 72 "TCO" 73 XEQ "IN" 74 ADV 75 GTO 14 76♦LBL E 77 SF 06 78 13 79 STO 00 80 "THO" 81 XEQ "IN" 82 ADV 83 GTO 04 84♦LBL 16 85 FS?C 03 86 GTO 06 87 RCL 10 88 "A" 89 XEQ 08 90 STO 11 91 "AU" 92 XEQ "0" 93♦LBL 01 94 FS?C 04 95 GTO 06 96 RCL 11 97 "E" 98 XEQ 08 99 RCL 07	Input AU.  Input Q.  Input TCO.  Input THO.  Calculate AU.  Calculate Q.
--	---	--	--

# Program Listings

## Heat Exchanger - Main Routine

100 *		151 X<>Y	
101 RCL 04		152 RCL 04	
102 RCL 03		153 RCL 03	
103 -		154 -	
104 *		155 /	
105 STO 12		156 RCL 05	
106 "Q"		157 RCL 06	
107 XEQ "0"		158 X<=Y?	
108♦LBL 05		159 X<>Y	
109 FS?C 05		160 RTN	
110 GTO 06	Calculate TCO.	161 X=0?	
111 RCL 12		162 X<> T	
112 RCL 05		163 /	
113 X#0?		164 STO 10	
114 /		165 SF 01	
115 RCL 03		166 "E"	
116 +		167 XEQ "0"	
117 STO 13		168 GTO 16	
118 "TCO"		169♦LBL "A0"	
119 XEQ "0"		170 1	
120♦LBL 14		171 RCL 10	
121 FS?C 06		172 -	
122 GTO 06		173 LN	A0 for C <sub>min</sub> =0.00.
123 RCL 13	Calculate THO.	174 CHS	
124 RCL 03		175 RTN	
125 -		176♦LBL "E0"	
126 RCL 05		177 1	
127 *		178 RCL 11	
128 RCL 06		179 CHS	
129 X#0?		180 E↑X	E0 for C <sub>min</sub> =0.00.
130 /		181 -	
131 RCL 04		182 RTN	
132 -		183♦LBL 08	
133 CHS		184 RCL 05	
134 STO 14		185 RCL 06	
135 "THO"		186 X>Y?	Find C <sub>min</sub> and
136 XEQ "0"		187 X<>Y	execute
137♦LBL 04		188 X<>Y	configuration
138 FS?C 02		189 STO 07	subroutine.
139 GTO 06		190 X<>Y	
140 RCL 13	Calculate E.	191 X#0?	
141 RCL 03		192 STO 07	
142 -		193 X<>Y	
143 RCL 05		194 X#0?	
144 *		195 /	
145 RCL 04		196 STO 09	
146 RCL 14		197 SF 25	
147 -		198 X=0?	
148 RCL 06		199 "F0"	
149 *		200 X#0?	
150 X=0?		201 ARCL 22	

# Program Listings

202 ASTO T		51	
203 XEQ IND			
T			
204 FS?C 25			
205 RTN			
206 "2ND LAW			
ERR"			
207 PROMPT	Trap errors from		
208 GTO 06	subroutines		
209♦LBL "IN"			
210 CF 22		60	
211 1			
212 ST+ 00			
213 RCL IND			
00			
214 "F=			
215 ASTO Y			
216 "F?"			
217 CF 21			
218 AVIEW			
219 SF 21		70	
220 CLA			
221 ARCL Y			
222 STOP			
223 STO IND			
00			
224 FS? 22			
225 FC? 55			
226 RTN			
227 ARCL X			
228 PRA		80	
229 RTN	Print if printer		
230♦LBL "O"	is attached		
231 "F=			
232 ARCL X			
233 AVIEW			
234 .END.			
40			
		90	
50		00	

# Program Listings

## Parallel Flow Subroutine

01♦LBL "ACO	Calculate AU.	51		
H"				
02 RCL 09				
03 1				
04 +				
05 RCL 10				
06 *				
07 CHS				
08 1				
09 +		60		
10 LN				
11 CHS				
12 1				
13 RCL 09				
14 +				
15 /				
16 RCL 07				
17 *				
18 RTN				
19♦LBL "ECO	Calculate E.	70		
H"				
20 1				
21 +				
22 RCL 11				
23 RCL 07				
24 /				
25 *				
26 CHS				
27 E↑X				
28 CHS				
29 1		80		
30 +				
31 1				
32 RCL 09				
33 +				
34 /				
35 RTN				
40		90		
50		00		

# Program Listings

## Counter Flow Subroutine

01♦LBL "ACO		50 RCL 11	
N"	Calculate AU.	51 RCL 07	
02 RCL 10		52 /	
03 1/x		53 ENTER↑	
04 -		54 ENTER↑	
05 1		55 1	
06 LASTX		56 +	
07 -		57 /	
08 /		58 RTN	
09 LN		60	
10 1			
11 RCL 09			
12 -			
13 X=0?			
14 GTO 10			
15 /			
16 RCL 07			
17 *			
18 RTN			
19♦LBL 10		70	
20 RCL 10			
21 1			
22 RCL 10			
23 -			
24 /			
25 RCL 07			
26 *			
27 RTN			
28♦LBL "ECO			
N"	Calculate E.	80	
29 1			
30 -			
31 RCL 11			
32 RCL 07			
33 /			
34 *			
35 E↑X			
36 1			
37 X<>Y			
38 -			
39 LASTX		90	
40 RCL 09			
41 *			
42 1			
43 X<>Y			
44 -			
45 X=0?			
46 GTO 11			
47 /			
48 RTN			
49♦LBL 11		00	

# Program Listings

## Parallel-Counter Flow Subroutine

01♦LBL "ACO		50♦LBL 12	
N"	Calculate AU.	51 RCL 09	
02 XEQ 12		52 1	
03 2		53 +	
04 *		54 STO 08	
05 RCL 12		55 RCL 09	
06 2		56 X↑2	
07 RCL 10		57 1	
08 /		58 +	
09 +		59 SQRT	
10 RCL 08		60 STO 12	
11 -		61 RTN	
12 /			
13 CHS			
14 1			
15 +			
16 LN			
17 RCL 12			
18 /			
19 CHS		70	
20 RCL 07			
21 /			
22 LASTX			
23 X↑2			
24 *			
25 RTN			
26♦LBL "ECO			
N"	Calculate E.		
27 XEQ 12			
28 RCL 11			
29 RCL 07		80	
30 /			
31 RCL 12			
32 *			
33 CHS			
34 E↑X			
35 1			
36 X<>Y			
37 +			
38 1			
39 LASTX		90	
40 -			
41 /			
42 RCL 12			
43 *			
44 RCL 08			
45 +			
46 2			
47 X<>Y			
48 /			
49 RTN		00	

# Program Listings

## Cross Flow Subroutine

01♦LBL "ACO		49 E↑X
N"	Calculate AU.	50 1
02 0		51 -
03 STO 19		52 *
04 1		53 E↑X
05 RCL 10		54 CHS
06 CHS		55 1
07 STO 21		56 +
08 +		
09 LN		60
10 CHS		
11 STO 11		
12♦LBL 13		
13 RCL 11		
14 XEQ "ECO		
N"		
15 RCL 10		
16 -		
17 STO 20		
18 RCL 19		70
19 RCL 11		
20 STO 19		
21 -		
22 RCL 21		
23 RCL 20		
24 STO 21		
25 -		
26 /		
27 *		
28 ST- 11		80
29 ABS		
30 1 E-4		
31 X<=Y?		
32 GTO 13		
33 RCL 11		
34 RTN		
35♦LBL "ECO		
N"		
36 RCL 11	Calculate E.	
37 RCL 07		
38 /		90
39 ENTER↑		
40 ENTER↑		
41 .22		
42 Y↑X		
43 RCL 09		
44 /		
45 /		
46 LASTX		
47 X<>Y		
48 CHS		00

# REGISTERS, STATUS, FLAGS, ASSIGNMENTS

DATA REGISTERS			STATUS				
			SIZE	23	TOT. REG.	102	USER MODE
			ENG		FIX		ON X OFF
			DEG		RAD		GRAD
TC IN			FLAGS				
TH IN			#	INIT S/C	SET INDICATES	CLEAR INDICATES	
05 CC	55		0		Unit conversion		
CH			1	C			
Cmin			2	C			
Cmax			3	C			
Cmin/Cmax			4	C			
10 E	60		5	C			
AU			6	C			
Q			23		Alpha input		
Tco			55		Printer connected		
Tho							
15 MC	65						
MH							
cpc							
cph							
(AU <sub>i-1</sub> )							
20 F(AU <sub>i</sub> )	70						
F(AU <sub>i-1</sub> )							
"CON"							
25	75						
30	80						
35	85						
			ASSIGNMENTS				
			FUNCTION	KEY	FUNCTION	KEY	
40	90						
45	95						

## DECIBEL ADDITION AND SUBTRACTION

This program adds or subtracts sound pressure levels measured in decibels.

Equations:

$$dB_1 + dB_2 = 10 \log (10^{dB_1/10} + 10^{dB_2/10})$$

$$dB_1 - dB_2 = 10 \log (10^{dB_1/10} - 10^{dB_2/10})$$

When subtracting, if  $dB_1 < dB_2$ , the program will exchange values.

Example 1:

A noise level of 72 decibels is measured in a room. The air conditioning is turned on and the noise level increases to 74 decibels. What is the noise level of the air conditioning system.

Keystrokes:

Display:

[///] [FIX] 2

74 [ENTER] 72 [XEQ] [ALPHA] dB- [ALPHA] 69.67 dB

Example 2:

A compressor is known to have a sound pressure level of 90 dB. The background is 85 dB. What is the total?

Keystrokes:

Display:

[///] [FIX] 2

90 [ENTER] 85 [XEQ] [ALPHA] dB+ [ALPHA] 91.19dB

# User Instructions

# Program Listings

01♦LBL "dB+"	Add decibels.	51	
"			
02 XEQ 00			
03 +			
04 GTO 01			
05♦LBL "dB-	Subtract decibels.		
"			
06 XEQ 00			
07 -			
08 ABS			
09♦LBL 01	Display result.	60	
10 LOG			
11 10			
12 *			
13 CLA			
14 ARCL X	Convert for add or subtract.		
15 "F dB"		70	
16 AVIEW			
17 RTN			
18♦LBL 00			
19 10	30		
20 ST/Z			
21 /			
22 X<>Y			
23 10↑X			
24 X<>Y	40		
25 10↑X			
30	80		
40	90		
50	00		

# REGISTERS, STATUS, FLAGS, ASSIGNMENTS

DATA REGISTERS			STATUS					
00	50		SIZE	ANY	TOT. REG.	07	USER MODE	
			ENG		FIX		ON	OFF
			DEG		RAD		GRAD	
05	55		FLAGS					
			#	INIT S/C	SET INDICATES		CLEAR INDICATES	
10	60							
15	65							
20	70							
25	75							
30	80							
35	85							
40			ASSIGNMENTS					
			FUNCTION	KEY	FUNCTION	KEY		
			(suggested)					
45			dB+	-61				
			dB-	-51				
90	95							

## TEMPERATURE CONVERSION

This program converts interchangeably between the four types of temperature.

Equations:

$$K = ({}^{\circ}F + 459.67)/1.8$$

$$K = {}^{\circ}C + 273.15$$

$$K = {}^{\circ}R / 1.8$$

where:

K is temperature in Kelvins.

{}^{\circ}F is temperature in degrees Fahrenheit.

{}^{\circ}C is temperature in degrees Celsius.

{}^{\circ}R is temperature in degrees Rankine.

Remarks:

Only the stack registers, LASTx and the alpha register are used in the conversions.

Example:

Convert: 472K to {}^{\circ}R  
 27{}^{\circ}F to {}^{\circ}C  
 25{}^{\circ}C to {}^{\circ}F  
 100{}^{\circ}C to {}^{\circ}F

Keystrokes:

	Display:
[//] [FIX] 2	
[XEQ] [ALPHA] TCON [ALPHA]	F C R K
472 [D]	F C R K
[C]	849.60 ({}^{\circ}R)
[R/S]	F C R K
27 [A]	F C R K
[B]	-2.78 ({}^{\circ}C)
25 [B]	F C R K
[A]	77 ({}^{\circ}F)
100 [B]	F C R K
[A]	212 ({}^{\circ}F)

# User Instructions

# Program Listings

01♦LBL 00		51	
02 RTN	Display answer		
03♦LBL "TCO	-----		
N"	Initialize		
04 SF 27			
05 "F C R			
K"			
06 PROMPT			
07♦LBL A	-----		
08 459.67	°F-K	60	
09 +			
10 1.8			
11 /			
12 GTO D	-----		
13♦LBL B	-----		
14 273.15	°C-K		
15 +			
16 GTO D	-----		
17♦LBL C	-----		
18 1.8	°R-K	70	
19 /			
20♦LBL D	-----		
21 PROMPT	K-K		
22♦LBL A	-----		
23 1.8	K-°F		
24 *			
25 459.67			
26 -			
27 GTO 00	-----		
28♦LBL B	-----		
29 273.15	K-°C	80	
30 -			
31 GTO 00	-----		
32♦LBL C	-----		
33 1.8	K-°R		
34 *			
35♦LBL D	-----		
36 GTO 00	K-K		
37 .END.			
40		90	
50		00	

# REGISTERS, STATUS, FLAGS, ASSIGNMENTS

DATA REGISTERS			STATUS				
00	50		SIZE	ANY	TOT. REG.	14	USER MODE
			ENG	FIX	SCI	ON X	OFF
05	55		DEG	RAD	GRAD		
			FLAGS				
10	60		#	INIT S/C	SET INDICATES	CLEAR INDICATES	
			27	S	User mode		
15	65						
20	70						
25	75						
30	80						
35	85						
ASSIGNMENTS							
40	90		FUNCTION	KEY	FUNCTION	KEY	
45	95						

## **NOTES**

## **NOTES**

**HEWLETT-PACKARD**

**HP-41C**

**USERS' LIBRARY SOLUTIONS**

**Bar Codes**

**Heating, Ventilating &  
Air Conditioning**

## HEATING, VENTILATING & AIR CONDITIONING

OVERALL HEAT TRANSFER COEFFICIENTS .....	1
INSULATION BREAK EVEN ANALYSIS .....	2
AIR FLOW IN CIRCULAR DUCTS .....	3
AIR DUCT CONVERSION .....	6
EQUATIONS OF STATE .....	7
BLACK BODY THERMAL RADIATION .....	9
PSYCHROMETRIC PROPERTIES .....	11
HEAT EXCHANGERS .....	15
DECIBEL ADDITION AND SUBTRACTION .....	21
TEMPERATURE CONVERSIONS .....	22

## NOTICE

The program material contained herein is supplied without representation or warranty of any kind. Hewlett-Packard Company therefore assumes no responsibility and shall have no liability, consequential or otherwise, of any kind arising from the use of this program material or any part thereof.

OVERALL HEAT TRANSFER  
COEFFICIENTS  
PROGRAM REGISTERS NEEDED: 16

HEWLETT PACKARD  
SOLUTION BOOK:  
HEAT VENT & A/C

ROW 1 (1 - 4)



ROW 2 (5 - 7)



ROW 3 (7 - 14)



ROW 4 (14 - 20)



ROW 5 (21 - 26)



ROW 6 (26 - 33)



ROW 7 (33 - 40)



ROW 8 (41 - 48)



ROW 9 (48 - 50)



INSULATION BREAK EVEN ANALYSIS

PROGRAM REGISTERS NEEDED: 29

HEWLETT PACKARD  
SOLUTION BOOK:  
HEAT VENT & A/C

ROW 1 (1 - 5)



ROW 2 (5 - 8)



ROW 3 (8 - 11)



ROW 4 (11 - 13)



ROW 5 (14 - 19)



ROW 6 (20 - 24)



ROW 7 (25 - 36)



ROW 8 (37 - 46)



ROW 9 (47 - 57)



ROW 10 (58 - 63)



ROW 11 (64 - 74)



ROW 12 (74 - 79)




ROW 13 (79 - 85)



ROW 14 (86 - 93)



ROW 15 (93 - 98)




ROW 16 (99 - 99)



AIR FLOW IN CIRCULAR DUCTS  
PROGRAM REGISTERS NEEDED: 90

HEWLETT PACKARD  
SOLUTION BOOK:  
HEAT VENT & A/C



ROW 19 (87 - 92)



ROW 20 (92 - 97)



ROW 21 (98 - 105)



ROW 22 (105 - 108)



ROW 23 (109 - 112)



ROW 24 (112 - 117)



ROW 25 (118 - 122)



ROW 26 (123 - 125)



ROW 27 (126 - 129)



ROW 28 (129 - 132)



ROW 29 (132 - 136)



ROW 30 (137 - 143)



ROW 31 (144 - 152)



ROW 32 (153 - 163)



ROW 33 (164 - 169)



ROW 34 (170 - 179)




ROW 35 (180 - 188)



ROW 36 (189 - 197)



ROW 37 (198 - 210)



ROW 38 (211 - 222)



ROW 39 (223 - 231)



ROW 40 (232 - 242)



ROW 41 (243 - 250)



ROW 42 (250 - 252)



ROW 43 (252 - 259)



ROW 44 (260 - 269)



ROW 45 (270 - 274)




ROW 46 (275 - 280)



ROW 47 (281 - 288)



ROW 48 (289 - 293)



ROW 49 (294 - 295)



AIR DUCT CONVERSION

PROGRAM REGISTERS NEEDED: 33

HEWLETT PACKARD  
SOLUTION BOOK:  
HEAT VENT & A/C

ROW 1 (1 - 3)



ROW 2 (4 - 9)



ROW 3 (9 - 18)



ROW 4 (19 - 27)



ROW 5 (27 - 29)



ROW 6 (29 - 36)



ROW 7 (36 - 44)



ROW 8 (45 - 54)



ROW 9 (54 - 65)



ROW 10 (65 - 71)



ROW 11 (71 - 77)



ROW 12 (78 - 88)



ROW 13 (88 - 96)



ROW 14 (96 - 101)



ROW 15 (101 - 106)



ROW 16 (107 - 114)



ROW 17 (115 - 120)



ROW 18 (120 - 123)



EQUATIONS OF STATE

PROGRAM REGISTERS NEEDED: 47

HEWLETT PACKARD  
SOLUTION BOOK:  
HEAT VENT & A/C

ROW 1 (1 - 5)



ROW 2 (5 - 10)



ROW 3 (11 - 17)



ROW 4 (18 - 24)



ROW 5 (25 - 30)



ROW 6 (30 - 37)



ROW 7 (38 - 47)



ROW 8 (48 - 55)



ROW 9 (55 - 65)



ROW 10 (66 - 73)



ROW 11 (73 - 79)



ROW 12 (80 - 91)



ROW 13 (91 - 98)



ROW 14 (98 - 108)



ROW 15 (109 - 121)



ROW 16 (122 - 130)



ROW 17 (130 - 138)



ROW 18 (139 - 151)



ROW 19 (152 - 164)



ROW 20 (165 - 177)



ROW 21 (178 - 190)



ROW 22 (191 - 202)



ROW 23 (203 - 210)



ROW 24 (211 - 222)



ROW 25 (222 - 230)



ROW 26 (230 - 230)



BLACK BODY THERMAL RADIATION  
PROGRAM REGISTERS NEEDED: 50

HEWLETT PACKARD  
SOLUTION BOOK:  
HEAT VENT & A/C


ROW 1 (1 - 4)



ROW 2 (4 - 10)



ROW 3 (10 - 13)



ROW 4 (13 - 17)



ROW 5 (17 - 20)



ROW 6 (20 - 23)



ROW 7 (23 - 27)



ROW 8 (27 - 30)



ROW 9 (30 - 33)



ROW 10 (33 - 36)



ROW 11 (36 - 42)



ROW 12 (42 - 49)



ROW 13 (49 - 52)



ROW 14 (53 - 58)



ROW 15 (58 - 61)



ROW 16 (62 - 74)



ROW 17 (75 - 82)



ROW 18 (83 - 94)



ROW 19 (95 - 107)



ROW 20 (108 - 120)



ROW 21 (121 - 131)



ROW 22 (131 - 140)



ROW 23 (141 - 146)



ROW 24 (146 - 149)



ROW 25 (149 - 157)



ROW 26 (158 - 167)




ROW 27 (167 - 170)



PSYCHROMETRIC PROPERTIES  
PROGRAM REGISTERS NEEDED: 129

HEWLETT PACKARD  
SOLUTION BOOK:  
HEAT VENT & A/C




PSYCHROMETRIC PROPERTIES

HEWLETT PACKARD  
SOLUTION BOOK:  
HEAT VENT & A/C

ROW 19 (86 - 91)




ROW 20 (91 - 97)



ROW 21 (98 - 106)



ROW 22 (107 - 112)



ROW 23 (113 - 120)



ROW 24 (121 - 126)



ROW 25 (126 - 130)



ROW 26 (131 - 138)



ROW 27 (139 - 143)



ROW 28 (143 - 151)



ROW 29 (151 - 153)



ROW 30 (153 - 161)



ROW 31 (162 - 170)



ROW 32 (170 - 177)



ROW 33 (177 - 184)



ROW 34 (184 - 186)



ROW 35 (186 - 191)




ROW 36 (191 - 193)



ROW 37 (194 - 198)



ROW 38 (198 - 204)



ROW 39 (204 - 206)



ROW 40 (206 - 211)



ROW 41 (211 - 215)



ROW 42 (216 - 220)



ROW 43 (220 - 228)



ROW 44 (228 - 231)



ROW 45 (232 - 236)



ROW 46 (236 - 241)



ROW 47 (241 - 243)



ROW 48 (243 - 249)



ROW 49 (249 - 254)



ROW 50 (254 - 256)



ROW 51 (256 - 261)



ROW 52 (261 - 264)



ROW 53 (265 - 267)



ROW 54 (267 - 275)



ROW 55 (276 - 286)



ROW 56 (286 - 290)



ROW 57 (291 - 298)



ROW 58 (299 - 305)



ROW 59 (305 - 310)



ROW 60 (311 - 314)



ROW 61 (315 - 322)



ROW 62 (323 - 328)



ROW 63 (328 - 332)



ROW 64 (333 - 336)



ROW 65 (337 - 344)



ROW 66 (344 - 349)



ROW 67 (349 - 356)



ROW 68 (356 - 363)



ROW 69 (364 - 369)



ROW 70 (369 - 369)



HEAT EXCHANGERS

PROGRAM REGISTERS NEEDED: 67

HEWLETT PACKARD  
SOLUTION BOOK:  
HEAT VENT & A/C

ROW 1 (1 - 4)



ROW 2 (4 - 6)



ROW 3 (6 - 11)



ROW 4 (11 - 14)



ROW 5 (15 - 20)



ROW 6 (20 - 26)



ROW 7 (27 - 33)



ROW 8 (33 - 34)



ROW 9 (35 - 40)



ROW 10 (40 - 44)



ROW 11 (45 - 51)



ROW 12 (51 - 57)



ROW 13 (57 - 64)



ROW 14 (64 - 70)



ROW 15 (70 - 75)



ROW 16 (76 - 81)



ROW 17 (81 - 88)



ROW 18 (88 - 94)



ROW 19 (94 - 102)



ROW 20 (103 - 110)



ROW 21 (111 - 119)



ROW 22 (119 - 129)



ROW 23 (130 - 137)



ROW 24 (138 - 148)



ROW 25 (149 - 161)



ROW 26 (162 - 168)



ROW 27 (168 - 175)



ROW 28 (176 - 183)



ROW 29 (184 - 196)



ROW 30 (197 - 203)



ROW 31 (204 - 206)



ROW 32 (206 - 210)



ROW 33 (211 - 216)



ROW 34 (217 - 224)



ROW 35 (225 - 230)



ROW 36 (231 - 234)



HEAT EXCHANGERS:  
PARALLEL FLOW SUBROUTINE  
PROGRAM REGISTERS NEEDED: 8

HEWLETT PACKARD  
SOLUTION BOOK:  
HEAT VENT & A/C

ROW 1 (1 - 6)



ROW 2 (7 - 19)



ROW 3 (19 - 25)



ROW 4 (26 - 36)



HEAT EXCHANGERS:  
COUNTER FLOW SUBROUTINE  
PROGRAM REGISTERS NEEDED: 11

HEWLETT PACKARD  
SOLUTION BOOK:  
HEAT VENT & A/C

ROW 1 (1 - 6)



ROW 2 (7 - 18)



ROW 3 (19 - 28)



ROW 4 (28 - 37)



ROW 5 (38 - 49)



ROW 6 (50 - 59)




HEAT EXCHANGERS:  
PARALLEL-COUNTER FLOW SUBR.  
PROGRAM REGISTERS NEEDED: 12

HEWLETT PACKARD  
SOLUTION BOOK:  
HEAT VENT & A/C

ROW 1 (1 - 4)



ROW 2 (5 - 17)



ROW 3 (18 - 26)



ROW 4 (26 - 34)



ROW 5 (35 - 47)



ROW 6 (48 - 60)



ROW 7 (61 - 62)



HEAT EXCHANGERS:  
CROSS FLOW SUBROUTINE  
PROGRAM REGISTERS NEEDED: 14

HEWLETT PACKARD  
SOLUTION BOOK:  
HEAT VENT & A/C

ROW 1 (1 - 5)



ROW 2 (6 - 14)



ROW 3 (14 - 22)



ROW 4 (22 - 30)



ROW 5 (30 - 35)



ROW 6 (35 - 44)



ROW 7 (45 - 57)



ROW 8 (57 - 57)



DECIBEL ADDITION AND  
SUBTRACTION  
PROGRAM REGISTERS NEEDED: 8

HEWLETT PACKARD  
SOLUTION BOOK:  
HEAT VENT & A/C

ROW 1 (1 - 4)



ROW 2 (5 - 9)



ROW 3 (10 - 16)



ROW 4 (17 - 26)



ROW 5 (26 - 26)



TEMPERATURE CONVERSION

PROGRAM REGISTERS NEEDED: 15

HEWLETT PACKARD  
SOLUTION BOOK:  
HEAT VENT & A/C

ROW 1 (1 - 5)



ROW 2 (5 - 7)



ROW 3 (8 - 12)



ROW 4 (12 - 16)



ROW 5 (17 - 23)



ROW 6 (23 - 28)



ROW 7 (29 - 33)



ROW 8 (33 - 37)



## **NOTES**

## **NOTES**

## **NOTES**



## **Hewlett-Packard Software**

In terms of power and flexibility, the problem-solving potential of the HP-41C programmable calculator is nearly limitless. And in order to see the practical side of this potential, HP has different types of software to help save you time and programming effort. Every one of our software solutions has been carefully selected to effectively increase your problem-solving potential. Chances are, we already have the solutions you're looking for.

### **Application Pacs**

To increase the versatility of your HP-41C, HP has an extensive library of "Application Pacs". These programs transform your HP-41C into a specialized calculator in seconds. Included in these pacs are detailed manuals with examples, miniature plug-in Application Modules, and keyboard overlays. Every Application Pac has been designed to extend the capabilities of the HP-41C.

You can choose from:

<b>Aviation</b>	<b>Structural Analysis</b>	<b>Home Management</b>
<b>Clinical Lab</b>	<b>Surveying</b>	<b>Machine Design</b>
<b>Circuit Analysis</b>	<b>Securities</b>	<b>Navigation</b>
<b>Financial Decisions</b>	<b>Statistics</b>	<b>Real Estate</b>
<b>Mathematics</b>	<b>Stress Analysis</b>	<b>Thermal and Transport Science</b>
	<b>Games</b>	

### **Users' Library**

The Users' Library provides the best programs from contributors and makes them available to you. By subscribing to the HP-41C Users' Library you'll have at your fingertips literally hundreds of different programs from many different application areas.

### **\* Users' Library Solutions Books**

Hewlett-Packard offers a wide selection of Solutions Books complete with user instructions, examples, and listings. These solution books will complement our other software offerings and provide you with a valuable tool for program solutions.

You can choose from:

<b>Business Stat/Marketing/Sales</b>	<b>Civil Engineering</b>
<b>Home Construction Estimating</b>	<b>Heating, Ventilating &amp; Air Conditioning</b>
<b>Lending, Saving and Leasing</b>	<b>Mechanical Engineering</b>
<b>Real Estate</b>	<b>Solar Engineering</b>
<b>Small Business</b>	<b>Calendars</b>
<b>Geometry</b>	<b>Cardiac/Pulmonary</b>
<b>High-Level Math</b>	<b>Chemistry</b>
<b>Test Statistics</b>	<b>Games</b>
<b>Antennas</b>	<b>Optometry I (General)</b>
<b>Chemical Engineering</b>	<b>Optometry II (Contact Lens)</b>
<b>Control Systems</b>	<b>Physics</b>
<b>Electrical Engineering</b>	<b>Surveying</b>
<b>Fluid Dynamics and Hydraulics</b>	

\* Some books require additional memory modules to accomodate all programs.

## **HEATING, VENTILATING & AIR CONDITIONING**

OVERALL HEAT TRANSFER COEFFICIENT  
INSULATION BREAK EVEN ANALYSIS  
AIR FLOW IN CIRCULAT DUCTS  
AIR DUCT CONVERSION  
EQUATIONS OF STATE  
BLACK BODY THERMAL RADIATION  
PSYCHROMETRIC PROPERTIES  
HEAT EXCHANGERS  
DECIBEL ADDITION AND SUBTRACTION  
TEMPERATURE CONVERSIONS

