Includes barcode for easy software entry. **HEWLETT-PACKARD HP-41 USERS' LIBRARY Time Module Solutions I**

For the HP 82182A Time Module



NOTICE

The program material contained herein is supplied without representation or warranty of any kind. Hewlett-Packard Company therefore assumes no responsibility and shall have no liability, consequential or otherwise, of any kind arising from the use of this program material or any part thereof.

INTRODUCTION

This HP-41C Solutions book was written to help you get the most from your calculator. The programs were chosen to provide useful calculations for many of the common problems encountered.

They will provide you with immediate capabilities in your everyday calculations and you will find them useful as guides to programming techniques for writing your own customized software. The comments on each program listing describe the approach used to reach the solution and help you follow the programmer's logic as you become and expert on your HP calculator.

KEYING A PROGRAM INTO THE HP-41C

There are several things that you should keep in mind while you are keying in programs from the program listings provided in this book. The output from the HP 82143A printer provides a convenient way of listing and an easily understood method of keying in programs without showing every keystroke. This type of output is what appears in this handbook. Once you understand the procedure for keying programs in from the printed listings, you will find this method simple and fast. Here is the procedure:

1. At the end of each program listing is a listing of status information required to properly execute that program. Included is the SIZE allocation required. Before you begin keying in the program, press **XEQ ALPHA** SIZE **ALPHA** and specify the allocation (three digits; e.g., 10 should be specified as 010).

Also included in the status information is the display format and status of flags important to the program. To ensure proper execution, check to see that the display status of the HP-41C is set as specified and check to see that all applicable flags are set or clear as specified.

- 2. Set the HP-41C to PRGM mode (press the **PRGM** key) and press **GTO** • to prepare the calculator for the new program.
- 3. Begin keying in the program. Following is a list of hints that will help you when you key in your programs from the program listings in this handbook.
 - a. When you see " (quote marks) around a character or group of characters in the program listing, those characters are ALPHA. To key them in, simply press **ALPHA**, key in the characters, then press **ALPHA** again. So "SAMPLE" would be keyed in as **ALPHA** "SAMPLE" (ALPHA).
 - b. The diamond in front of each LBL instruction is only a visual aid to help you locate labels in the program listings. When you key in a program, ignore the diamond.
 - c. The printer indication of divide sign is /. When you see / in the program listing, press +.
 - d. The printer indication of the multiply sign is \ddagger . When you see \ddagger in the program listing, press \Join .
 - e. The H character in the program listing is an indication of the **APPEND** function. When you see H, press **APPEND** in ALPHA mode (press **A** and the K key).
 - f. All operations requiring register addresses accept those addresses in these forms:

nn (a two-digit number) IND nn (INDIRECT: , followed fy a two-digit number) X, Y, Z, T, or L (a STACK address: followed by X, Y, Z, T, or L) IND X, Y, Z, T or L (INDIRECT stack: followed by X, Y, Z, T, or L)

Indirect addresses are specified by pressing and then the indirect address. Stack addresses are specified by pressing • followed by X, Y, Z, T, or L. Indirect stack addresses are specified by pressing • and X, Y, Z, T, or L.

Printer Listing

Keystrokes

Display

01+LBL "SAM PLE" A2 "THIS IS	LBL (ALPHA) SAMPLE (ALPHA) (ALPHA) THIS IS A (ALPHA)	01 LBL ^T SAMPLE 02 ^T THIS IS A
A "	ALPHA APPEND SAMPLE	03 [⊤] ⊢ SAMPLE
03 "HSAMPLE "	AVIEW ALPHA	04 AVIEW
04 AVIEW	6	05 6
05 6	ENTER+	06 ENTER 1
06 ENTERT 07 -2	2 (CHS)	07 –2
08 /	÷	08 /
09 ABS 10 STO IND	XEQ ALPHA ABS ALPHA	09 ABS
L	STO 🗖 💿 L	10 STO IND L
11 "R3="	$\begin{bmatrix} ALPHA \end{bmatrix} B3 = \begin{bmatrix} ARCL \end{bmatrix} 03$	11 ^T R3=
12 HRUL 03 13 OVIEW		12 ARCL 03
14 RTN		13 AVIEW
	RTN	14 RTN

TABLE OF CONTENTS

1.	APPOINTMENT CALENDAR , Allows you to create a list of time-based appointments and reminders that can be copied to mass storage, edited, added to and printed-out as an organized memo calendar.	•	1
2.	WORLD TIME CONVERTER	•	15
3.	EXERCISE MONITOR A complete program for runners including timed courses, pulse counts, and splits.	•	20
4.	AUTOMOBILE TRIP COMPUTER AND SPEED CALIBRATION . Performs various timing functions on automobile trips.	•	31
5.	FOUR-CHANNEL CONTROLLER	•	48
6.	LOGBOOK	•	62
7.	"PLAYBACK" PROGRAMMABLE TIMER	•	73
8.	RANDOM SEED GENERATOR May be used with any random number generator to provide an automatic, unpredictable seed.	•	84

This book was developed and coded under consultation from Cary E. Reinstein

PROGRAM DESCRIPTION

APPOINTMENT CALENDAR

"Appointment Calendar" allows you to create in calculator memory a list of timebased appointments and reminders. This list can be copied to mass storage, edited, added to, and can be printed out as an organized memo calendar. Entries may be added or edited at any time and may be viewed, printed and/or set as alarms.

Appointment lists may be any length that is practical for the amount of calculator memory available. Each appointment requires 7 data registers and is composed of a date, time, sorting value (invisible to the user), and ALPHA message. Once a list has been created, it may be modified at any time using the routine labelled "B" (key [1/X] in USER mode) and added to using routine "a" ([shift] [Σ +] in USER MODE). Appointments cannot be deleted, but may be written over.

All appointments that have associated times will be set as alarms by the alarm setting routine (labelled "E", key [LN] in USER mode). Appointments with associated times of \emptyset are considered to be "REMINDERS" and are not set as alarms. Since the time module considers the time \emptyset to be midnight, appointments cannot be set for this time. This is no inconvenience since appointments can be set to within one-tenth of a second of midnight and still be set as alarms.

"Appointment Calendar" includes three versions of the "LOAD" and "STORE" routines in order to be compatible with the card reader, cassette drive and extended memory. The appropriate version for your system configuration should be the only version loaded. These routines can be called from the "APPT" program, but if the SIZE function must be performed while in these subroutines, control will not be passed back to "APPT".

The "STORE" routine creates and records the appointment list on a mass storage device.

The "LOAD" routine is used to download data files from the mass storage device to the HP-41's data registers. The cassette version of the routine checks for the necessary SIZE setting and prompts you if the current setting is inadequate. The card reader version assumes the proper SIZE is set. The extended functions version attempts to reset the SIZE if it is not large enough and will generate an error message if there is not enough room in calculator memory for both the programs and required data.

OPERATING LIMITS AND WARNINGS

At least six unused registers must be allowed in program memory for each alarm that is to be set. Fewer registers are required for alarms with fewer than 24-character messages. See the HP 82182A Time Module Owner's Manual for storage requirements of the various alarm types.

Anytime the calculator prompts you for a change in the SIZE setting, be sure you do not alter the stack in any way, or the appointments may be stored in unpredictable places.

SAMPLE PROBLEM

Appointments and reminders for the fourth week of January, 1983.

January	28,	5	p.m.	NICKS BIRTHDAY PRESENT
January	28,	9:15	a.m.	DENTIST APPT
January	28,	11:45	a.m.	LUNCH WITH JIM B.
January	29			MAKE LUNCH RES/NICK
January	29,	2	p.m.	RENEW LICENSE
January	30			NICK 5 TODAY

This example assumes a SIZE setting of less than 49 registers, MDY mode, flags 28 and 29 set and that no assignments have been made to the referenced keys.

DISPLAY	INPUT	FUNCTION
		[XEQ] "APPT"
APPTS	6	[R/S]
SIZE>=49.		[XEQ] "SIZE" 049
48.		[R/S]
DATE? ()/()	1.281983	[R/S]
TIME?	-5	[R/S]
MSSG?	NICKS BIRTHDAY PRESENT	[R/S]
DATE? 01/28		[R/S]
TIME?	9.15	[R/S]
MSSG?	DENTIST APPT	[R/S]
DATE? 01/28		[R/S]
TIME?	11.45	[R/S]
MSSG?	LUNCH WITH JIM B.	[R/S]
DATE? 01/29	1.291983	[R/S]
TIME?		[R/S]
MSSG?	MAKE LUNCH RES/NICK	[R/S]
DATE? 01/29		[R/S]
TIME?	-2	[R/S]
MSSG?	RENEW LICENSE	[R/S]
DATE? 01/30	1.301983	[R/S]
TIME?		[R/S]
MSSG?	NICK 5 TODAY	[R/S]
0.00		[C] Output calendar.
FRIDAY		[R/S]*

DISPLAY	INPUT	FUNCTION	
01/28/83		[R/S]*	
9:15:00 AM		[R/S]*	
DENTIST APPT		[R/S]*	
11:45:00 AM		[R/S]*	
LUNCH WITH JIM B.		[R/S]*	
5:00:00 PM		[R/S]*	
NICKS BIRTHDAY PRESENT		[R/S]*	
SATURDAY		[R/S]*	
01/29/83		[R/S]*	
REMINDER		[R/S]*	
MAKE LUNCH RES/NICK		[R/S]*	
2:00:00 PM		[R/S]*	
RENEW LICENSE		[R/S]*	
SUNDAY		[R/S]*	
01/30/83		[R/S]*	
REMINDER		[R/S]*	
NICK 5 TODAY		[R/S]*	
-1.0000		[R/S]*	
* [R/S] is not required if	a printer is attached		

<u>STATUS</u>			
SIZE	:	appointment * 7 + 7	
FIX	:	2, 4	
TOTAL PROGRAM BYTES	:	APPT LOAD/STORE (card) (cassette) (x memory)	605 27 105 73

REQUIRED PERIPHERALS

HP 82182A Time Module 1 HP 82106A Memory Module (minimum) Optional: HP 82104A Card Reader <u>OR</u> HP 82160A HP-IL Module <u>AND</u> HP 82161A Digital Cassette Drive <u>OR</u> HP 82180A Extended Functions/Memory Module

DATA REGISTE	RS
R00	Index for "A", "a", and "B"
R01	Last appointment date input
R02	1.01198 - Used to generate the sorting values
R03	Index for "C"
R04	Current earliest appoint in "C"'s sort
R05	Index constant used to refresh RO3 in "C" Also used as index for "E"
R06	Last date output by "C"
R07	The remaining registers are grouped in blocks of 6 and are the appointments Where: R(0+7n) = Date R(1+7n) = Time R(2+7n) = Sort value R(3+7n) to R(6+7n) = Message (24 characters)
	for the nth appointment

FLAGS USED			
00	Set	:	Edit mode
05	Clear Set	:	All other modes Single appointment - used by "C"
	Clear	:	All other conditions
12	Set	:	Print double-wide
	Clear	:	Print single-wide
21	Set	:	Enable printer
	Clear	:	Disable printer
25	Set	:	Error detected
	Clear	:	No error detected
27	Set	:	USER mode on
	Clear	:	USER mode off

FUNCTION LABELS	
Labe1	Function
"APPT"	Main global label
"A"	Establish appointment list
"a"	Add appointments to list
"B"	Edit current list
"C"	Memo calendar output
"D"	XEQ "STORE"
"d"	XEQ "LOAD"
"E"	Set alarms in current list

				SIZE: 7n + 7
STEP	INSTRUCTIONS	INPUT	FUNCTION	DISPLAY
1	Load "APPT".		[GTO]	PACKING
2	Load one of the versions of the "LOAD"			
	program, if desired.		[GTO]	PACKING
3	Set any desired modes. Display mode is			
	modified by the program and, consequently,			
	any mode the user has selected will not			
	be preserved.			
4	Initialize the program.		[XEQ]"APPT"	APPTS?
5	Input the number of appointments you plan			
	to store. No input or an input of zero			
	causes this prompt to be repeated.	#appts.	[R/S]	SIZE>=()
6	This prompt will only be generated if the			
	currently allocated SIZE is too small. If			
	the prompt does not appear, go to step 7.			
6a	Correct the SIZE.		[XEQ]"SIZE"nnn	
	Note: Do not modify the stack at this			
	time or errors may result.			
6b	Continue.		[R/S]	DATE? ()
7	The prompt "DATE?" is followed initially by			
	today's date in the current MDY or DMY			
	format. All later occurrences of this			
	prompt will contain the last input date			
	rather than today's date. Input the date			
	of the first appointment, be sure to			
	include the year. Omission of the date			
	will cause the use of the displayed date			
	as default. Dates are restricted to			

5

STEP	INSTRUCTIONS	INPUT	FUNCTION	DISPLAY
	those later than January 1, 1980.	date	[R/S]	TIME?
8	Input the time of the appointment. Input			
	time in the same way that you normally			
	would when using the HP 82182 Time			
	Module. No input or an input of zero			
	signifies a "REMINDER" with no associated			
	time. "REMINDER"'s are not set as alarms.			
	The time of midnight cannot be input as \emptyset ,			
	but can be input as a time arbitrarily			
	close to 12 a.m. (i.e. 11:59:59.99 p.m.).	time	[R/S]	MSSG?
9	Input the message you wish, up to 24			
	characters. Keep in mind that all 24			
	characters will be output by the calendar			
	output portion (label "C") of this program,			
	but if set as an alarm only the first 12			
	characters will be displayed as the alarm			
	is activated.	message	[R/S]	DATE? ()
10	If more appointments remain to be keyed			
	in, go to step 7. Otherwise, input			
	terminates with a display of Ø.ØØ.			
11	To Add Appointments:		[shift][a]	APPTS ADDED?
	Note: This cannot be done unless steps			
	1 - 1Ø have been performed.			
12	Key in the number of appointments you wish			
	to add to the current list. No input or			
	an input of zero causes this prompt to			
	be repeated.	#appts. more	[R/S]	SIZE>=()

STEP	INSTRUCTIONS	INPUT	FUNCTION	DISPLAY
13	Go to step 6.			
14	To Edit the current list:		[B]	()
	Note: This cannot be performed if steps			
	3 - 1Ø have not previously been performed.			
15	The date of the appointment is displayed			
	first. A new date may be entered or the			
	displayed date may be left as is. If the			
	input value is not a proper date, this			
	prompt will be repeated.	date	[R/S]	()
16	The time of the appointment is displayed			
	next. If the appointment was stored with			
	no time, "REMINDER" will be displayed. A			
	new time (or no time) may be input now or			
	the value left as it is. No error check			
	is made on this value.	time	[R/S]	()
17	The appointment's message is displayed next			
	The message may be altered, or left alone.	message	[R/S]	
18	If there are more appointments in the			
	current list, go to step 15, otherwise			
	the program halts here.			
19	To print out a calendar of the current			
	appointment list.		[C]	
	The current appointment list is printed out			
	in chronological order. Different dates			
	are separated by headings of date and			
	day-of-week. All appointments on a			
	certain date are listed by time and			

STEP	INSTRUCTIONS	INPUT	FUNCTION	DISPLAY
	message. "REMINDERS" are listed as such.			
20	To set all alarms in the current			
	appointment list. All timed appointments			
	will be set as alarms.		[E]	
21	To store the current appointment list			
	on mass storage:		[D]	
22a	If the cassette drive or extended			
	functions/memory version of "LOAD" is			
	in memory:			FL NAME?
	Key in the file name - 6 characters max.	name	[R/S]	
22b	If the card reader version of "LOAD"			
	is in memory:			RDY nn OF mm
	Load the proper blank cards.			
23	To recall an appointment list from			
	mass storage:		[d]	
24a	If the cassette drive or extended			
	functions/memory version of "LOAD"			
	is in memory:			FL NAME?
	Key in the file name.	name	[R/S]	SIZE>=()
	If the number of allocated data registers			
	is inadequate, alter the SIZE setting			
	and procede.		[XEQ]"SIZE"nnn	
24b	If the card reader version of "LOAD"			
	is in memory:			CARD
	Load the data cards. Note that the program			
	assumes that you have adequate data			
	space allocated.			

STEP	INSTRUCTIONS	INPUT	FUNCTION	DISPLAY
25	To reset the appointment list:		[A]	APPTS?
	All previously stored appointments are			
	lost (except those that have been saved			
	on mass storage).			
	Go to step 5 of these instructions.			

01+LBL "APP	•	49 ISG 00	•
Τ"		50 RCL IND	Last time
02 SF 21	Enable printer and	00	
03 SF 27	USER mode	51 FC? 00	Not EDIT mode?
04+LBL H	Set up initial list	52 CLX	
05 CF 00	Not EDIT mode	53 FC? 00	
06 CLX		54 GTO 09	
07 "APPTS?"	No. of appointments	55 CLA	
08 PROMPT		56 ATIME	Last time
09 X=0?	No input?	57 X=0?	
10 GTO H		58 "REMINDE	No time
11 7		R"	
12 *		59+LBL 09	
13 7		60 PROMPT	Now time
14 +		61 STO IND	
15 XEQ 99	Check SIZE	00	
16 FC?C 25	Bad SIZE?	62 X>0?	AM?
17 PROMPT		63 GTO 10	
18.1	Set up index	64 ABS	
19 %		65 12	
20 7		66 +	
21 +		67+LBL 10	
22 STO 00		68 1 E2	
23 DATE	Default date	69 /	
24 STO 01		70 RCL 02	Jan. 1, 1980
25 1.01198	Jan. 1, 1980	71 RCL 01	Date
26 STO 02		72 DDAYS	
27+LBL 20	Input loop	73 +	
28 "DATE? "		74 ISG 00	
29 RCL 01	Default	75 STO IND	Sort value
30 FS? 00	EDIT mode?	0 0	
31 RCL IND		76 "MSSG?"	
00		77 CF 21	
32 FS? 00		78 FC? 00	Not EDIT mode?
33 CLA		79 AVIEW	Display prompt
34 FIX 2		80 CLA	
35 FS? 00		81 FC? 00	Not EDIT mode?
36 FIX 4		82 GTO 08	
37 ADATE	Format prompt	83 ISG 00	
38 PROMPT		84 ARCL IND	Last message
39 RCL 02	Test for valid date	00	
40 X<>Y		85 ISG 00	
41 SF 25		86 ARCL IND	
42 DDAYS		00	
43 FC?C 25	Not valid?	87 ISG 00	
44 GTO 20		88 ARCL IND	
45 LASTX	Get date	00	
46 STO IND		89 ISG 00	
00		90 ARCL IND	
47 STO 01	New default	00	
48 "TIME?"		914	Decrement index

	•	
92 ST- 00	141 FIX 4	
93+1 BL 08	. 142 SF 00	
	for message 143 GTO 20	
		Goto input loop
93 310F		Calendar output
96 HUFF	145 RUL 00	
97 4	146 FRU	
98+LBL 07	ew message 147 16	
99 ISG 00	148 +	
100 ASTO IND	149 7 E-5	
00	150 +	
101 ASHE	151 STO 05	New index
102 DSE X	152 INT	
107 CTO 07	157 LOSTX	
103 610 07	1J3 LH31A	
104 ISG 00 Nexta	opointment 104 FRU	
105 GTO 20	155 1 E3	
106 CF 00	156 *	
107 RTN	157 INT	
108+LBL a	158 CF 05	
	159 X <y?< td=""><td>Oulu and appointment?</td></y?<>	Oulu and appointment?
110 DEPTS O		Only one appointment?
		One appointment
		Last date used
112 PRUMPI More?	163+LBL 30	Sort loop
113 X=0? Invalid	input? 164 9	First sort number
114 GTO a	165 STO 04	location
115 7	166 FS? 05	Only one appointment?
116 *	167 GTO 36	,
117 RCL 00	168 RCL 05	
118 FPC	169 510 03	
110 1 57	170 PCL 12	Refresh index
117 I E3	170 KUL 12	Second sort number
120 *	ITIVLBL 31	Search loop
121 SIU 00 Last re	aister used 172 RUL IND	Last sort number
122 +	04	
123 1	173 X<=0?	Already used?
124 +	174 GTO 34	
125 XEQ 99 Obush	175 RCL IND	Novt cort number
126 EC2C 25	ara 03	Next solt humber
127 PROMPT	176 X(=0?	
120 1	177 CTO 33	Already used?
120 .1	170 2/22	
		X >= Y?
130 1	179 X=Y?	
131 +	180 GIU 33	
132 ST+ 00 New in	dex 181+LBL 34	New last number
133 GTO 20 Goto in	182 RCL 03	
134 RTN 0000	183 STO 04	
135+LBL B	. 184+LBL 33	Nové contactor bon
136 RCL 00 EDIT		Next sort number
137 FRC	186 GTO 31	
170 7	107 DCI TND	
130 (IOT KUL IND	
137 +		
140 STO 00 Reset i	ndex 188 X>0?	Not used?

		· · · · ·	
189 GTO 36		236 ATIME	
190+LBL 38	Re-establish sort	237 X=0?	
191 RCL 05	numbers as positive	238 "REMINDE	No time
192 FC? 05		R"	
193 STO 04		239 AVIEW	
194 -1		240 CLX	
195 ST* 09		241 2	
196+LBL 37		241 2	
197 ST* IND		242 7	
04		243 LLH	Massage
100 TCC 04		244 HRUL IND	iviessage
178 136 04		X	
199 GIU 37		245 1	
200 CLD		246 +	
201 RIN		247 ARCL IND	
202+LBL 36		×	
203 -1	Flag the number as	248 1	
204 ST* IND	used	249 +	
04		250 ARCL IND	
205 RCL 04	Index of appointments	×	
206 INT		251 1	
207 2		252 +	
208 -		253 ARCI IND	
209 RCL 06	atch tec l	x x	
210 RCL IND		254 OVIEN	
V KOE INS	I his date	254 AVILM 255 EC2 05	One appointment
211 GTO 06		2JJ F3: 0J 25/ CT0 70	
212 2-22		236 610 38	
212 0-1:	Same?	257 610 30	Davis
213 610 35		258+LBL 00	Days
214 SF 21		259 "SUN"	
215 ENTERT		260 RTN	
216 DUW	New day	261 + LBL 01	
217 XEQ IND		262 "MON"	
×		263 RTN	
218 "FDAY"		264+LBL 02	
219 ADV		265 "TUES"	
220 SF 12		266 RTN	
221 AVIEW	1	267+LBL 03	
222 RDN		268 "WEDNES"	
223 CLA		269 RTN	
224 FIX 4		270+LBL 04	
225 ADATE		271 "THURS"	
226 AVIEW	New date	272 RTN	
227+LBL 35	Ì	273+1 BL Ø5	
228 ANV		273 "EDI"	
229 CE 12		274 FRI 275 PTN	
230 010		ZELJ KIN 976aldi qe	
271 DCI 04		210VLDL 00 977 #COTUD#	
231 KUL 04 373 INT		277 "SHIUK" 270 DTH	
232 1111		ZIN KIN	Set clorme
233 1		279+LBL E	Set alarms
234 - 275 DOL IND		280 RCL 00	
235 KUL INU	Appointment time	281 FRC	
Х			

282	7	
283	+	
284	STO 05	Now Index
285	♦ BL 50	New Index
200	CLST	Alarm set loop
200		
287		
288	RUL IND	Date
05		
289	ISG 05	
290	RCL IND	Time
05		11110
291	ISG 05	Cant value
292	ISG 05	Sort value
297		
275	HKCE IND	Message
204	100 05	
294	156 05	
295	HRUL IND	
05		
296	ISG Ø5	
297	ARCL IND	
05		
298	ISG 05	
299	ARCL IND	
05		
700	X≠02	No time?
701		
301		Set alarm
302	136 03	
303	610 30	Loop
304	RIN	
305	◆LBL D	XEQ 'STORE'
306	CF 25	
307	XEQ "STO	
RE "		
308	RTN	
309	♦LBL d	
310	CE 25	AEG LOAD
311	XF0 "I 00	
	ALG LON	
710	рты	
312		
313	*LBL 77	SIZE test
314	"SIZE>="	
315	FIX Ø	
316	ARCL X	Desired SIZE
317	1	
318	-	
319	SF 25	
320	STO IND	Highart register
x	- ·	ingnest register
321	END	

Cassette Version		X Function/Memory Versi	on
01+LBL "LOA	"LOAD" routine	01+LBL "LOA	"LOAD" routine
D		D	
02 XEQ 20	"FL NAME?" routine	02 XEQ 00	"FL NAME?" routine
03 CLX		03 SIZE?	Allocated registers
04 SEEKR	Find file	04 FLSIZE	File size
05 READRX	Read register zero	05 CF 25	Allow errors
06 XEQ 21	Find file size	06 X>Y?	Need more room?
07 ASTU Y	Save file name	07 PSIZE	Allocate registers
08 FIX 0		US CLX	
09 "SIZE)="		US SEEKPI	Position to file
10 HRUL X	Desired SIZE		Load file
17 65 25			"STORE" routine
13 3F 23 14 9TO IND		17 VEO 00	
	Highest register		"FL NAME?" routine
A 15 ECOC 25		14 KCL 00	Index
10 FC(C 20 12 DDOMDT	Bad SIZE	12 1 57	Determine necessary
17 010		17 *	file size
18 OPCI Y	File name	18 1	
		19 +	
20 SEEKR	Beset file to B00	20 CE 25	Allow errors
21 READR	Read file contents	21 CRFLD	Create the data file
22 RTN		22 RCL 00	Index
23+LBL "STO	"STORE" routine	23 FRC	
RE"		24 SEEKPT	Position to the file
24 XEQ 20	"FL NAME?" routine	25 SAVERX	Store the registers
25 XEQ 21	Find file size rad.	26 RTN	
26 CF 25	Allow errors	27+LBL 00	"FL NAME?" routine
27 CREATE		28 "FL NAME	
28 0		?"	
29 SEEKR	Position to file	29 AON	
30 RCL 00	Index	30 STOP	
31 FRC		31 AOFF	
32 WRTRX	Write list	32 END	
33 RTN			
34+LBL 20	Name prompt routine		
35 "FL NHME			
?" 		Card Reader Version	
36 HUN		Card Reader Verston	_
37 STUP 70 00EE		01+LBL "LOA	"I OAD" routine
30 HUFF 79 DTN		D	
32 KIN 49≜I BI 21	Desired file size	02 RDTA	Read data
41 RCI 00	from index	03 RTN	
42 FRC		U4+LBL "STO	"STORE" routine
43 1 F3			
44 *		00 KUL 00 04 EDC	Index
45 1		00 FKU 07 UDTOV	
46 +		00 FND	Write registers
47 END			

PROGRAM DESCRIPTION

WORLD TIME CONVERTER

While it is useful to know the time in a foreign city, that time will not always correspond to business hours or other convenient calling or arrival time. "World Time Converter" is a programmable alarm clock that displays the time and date of a foreign city and can set an alarm that corresponds to a time in the destination city's time zone.

"WTIME" does a straightforward time conversion by adding the time differences between each city of interest and Greenwich time. Each location must be keyed into program memory by the user so as to eliminate the need for a large data base of locations and time offsets.

"T2" prompts for the time of interest in the destination city, and then sets an alarm that is activated in the home city's time when the desired time in the destination city is reached. The name of the city is flashed as a message.

City	Offset	City	Offset	City	Offset
Alexandria Amsterdam Athens Auckland Baghdad Bangkok Beijing Belfast Berlin Bogota Bombay Brussels Bucharest Budapest Buenos Aires Calcutta Capetown Caracas Copenhagen Dacca Delhi Djakarta Dublin	2 1 2 0 3 7 8 0 1 -5 5.3 1 2 1 -3 5.3 2 -4 1 6 5.3 7 0	Gdansk Geneva Haifa Havana Helsinki Hong Kong Istanbul Jerusalem Johannesburg Karachi Kyoto Leningrad Lima Lisbon London Madrid Manila Melbourne Mexico City Montevideo Montreal Moscow	1 -5 2 8 2 2 3 5 9 3 5 9 3 5 1 0 1 8 0 -6 -3 -5 3 9	Oslo Paris Prague Rangoon Rio de Janeiro Rome Saigon Santiago, Chile Seoul Shanghai Singapore Stockholm Sydney Teheran Tel Aviv Tokyo Vancouver, BC Vienna Warsaw Wellington Yokohama Zurich	$ \begin{array}{c} 1\\ 1\\ -3\\ -3\\ -3\\ -3\\ -3\\ -3\\ -3\\ -4\\ -4\\ -4\\ -9\\ -8\\ -4\\ -4\\ -9\\ -8\\ -1\\ -1\\ -2\\ -8\\ -8\\ -1\\ -2\\ -8\\ -8\\ -1\\ -2\\ -8\\ -8\\ -1\\ -2\\ -8\\ -8\\ -1\\ -2\\ -8\\ -8\\ -1\\ -2\\ -8\\ -8\\ -8\\ -1\\ -2\\ -8\\ -8\\ -8\\ -8\\ -8\\ -8\\ -8\\ -8\\ -8\\ -8$
North American Time Zones:					
Atlantic Eastern Central	-4 -5 -6	Mountain Pacific Yukon	-7 -8 -9	Alaska-Hawaii Bering	-10 -11

OPERATING LIMITS AND WARNINGS

The time adjustment chart does not take into account Daylight Savings Time or any other adjustments due to local laws and ordinances. These must be known and input by the user of the program. If your appointment time is critical, please verify the offsets in this against some standard reference source for correct time.

SAMPLE PROBLEM

An electronics manufacturer in Corvallis, Oregon frequently finds it necessary to call Singapore. The caller needs to phone at a convenient business hour in Singapore's time zone.

To run this example the user must key the example cities, Corvallis and Singapore, into the program. The actual answer will depend upon the time of day in which the example is run. If the output time is 15-1/2 hours later than the input Corvallis time, the program has been run correctly.

DISPLAY	INPUT	FUNCTION
The program	steps to insert would be as follows:	
		[GTO]
		[PRGM]
		01 LBL "CORV"
		02 -8
		03 "CORVALLIS"
		04 GTO "WT"
		05 LBL "SING"
		06 7.3
		07 "SINGAPORE"
		08 GTO "WT"
		09 END
		[PRGM]
Find the Cor	vallis offset	[XEQ] "CORV"
Find the Sin	gapore offset	[XEQ] "SING"
Find the tim	e in Singapore	[XEQ] "WTIME"
Select a tim of day on yo	e of day in Singapore that is 2 or 3 minute ur clock for the next portion of the proble	s later than the time m.
You would li	ke to be reminded to call Singapore at nn:n	n a.m. or p.m. their time.

DISPLAY	INPUT	FUNCTION	
		[XEQ] "T2"	
SINGAP. TIME?	HH.MMSS	[R/S]	
The time of day that	the alarm is to be acti	vated is left in the X register.	

<u>STATUS</u>		
SIZE	:	003
FIX	:	2
TOTAL PROGRAM BYTES	:	201

DATA REGISTERS	
00	Time difference between the input city and Greenwich
01-02	City name

FLAGS USED		
21	t : Printer enabled ear : Printer disabled	
55	t : Printer exists ear : Printer does not exist	

Γ

FUNCTION LABELS	
<u>Label</u>	<u>Function</u>
"WTIME"	Calculates and displays time of day in foreign city
"T2"	Sets relative time alarm
"WT"	Accessed by user written routines

				SIZE: 003
STEP	INSTRUCTIONS	INPUT	FUNCTION	DISPLAY
1	Load program "WTIME".		[GTO]	PACKING
	If you have not yet programmed the cities			
	that you require, go to step 7.			
2	Find the home city. Do not alter the			
	stack at this point.		[XEQ] city	city's name
3	Find the destination city. Do not alter			
	the stack at this point.		[XEQ] city	city's name
4	Calculate the time of day in the			
	destination city.		[XEQ] "WTIME"	(time,day)
5	Set an alarm in the home city's time			
	that will activate at a time in the			
	destination city.		[XEQ] "T2" or	
			[R/S]	(city). TIME?
6	Input the time of day in the destination			
	city that you require.	HH.MMSS	[R/S]	():()
	The alarm time is left in the X-register.			
7	To program cities of interest: Position			
	the calculator to the end of program			
	memory.		[GTO]	PACKING
	Label the routine. Use a global label.			
	Key in the number taken from the time			
	zone chart including the sign (if any).			
	Key in the name of the city using no			
	more than 12 characters.			
	Key in as the last line for each city:			
	[GTO] "WT".			

01+LBL "WTI ME" 02 X<0? 03 GTO 08 04 X<>Y 05 ABS 06 + 07 GTO 09 08+LBL 08 09 - 10 CHS 11+LBL 09 12 STO 00 13 TIME 14 XEQ 10	Is destination city earlier than Greenwich time? If not, then make home city positive and add numbers If destination city earlier, subtract Save time adjustment for LABEL 'T2' Do relative time sub- routine to get clock and	49 ENTER↑ 50 24 51 / 52 INT 53 DATE 53 DATE 54 X<>Y 55 DATE+ 56 LASTX 57 24 58 * 59 ST- Z 60 CLX 61 STO T 62 RDN 63 X<>Y 64 RTN	Number of days Set up stack for XYZALM time, date, no reset
15 CLA 16 FIX 2 17 ATIME 18 "⊢ " 19 X<>Y 20 DOW 21 X<> L 22 X<>Y 23 XEQ IND	date in stack Get time into ALPHA Calculate day from date in Y	64 KIN 65+LBL 00 66 "FSUN" 67 RTN 68+LBL 01 69 "FMON" 70 RTN 71+LBL 02 72 "FTUE"	Day of the week strings
L 24 AVIEW 25 RTN 26+LBL "T2" 27 CLA 28 ARCL 01 29 "⊢. TIME ?" 30 PROMPT 31 -12 32 X<>Y 33 X<0? 34 + 35 ABS 36 24 37 + 38 RCL 00 39 CHS 40 XEQ 10 41 CLA 42 ARCL 01 43 ARCL 02 44 XYZALM 45 RTN 46+LBL 10 47 HMS+ 48 ENTER↑	Get day string Get day string Get city name as message (destination city) Allows negative input to be recognized as PM time, to be consistent with Tim Module in- put formats If negative, convert to 24-hour format Allows routine 10 to cal- culate time if next day Recall adjustment and subtract from midnight Get city name as alarm message Set Almrel routine to calcu- late time offset and leave alarm parameters in X	73 KIN 74+LBL 03 75 "FWED" 76 RTN 77+LBL 04 78 "FTHU" 79 RTN 80+LBL 05 81 "FFRI" 82 RTN 83+LBL 06 84 "FSAT" 85 RTN 86+LBL "WT" 87 FC? 55 88 CF 21 89 AVIEW 90 ASTO 01 91 ASHF 92 ASTO 02 93 END	If no printer, clear printer enable flag to prevent halt Save city name for messages

PROGRAM DESCRIPTION

EXERCISE MONITOR

This program can be used for timing periods of aerobic exercise preceded by a pulse count and followed by pulse counts at one-and five-minute intervals. Runners can input the various distance markers and an overall time goal for the course and alarms will signal when each marker should be reached so as to remain on target. Splits may be stored and later replayed and compared to the goals. The course is easily set up before the exercise period and remains in the HP-41 until ready. A course can also be saved on any storage medium.

The program consists of six main segments which use many of the capabilities of the HP 82182A Time Module: message alarms, stopwatch and control alarms.

Label "RUN" identifies the program, initializes flags and interactively sets up the running course and options. If the user needs to record a pulse count, the program will provide a fifteen-second pulse timing interval at the start and end of the course, followed at the end in five minutes by another pulse count to monitor recovery. Any prompted for option that is not wanted can be skipped by pressing [R/S] with no input. The user is prompted for a course goal, if any, and the successive distances of the various course. The goal time is divided into segments that will activate a control alarm, "M", at the moment that the distance marker should be passed to remain on target. When all markers have been input, the number of splits desired is prompted for. The usefulness of storing splits is best realized by having a coach or friend take them.

The initialized program halts at label "GO" (which is a global label to facilitate a key assignment). "GO" will activate the stopwatch, the initial pulse count (if chosen), and the time limit alarm.

"SPLIT" uses the programmable stopwatch command to store splits in successive registers by incrementing a counter in register 12. If storing splits was chosen as an option during the input portion of the program, the marker alarms are of short duration to allow for greater accuracy.

Label "FIN" simply stops the stopwatch, and trips the pulse intervals after 15 seconds and 04:45 minutes. The three pulse counts remain temporarily in registers 01, 02, and 03.

"REPLAY" recalls the stored pulse counts and all stored splits formatted for printing (may be replayed without printer).

"M" is the control alarm that is activated at each marker in proportion to the total goal time for the course. If the option of storing splits was chosen, "M" sounds two high pitch tones only and resets to the next marker. If splits were not chosen, eight tones would sound and the marker number would be displayed. If the program were to run for several seconds to output audio feedback signals and format an alpha display, a split could not be stored close to the "marker" (if they coincided). The keyboard and user functions are only available when a program is not running.

Registers 00 through 11 are only used during the input phase of the program. When the course splits and pulse counts have been displayed and/or printed, they are available for plotting routines using the PRPLOT program of the HP 82143A printer and HP 82160A HP-IL Module.

SAMPLE PROBLEM

Simulate the training course undertaken by Wonder Woman on her secret island, who, with her HP-41 to time her goals and performance, desires to run an irregularly marked course of ten kilometers in six minutes.

DISPLAY	INPUT	FUNCTION	
·		[XEQ] "RUN"	
PULSE? Y/N	γ	[R/S]	
LIMIT HMS?		[R/S]	
GOAL HMS?	.06	[R/S]	
DISTANCE 1?	1	[R/S]	
DISTANCE 2?	2.5	[R/S]	
DISTANCE 3?	4.2	[R/S]	
DISTANCE 4?	7	[R/S]	
DISTANCE 5?	9	[R/S]	
DISTANCE 6?	10	[R/S]	
DISTANCE 7?		[R/S]	
N SPLITS?	1	[R/S]	
READY			
In actual practice 40 minutes would course. If we we where Wonder Woman were divided into	e, a runner desiring to run input the distance to known re to recall the data regist n's distance markers were st linear time intervals.	a ten kilometer course in points to the end of the ers, beginning with R19, cored, we could see how they	
	R19 = 0.003600 R20 = 0.013000 R21 = 0.023120 R22 = 0.041200 R23 = 0.052400 R24 = 0.060000	(00:00:36.00) (00:01:30.00) (00:02:31.00) (00:04:12.00) (00:05:24.00) (00:06:00.00)	
To begin the cours	se:	[R/S] or [XEQ] "GO"	
The first display be used for taking vated and you are the number of beat	is "PULSE", signalling the g a pulse count. After 15 s prompted with "BEATS=?". A ts counted, in this case: 1	start of a 15 second interval to econds, a message alarm is acti- cknowledge the alarm and input 7.	

DISPLAY	INPUT	FUNCTION
	17	[R/S]
RATE=68		
A message alarm will Acknowledge the alar	be activated with the dis m and proceed.	play: "READY".
		[R/S]
0		
As each marker shoul followed by the disp (in this case, after to select key assign	d be passed, a series of e blay: "MARK (n)". When th ""MARK 6") execute "FIN". mments for functions like "	ight high pitched tones will sound e end of the course is reached (in practice, the user might wish GO" and "FIN").
MARK 6		[XEQ] "FIN"
WAIT		
PULSE		
BEATS=?	29	[R/S]
After 4:45 minutes, monitor pulse recove been stored or they,	the "WAIT" and "PULSE" ala ery. To replay the stored too, would be displayed):	rms are repeated to allow you to pulse counts (no splits have
		[XEQ] "REPLAY"
PULSE 1=68		[R/S]
PULSE 2=116		[R/S]
PULSE 3=(n)		[R/S]
00:00:00.00 (no spli	t)	[R/S]
The various options For example, store s initial prompts unti	offered by the program may plits under program contro 1 "N SPLITS?".	be used in any combination. 1 by skipping all of the
If the program "time 10 minutes, no flag	es out" and the machine tur used by the program will b	ns off automatically after e affected.

<u>STATUS</u> SIZE : # of Distance Markers + # of Splits + 19 FIX : 0, 2, 4, 6 TOTAL PROGRAM BYTES : 528

00 Index for storing pulse counts (1.003)	
01 Start pulse	
02 Finish pulse	
03 Recovery pulse	
04 SIZE (also used as recall split index)	
05 1 E-3 (.001) a constant repeated in the program	
06 Split index	
07 15 E-4 used to time pulse and wait intervals	
08 Marker n, during input	
10 "READY"	
11 Index for recalling distance, converting to time interval	s
12 Highest distance register n, used to compute size require store splits	ed,
13 Distance marker store index	
14 Goal HH.MMSS	
15 Start "GO" time	
16 Time limit	
18 Loop control for "M" control alarm	
19-23 Store distance marker intervals	
24-25 Splits begin after last "M" register	

FLAGS USED			
01	Set	:	Set pulse alarm and wait interval
02	Set	:	Allow pulse alarm
05	Set	:	Skip marker display, shorten tones to 2
21	Clear Set	:	Printer enabled
25	Clear Set	:	Printer disabled No error detected
26	Clear Set	:	Error detected Audio enabled
27	Clear	:	Audio disabled
27	Clear	:	User mode off
29	Set Clear	:	Radix separators displayed No separators
55	Set Clear	:	Printer exists No printer
			•

FUNCTION LABELS	
<u>Label</u>	FUNCTION
"RUN	Initialize, set indices and flags for options, check size
"GO"	Start activity
"SPLIT"	Store splits
"FIN	End activity, trigger pulse counts, if optioned - stops stopwatch
"REPLAY"	Read pulse counts and splits

				SIZE: *
STEP	INSTRUCTIONS	INPUT	FUNCTION	DISPLAY
1	Load "RUN"		[GTO]	PACKING
2	Initialize "RUN"		[XEQ] "RUN "	PULSE? Y/N
3	If you wish to check your pulse:	"Y" or "N"	[R/S]	LIMIT HMS?
4	Input the maximum duration of the exercise			
	period. This step may be skipped if it is			
	not applicable.	HH.MMSS	[R/S]	GOAL HMS?
5	Input the goal time for completion of the			
	course. This step may be skipped if it			
	is not applicable.	HH.MMSS	[R/S]	DISTANCE N?
6	Input the elapsed distance to the			
	first marker.	distance	[R/S]	DISTANCE N?
7	Input the elapsed distance to next marker.	distance	[R/S]	DISTANCE N?
8	Repeat line 7 until all distance markers			
	are inputted.		[R/S]	N. SPLITS?
9	Input the number of splits you plan to			
	store. If skipped, the distance marker			
	output display will be shortened to			
	allow greater accuracy in the displayed			
	splits. To see the full output display,			
	input at least one split.	HH.MMSS	[R/S]	READY
10	When ready to begin:			
10a	Immediately following step 9:		[R/S]	PULSE
10b	Otherwise:		[XEQ] "GO"	PULSE
11	Take a pulse count until the program			
	prompts for the total.			BEATS=?
12	Stop counting your pulse when the			
	* # of splits + # of distance markers + 19	9		

STEP	INSTRUCTIONS	INPUT	FUNCTION	DISPLAY
	calculator flashes the display. The			
	display will flash until the user			
	acknowledges the alarm.		[R/S]	Ø.ØØØØ
13	Input total beats counted.	beats	[R/S]	RATE=()
14	Start your exercise period.		[R/S]	Ø
15	To store splits: ("SPLITS" should be			
	assigned to a key to be effective).		[XEQ] "SPLIT"	.nnn
16	During the exercise period, if the goal			
	option was chosen, there are two possible			
	outputs:			
16a	Split option: feedback at the checkpoint			
	consist of two high pitched tones and			
	no display.			
16b	No split option: feedback consist of 8			
	high pitch tones and an alpha display.			MARK()
	Either way, no acknowledgement			
	is required.			
17	To end the exercise period:		[XEQ]"FIN"	
	There are two possible results of			
	this action:			
17a	No pulse option: two tones are generated			
	and the program terminates.			
17b	Pulse option: A 15-second interval is			
	timed in order to prepare for a pulse			
	count.			WAIT
18	An alarm is sounded at the end of the			
	period.			PULSE

STEP	INSTRUCTIONS	INPUT	FUNCTION	DISPLAY
19	The display will flash until the user			
	acknowledges the alarm.		[R/S]	Ø.ØØØØ
20	Input total beats counted.	beats	[R/S]	RATE=()
21	To read back splits and/or pulse:		[XEQ]"REPLAY"	PULSE N=()
			[R/S]	•
			[R/S]	•
				nn:nn:nn:nn
				•
				•
				•

01+LBL "RUN		47 PROMPT	
		48 STO IND	Store distance
02 CF 01	Initialize the flags that	13	
03 CF 05	will be tested by the	49 X≠0?	If not 0, save number of
04 CE 29	program	50 510 08	highest input
07 CI 27 05 "V"		51 V+02	If not 0 continue in
0J 1" 04 00TO V	Prepare stack for option	JI A+0:	
06 HSTU Y	test	52 GIU 00	юор
07 "PULSE?	Pulse option?	53 RCL 13	If 0, format index for
YZN"	·	54 18	recall of distances and
08 AON		55 -	conversion to time for
09 STOP	Stop in ALPHA mode	56 RCL 05	aiaiiis
10 DOFF	Stop III ALFHA mode	57 *	
11 OCTO V		50 CTO 17	
11 H310 A	ALFHA to stack for		Loop control
12 X=Y?	comparison	59 RUL 13	
13 SF 01	t	60 STU 12	Save to form split index
14 CLRG	Prevents recall of use-	61 1	later
15 1 E-3	less splits or goal	62 -	
16 STO 05	points	63 RCL 05	
17 3	E-3 is a constant that	64 *	R05=1E-3, build ISG
10 4	will be used by the	25 10	loop number
	program to form ISG		Get start register
19 510 00	loop control numbers	66 +	-
20 2	Register 00 will store	67 STU 11	
21 /	pulse counts	68 STO 13	
22 STO 07		69+LBL 01	
23 "LIMIT H	Time Limit Option?	70 RCL 14	R14=course goal
MS2"		71 HR	To decimal time
	0 is default	72 PCL TND	Recall first distance
24 ULA 25 DD0MDT		11 KGE IND	marker
25 PRUMPT			
26 510 16		73 RCL 08	Recall number of
27 "GOAL HM	Goal for the course	74 /	Divide into goal and
S?"	(option) - may also	75 *	convert to time
28 CLX	Default is 0	76 HMS	
29 PROMPT		77 STO IND	Replace distance with
70 STO 14		11	time
71 8-02	If no noal skin next	70 TCC 11	
31 A-0:	input sequence	70 136 11	increment counter,
32 610 02		79 GIU ØI	Loop ended net start
33 17		80 RCL 13	register saved at line 68
34 STO 13	Store index for distance	81 STO 11	Re-use R11
35+LBL 00	marker input and store	82+LBL 02	
36 1	Loop entry point	83 "N SPLIT	Split option?
37 ST+ 13	distance	S?"	
78 "NISTONC		84 CLX	
		05 PPOMPT	Propara input test
		00 FKUNFI 07 V400	
39 FIX 0		85 AFU?	Option chosen set solit
40 RCL 13	Get increment value	87 51 05	flag
41 17		88 "RESIZE>	Test for sufficient size,
42 -		= "	to ensure that program
43 ARCL X		89 FIX Ø	will not fail to store
44 "	prompt	90 SF 25	requirea n splits
45 FIX 2	F	91 RCL 12	Format prompt
		00 ±	Set error flag
46 LLX		72 7	

93 1	Compute size require-	143 XYZALM	Time limit alarm
94 +	ment	144 + LBL 04	
95 ARCL X	Format ALPHA display	145 RCL 14	Goal time
96 LASTX	if needed	146 X≠0?	If there is a goal, set
97 -		147 GTO 20	marker alarms, if not,
98 STO 04	SIZE	148 RTN	do nothing
99 RCL IND	Jizz	149+I BI "SPI	Global label allows fastor
×	Test II register exists	IT"	execution if assigned to
100 FC? 25		150 RCLSW	USER key
101 PROMPT	If test failed then dis-	151 FIX 4	Get stopwatch
102 FC?C 25	play prompt	152 TONE 9	Display when done
103 GTO 02		153 TONE 8	Tick-tock feedback that
104 RCI 04	If the flag was cleared	154 ISC 12	split was actually stored
105 PCL 05	assume that size will	155 CTO IND	Increment split counter
106 *	be changed	100 010 100	
100 * 107 CT+ 12		12 157 DTN	
100 001 12	Store index	136 KIN 453.101 #511	Stop
108 KLL 12		157+LBL "FIN	Global label for end
	Split index		routine
110 SF 27		158 STOPSW	Terminate activity timing
111 FIX 4	Set fix mode to display	159 TONE 9	
112 "READY"	time	160 TONE 9	Audible feedback
113 ASTO 10	Save prompt for re-use	161 FC? 01	
114 RCL 10	seen when machine is	162 RTN	Pulse not wanted? STOP
115 RTN	turned back on	163 CLST	Else, set up stack for
116+LBL "GO"	Global label allows a key	164 TIME	alarm command clock
117 CF 02	assignment	165 RCL 07	+15 seconds (stored at
118 FC? 55	Flag 02 will be used to	166 HMS+	Initialization/
119 CF 21	toggle pulse alarm	167 "↑↑"	
120 SF 26	Set tone flag	168 XYZALM	ALPHA alarm command
121 FS? 01		169 "WAIT"	
122 XEQ 05	If pulse option chosen,	170 PROMPT	Display required activity
123 RCL 10	uo puise alarm	171+LBL 05	
124 FS? 01	-	172 FC? 55	No printer?
125 RTN	Repeat flag test as no op	173 CF 21	
126 SF 02	flag	174 "PULSE"	Now take pulse
127 RCL 11	Now toggle flag 02 on	175 AVIEW	
128 STO 13	for later test by FIN	176 "BEATS=?	Message for alarm
129 RUNSW	routine Get index		
130 CLST	Start activity timer	177 CLST	Set up stack for alarm
131 SETSW	Set stopwatch to 0	178 RCL 07	15 seconds added to
132 TIME	Save start time	179 TIME	clock
133 TONE 9	Signal activity start	180 HMS+	
134 TONE 9		181 TONE 9	Start signal
135 STO 15	Time will be used for	182 TONE 9	
136 RCL 16	setting alarms	183 XY70 M	
137 X=0?	If time limit chosen.	184 .043	Do again in 4½ minutes
138 GTO 04	start here	185 HMS+	Alarm entry point
139 CLA	If not, skip	186 "44FTN"	Alarm toggle flag
140 FIX 4	Time limit message will	187 FS2C 02	Clear display Wait for
141 ATIME24	be time formatted	188 XY701 M	pulse alarm to display
142 HMS+		189 CLX	'BEATS=?'
		100 000	

190 STOP		237+LBL 08	Tone loop, sound eight
191 4	Multiply pulse count by	238 TONE 9	high pitch tones
192 *	4 to get rate/minute	239 DSE X	
193 ISG 00		240 GTO 08	
194 STO IND	Save pulse count R01.	241 FIX 0	Format ALPHA display
00	R02, R03	242 "MARK "	
195 "RATE="	Display	243 RCI 13	
196 FIX Ø	Display	244 18	Get number of marker
197 ARCL X		245 -	
198 AVIEW	Recall splits and pulse	246 INT	
199 RTN	oounts	247 ARCI X	AVIEW must not halt
200+LBL "REP		248 CF 21	program or next control
LAY"		249 OVIEW	alarm will not be set
201 SF 21		250+1 BL 20	
202 1.003	Enable printer	251 CLST	Set up stack for alarm
203 STO 00	Index for nulse sound	251 0C01 252 PCL 15	Start time
204 FIX 0	Display similar	252 ROL 15	
205+LBL 06	only	17	Next goal point
206 "PULSE "	Sin,	13 257 UMC+	
207 ARCI 00		234 NH37 255 #44M#	Control alarm
208 "+="	Index number	255 TTN 256 Tec 17	Loop control
209 RCI IND		230 130 17 257 VV701M	
		257 612860	
210 BRCL X		238 ULA 250 ICC 17	Increment goal register
211 X±02	Display only if not 0	207 13G 13 240 END	morement gour register
212 OVIEW	Display and get next, do	260 END	
217 190 00	not stop if printer is		
213 13G 00 214 CTO 04	attached		
215 PCL 06	Number of solits		
213 KCL 00			
210 1			
217 T 210 ETV 2	Time format to AL PHA		
210 FIA 0 210 STA 04	Store index		
217 510 04 22041 DL 07	Store muex		
220VLDL 07 221 DCL IND	Got splits		
221 RUL IND	Get spirts		
04 222 CLO			
222 CLH 227 OTIME24	Into ALPHA		
223 HITHE24			
224 HVIEW 225 ICC 04	Print, or stop and get		
22J 13G 04 226 CTO 07	licat		
220 GIU 07	Leave display clear when		
227 ULA 220 EIV 2	done		
220 FIA 2			
227 R.IN 970ald: "M"	Control alarmanter		
2307LDL ""	point		
201 0 070 ECO AE			
232 F3(03 977 CT0 00	It splits option chosen,		
233 GIU 08 374 TOUE 0			
234 IUNE 7 975 TOUE 0	Set up pext control		
230 IUNE 9	alarm for marker		
236 610 20			

PROGRAM DESCRIPTION

AUTOMOBILE TRIP COMPUTER AND SPEED CALIBRATOR

"TRIP" and "CAL" are two programs designed to work together to perform time related functions on automobile trips. Users of the "TRIP" program can calculate their estimated time of arrival based on their travel speed and/or the speed required to arrive at a planned destination in a certain amount of time. The program has routines for setting periodic alarms, converting tachometer readings to speed in a given gear and correcting a speedometer reading. Alarms may be set, cleared, changed or merely silenced at any time. One feature of the program is its ability to be interrupted and restarted as often as needed. Travel time-outs are also provided.

The programs contain several routines that may be useful in other applications. All of the routines in the program are written in functional blocks and may easily be extracted or modified for other uses. There are only two subroutines in the program: an alpha prompt and a version of the "ALMREL" program in the HP 82182A Time Module Owner's Manual. The use of the latter prevents data errors when alarms set relative to current clock time produce times greater than 24 hours.

The chime routine, "A", sets a periodic tone that may be used for signaling or as a keep-alert device on monotonous stretches of highway. To maintain a constant time lapse between alarms, the repeat interval is added to the last alarm time rather than the current clock time, eliminating the time taken by label searches and the alarm calculations themselves. Like all of the alarms in the program, the chime alarm is set by the program and stored in the alarm stack without an automatic reset. The chime may be set at program initialization or bypassed and set at a later time. It may also be changed or cancelled. When a change is desired, the existing alarm in the alarm stack is not cleared. The alarm catalog is displayed to enable the user to purge the obsolete alarm. When the alarm is activated, the routine first saves the X-, Y- and Z- registers and later restores them to prevent calculations in progress, if any, from being disturbed.

The global label "2" is called by a control alarm at the start of the program to keep track of 100's of hours if the stopwatch rolls over.

Routine "G" is a time-out feature that, when activated, subtracts hours and minutes of rest time from the total driving time. An alert is sounded approximately every ten minutes to remind the user that a time-out is in progress. It will remain set until cleared by restart - toggled by pressing the "G" key again. When restart is initiated, although the time-out alarm becomes due, it does not sound a tone or display a prompt. The alarm will not be reset until toggled again. Routine "J" prevents the alarm from appearing, but does not cause time to be accumulated again. This way a time-out can last overnight, for example, without hearing alarms every ten minutes. Routine "a" resets the running stopwatch, presumed to have been interrupted, to where it would have been if not stopped. It uses clock data to perform the necessary calculation and then adds the amount of time used by the routine itself to restore the stopwatch. The necessary data are the time the trip clock started and the current clock time. The difference is calculated and multiplied by the number of days and the stopwatch is set MOD 100. This may be performed at any time after starting the program, although a trivial error of a few hundredths of a second may gradually be introduced. The calibration program "CAL", contains an identical routine to allow the two programs to be used independently.

Label "E" is a Distance = Rate * Time calculation that estimates the time of arrival and formats the output in clock time. A date display is also seen if the arrival date differs from the current date. This linear calculation will give credible results for typical interstate highway travel. Inputs can be in either miles or kilometers, as long as the units are consistent. The program treats them only as units and does not convert or name them, allowing easier input and faster calculations. (If you wish to add conversion routines to this program, two conversion factors will be useful: miles to kilometers, miles [ENTER^] 5 [LN] [*] (accurate to 2 decimal places) and liters to gallons, liters [ENTER^] 3.785 [/]).

"Calibration" is a routine that accurately calculates a vehicle's speed, in miles per hour, translated from engine revolutions in a given gear. To adapt the program to kilometers, a conversion factor must be added. Although mathematical routines exist that calculate road speed from the tire rolling diameter and transmission ratios, it is more realistic and practical to actually time the vehicle. Tachometers on vehicles with manual transmission are generally a more reliable and linear gauge of speed than are speedometers. Speedometers may also be calibrated by the program, but they commonly have non-linear errors. A correction factor calibrated at 50 miles per hour may be virtually useless at 35 miles per hour. Therefore, calculated factors should be trusted only in a range close to the calibration speed.

It should be noted that a typical reaction time, wherein a mile marker is seen and the [ENTER^] key is pressed to take a split is about 100 milliseconds. This means that the splits taken on a measured stretch of road should not vary more than a few hundredths of a second from mile to mile to be reliable. If this is of importance, a routine might be added to convert the different splits to decimal form and accumulate them in a statistical block of registers (Σ REG 32). An acceptable standard deviation could be chosen and tested.

Important data used by the "TRIP" program is retained in higher numbered data registers and will not be overwritten by accidentally storing up to eight splits too many. Normally, four or five miles would suffice for accurate calibration and the program only counts from \emptyset to 1 \emptyset . Registers \emptyset 5 through 1 \emptyset serve primarily as an overflow buffer though they may also be used for additional splits such as on a ten-mile odometer calibration run in a time and distance rallye.
When the running program executes line 39, the calculator is put into stopwatch (SW) mode and the keyboard is redefined with stopwatch functions. Although a number of functions may be performed in this mode and the stopwatch may be controlled by the [R/S] key, the program is still running. When stopwatch mode is exited by manually pressing [<--] the program will resume normal execution and activate past due alarms, if any, that may have come due but could not be executed while the stopwatch was running. If the chime routine had been set to a short interval, such as five minutes, and had come due more than once, it would execute one time and become past due. It would not automatically be reset. This inconvenience is rarely encountered with control alarms.

"CAL" uses neither flags nor registers that are used by "TRIP", though it does provide data for tachometer RPM to speed conversion and its inverse. "CAL" resets the running stopwatch as if it had not been interrupted. It is not designed to correct the stopwatch if its use has bracketed the midnight hour.

OPERATING LIMITS AND WARNINGS

Estimated time of arrival cannot be calculated if the input odometer reading is equal to the start odometer reading.

Calibrated constants for any vehicle will vary slightly with environmental factors and tire inflation.

"CAL" is written to calibrate gauges in miles per hour. For kilometers, a conversion constant, 1.61, must be multiplied.

SAMPLE PROBLEM

(Some of the answers displayed in the following example are dependent upon the time of day that the example is run).

Use the "Automobile Trip Computer" on a vacation trip, driving 575 miles between Corvallis, Oregon and Palo Alto, California.

Use the "Calibration" program to calibrate the tachometer of your vehicle on a five-mile stretch of interstate highway. Use the calculated correction factor to be sure you are actually driving 55 miles per hour.

DISPLAY	INPUT	FUNCTION
 Load the "TRIP" program		[GTO]
Load the "CAL" program		[XEQ] "SIZE" 032
Initialize the program		[XEQ] "TRIP"
ODOMETER?	Input odometer at start of trip 16000	[R/S]
COREX?	The correction factor is not presently known	[R/S]
DISTANCE?	575	[R/S]
CHIME/HMS?	Input a 5-minute interval to see how the chime works 05	ΓριζοΊ
You might like to drive "etra	.uu	[R/S]
Tou might like to drive stra	inghi-through and be there	Th ten nours.
ODOMETER?	16000	
ARRIVE / HMS?	10	
RF0 SPD=57 5	10	[1/3]
The result of the next operat that you are running this exa of the trip. This example as	tion will depend upon the ac mple and the time elapsed s sumes that the trip was sta	ctual time of day since the beginning arted at 7 a.m.
You have been driving 25 minu	tes, and wish to know your	projected arrival time.
		[XEQ] "E"
ODOMETER?	16023	[R/S]
5:25 PM		
If the projected time of arri would also be displayed, for	val would be on the follow [.] example:	ing day, the date
5:25 AM 10/25		
If you input a fictitious dis travelling at an unusually hi	tance, the calculator may a gh speed.	assume you are
You would like to stop at the	Golden Arches.	
		[XEQ] "B"
TIME OUT		
TIME OUT		
Later, when you return to you	r vehicle:	
		[XEQ] "B"
RESTART		

DISPLAY	INPUT	FUNCTION
How long have you ac	tually been on the road, I	parring time-outs?
		[XEQ] "C"
DRIVE=() : ()		
The chime alarm is r different interval.	o longer useful to you and	l should be changed to a
		[XEQ] "A"
RESET		
CHIME/HMS?		
Input any interval a keys need to be pres reset, you might exe but not heard or res	nd press [R/S] or continue sed to ignore the prompt. cute "J" so that the alarr set.	e to the next operation. No If the chime is not to be n would be activated once,
Use the "Calibratior	" program.	
		[XEQ] "F"
Use of the function The remainder of the	labelled "F" enables a ret e examples are in the "TRIF	curn to the "TRIP" program. " program.
TACH RPM?	3000	[R/S]
GEAR? 3/4/5	4	[R/S]
00:00:00.00>R00		[R/S] (when ready)
Press [ENTER^] at ap passing of milepost	proximately the following in actual operation:	intervals to simulate the
	00:00:55.4 [EN 00:01:50.8 [EN 00:02:46.2 [EN 00:03:41.6 [EN 00:04:37.0 [EN [R,	ITER^] ITER^] ITER^] ITER^] 'S]
The splits in actual required for reliabi	use would be taken at mi lity.	eposts. At least five are
Press [shift] [<]	to exit stopwatch mode and	l resume program execution.
If either of the cor each would be active	trol alarms, "chime" (CS) ted before the program res	or "time-out" (T-) came due gumed execution.
Your output display	should be similar to:	
S/COREX=1.08X		[R/S]
1K RPM, 4=21.7		
Your vehicle travels in fourth gear.	at a rate of 21.7 miles p	per hour for every 1000 RPM's
If you have executed to the "TRIP" progra	the program properly, you m. Do not press [R/S].	ı will again be positioned

DISPLAY	INPUT	FUNCTION		
What should your per hour?	What should your speedometer indicate if you wish to drive exactly 55 miles per hour?			
55		[XEQ] "e"		
INDIC=50.8				
When the speedome travelling at 55	eter indicates 50.8 miles per H miles per hour.	nour, you are actually		
		[XEQ] "c"		
GEAR	4	[R/S]		
SPEED		[R/S]		
RPM?	2700	[R/S]		
SPEED=58.5				
The actual result splits. If they	s may vary slightly due to the are close, you have been runni	e variation in the stored ing the program correctly.		

<u>STATUS</u> SIZE : 032 FIX : 1, 2, 4 TOTAL PROGRAM BYTES : "CAL" 237 "TRIP" 575

DATA	REGISTERS	
	00-10	Split and overflow buffer
	11	Save X
	12	Save Y
	13	Save Z
	14	Counter, greater than O splits
	15	Total time, calibration routine
	16	Store gear, index for "CAL"
	17	Scratch
	18	Date start, MM.DDYYYY
	19	Index, high split
	20	Index, low split
	21	SW n(100)

22	Start of trip, clock time
23	Chime, next occurrence: interval, HMS+
24	Chime interval
25	Odometer start
26	Planned distance
27	Time-out
28	Speedometer correction factor: default is 1.00
29	Gear 3, miles/hour/one RPM
30	Gear 4, miles/hour/one RPM
31	Gear 5, miles/hour/one RPM

FLAGS USED	
00-07	May be used during the INSTAT command, if HP 82160A HP-IL Module is used without disturbing program operation
03	Set : Calibrating gear 3 Clear : All other states
04	Set : Calibrating gear 4 Clear : All other states
05	Set : Calibrating gear 5 Clear : All other states
07	Set : Control alarms "CS" and "T-" disabled
08	Set : Chime alarm is set
09	Set : Tachometer calibration
10	Set : Time-out in progress
21	Set : Printer enabled
22	Set : Numeric input detected
26	Set : Audio enabled
55	Set : Printer exists Clear : Printer doesn't exist

FUNCTION LABELS		
Label	Function	
"a"	Reset stopwatch	
"C"	Tachometer/gear/speed conversions	
"d"	Indicated to actual speedometer reading	
"e"	Actual to indicated speedometer reading	
"A"	Chime, change and/or reset	
"B"	Time-out/restart toggle	
"C"	Total driving time	
"D"	Required speed to distance in (n) HMS	
"E"	Estimated clock time of arrival	
"F"	Execute "Calibration" program and return	
 "J"	Cancel, disable control alarms	

				SIZE: 032
STEP	INSTRUCTIONS	INPUT	FUNCTION	DISPLAY
1	Loan Program "TRIP".		[GTO]	PACKING
2	Loan Program "CAL".		[GTO]	PACKING
3	Execute "TRIP" immediately prior to			
	the start of the trip.		[XEQ] "TRIP"	ODOMETER?
4	Input the current odometer reading. Any			
	units may be used as long as they are			
	consistent throughout the program.	reading	[R/S]	COREX?
5	Input the speedometer correction factor,			
	if known.	factor	[R/S]	DISTANCE?
6	Input the total distance to the			
	destination.	distance	[R/S]	CHIME/HMS?
7	If you want a periodic chime:	HH.MMSS	[R/S]	N.NN 0.00
	The following functions may be performed			
	at any time except as noted.			
8	Calculate the driving speed required			
	to reach the destination in n hours.		[XEQ] "D"	ODOMETER?
9	Input the odometer reading. If the			
	odometer passes through 1000,000 miles			
	and rolls over, you must input the <u>actual</u>			
	mileage it would read.	odometer	[R/S]	ARRIVE HMS?
10	Input the arrival time. The final output			
	can be miles or kilometers (or whatever)			
	depending on units that your odometer			
	reading is expressed in.	HH.MMSS	[R/S]	REQ SPD=()
11	To reset the stopwatch: If the trip timer			
	maintained by the stopwatch must be used			
	temporarily for another purpose, reset			

STEP	INSTRUCTIONS	INPUT	FUNCTION	DISPLAY
	the stopwatch when ready, allowing for			
	the interruption.		[XEQ] "a"	RESET SW
12	To change or set the chime interval.		[XEQ] "A"	RESET CHIME/HMS?
	Input the chime repeat period.	HH.MMSS	[R/S]	
13	To temporarily interrupt the running			
	trip timer:		[XEQ] "B"	TIME OUT TIME OUT
14	To restart the trip timer:		[XEQ] "B"	RESTART
15	To calculate the total driving time:			
	Note that time-outs are not accounted for			
	until the restart routine accumulates			
	them.		[XEQ] "C"	DRIVE=nn:nn
16	To disable the periodic "TIME-OUT"			
	display and chime and to prevent its reset:		[XEQ] "J"	CANCEL
	Note that a time-out, if in progress, must			
	be restarted to update the time accumulator			
17	Find the estimated time of arrival based			
	on the time you've been on the move and			
	your current distance from your			
	destination.		[XEQ] "E"	ODOMETER?
		distance	[R/S]	time and date
	The date display will not be seen if it			
	is the same as today's date.			
	The input distance may not equal the start			
	distance or a "DATA ERROR" will result.			
	USING THE CALIBRATION PROGRAM			
18a	If called as a subroutine from "TRIP":		[XEQ] "F"	TACH RPM?
18b	If run independently:		[XEQ] "TRIP"	TACH RPM?

STEP	INSTRUCTIONS	INPUT	FUNCTION	DISPLAY
19	Input engine RPM's: Skip this input if it			
	is not applicable, press [R/S] and go to			
	step 21.	RPM	[R/S]	GEAR? 3/4/5
20	Input the gear.	gear	[R/S] 00	00:00.00->R00
21	If "TACH RPM?" input bypassed, input your			
	speed. If both prompts are ignored, the			
	routine is repeated.	speed	[R/S] 00	00:00.00->R00
	OPERATING THE STOPWATCH			
22	To start the stopwatch:		[R/S]	
23	To store a split at a mile marker: Up to			
	11 splits may be stored. No programmable			
	test for the number of total splits is			
	possible in SW mode, so be cautious.		[ENTER^]	
	To exit SW mode and continue running			
	the program.		[shift][<]	
	Past due control alarms, if any, will run			
	immediately. Therefore, "TIME-OUT" and			
	chime HH.MMSS may be seen.			
	As an alternative, the calculator may be			
	turned off and on again and [R/S] pressed.		[R/S]	S/COREX= ()X
			[R/S]	1K RPM, ()=()
	Display Signifies: 1000 RPM's in the input			
	gear = (nn.n) miles or kilometers			
	per hour.			
24	To calculate the speedometer reading			
	that corresponds to a speed:	speed	[XEQ] "e"	INDIC=()
	To convert between RPM and speed:		[XEQ] "c"	GEAR?

STEP	INSTRUCTIONS	INPUT	FUNCTION	DISPLAY
25	Input the gear.	3,4 or 5	[R/S]	SPEED?
26	Input the speed, if known. No input if			
	not known.	speed	[R/S]	RPM?
27	Input RPM, if known. No input if not known.	RPM's	[R/S]	SPEED=() or RPM=()
28	To calculate actual speed for an observed			
	speedometer reading:	speed	[XEQ] "d"	ACTUAL=()

01+LBL "CAL		47 HMS+	•
		48 56 E-6	Allow for time taken by
02 CF 03	Clear Flags used by pro-	49 HMS-	reset code lines them-
03 CF 04	gram	50 SETSW	serves (approx.) Reset stopwatch
04 SF 09	Set calibrate tachometer	51 10	neset stopwaten
05 EREG 00	Flag	52 STO 20	Store index register ad-
06 CLΣ	Clear block of registers	53 9	dress of highest allowed
07 EREG 05	used to store splits	54 STO 19	split
08 CL 2		55 CLX	Store index, register ad-
		56 STO 14	split
10 "TACH RP	Place 0 in V for test input	57 STO 15	Set counter to 0
M2"	Frace of IT A for test input	58+1 BL 02	
11 PROMPT	Duamant as liburate to sh 2	59 PCI IND	
12 8=02	User to input RPM	20 KCC IND	Calculate delta splits
17 CTO 00	No input? Then next		
13 GIO 00 14 CTO 14	question	00 KCL IND 10	
14 310 10 15 #CEAD2 7	Store calibration RPM	17 71 UMC-	
IJ GEHK: 3 ///E"	Input gear to be cali-	61 MN3- 20 V/-02	
14 DDOMDT	brated	62 AN-0?	
10 FRUMFI 17 CE IND V		63 GIU 03	Test for end of splits
17 SF IND A	Set gear flag, serves only	54 KUL IJ 25 UMC:	
	as a visual alu	60 HMS+	Sum total time
		66 510 13	
	Set index register for	67 156 14 Co.(D) 07	Increment counter
21 STO IND	gear	68+LBL 03	
16		69 DSE 20	
22 GIU 01	Go to start	70 DSE 19	Continue calculation of
23+LBL 00		71 GTO 02	
24 CF 09		72 RCL 01	
25 CF 22	No tachometer input,	73 RCL 00	Calculate last delta split
26 "SPEED?"	clear Flag Try speedometer	74 HMS-	
27 PROMPT	Try specuometer	75 RCL 15	
28 FC?C 22		76 HMS+	Add to total time
29 GTO "CAL	No input? Repeat	77 HR	
••	sequence	78 RCL 14	
30+LBL 01		79 1	Convert to decimal
31 RCLSW	Save stopwatch and	80 +	Gat number of good
32 TIME	clock	81 /	splits
33 STO 20		82.01	
34 X<>Y		83 HR	Divide into one minute,
35 STO 19		84 X<>Y	written for 'miles', i.e.,
36 STOPSW	Initialize stopwatch	85 /	60 miles per hour is
37 CLX		86 STO 28	basis
38 SETSW	Set to 0	87 "S/COREX	Store correction factor
39 SW	Enter redefined keyboard	= "	for speedometer
40 CLD	mode: Stopwatch	88 FIX 2	Output display
41 ALMNOW	Clear display on exit	89 ARCL X	
42 RUNSW		90 "HX"	Identify number as a
43 TIME		91 AVIEW	multiplication factor
44 RCL 20	Calculate time taken by	92 FC?C 09	
45 HMS-	stopwatch calibration	93 RTN	If tach not wanted, return
46 RCL 19	And reset running stop-	94 FC? 55	or stop
	watch to where it would		
	Have Deell		

95	STOP	Stop if no printer, display	-	
96	60	register unchanged		
97	*			
77				
98	RUL IND	Recall gear RPM		
16				
99	1 E3	Convert to 1 RPM		
100	/			
101				
101				
102	"1K RPM,			
••		Format output display:		
103	FIX Ø	1,000 RPM in (n) gear		
104	RCI 16	= (n)/hour		
105	24			
105	20			
106				
107	ARCL X	Get gear number into		
108	"⊢="	ALPHA		
109	FIX 1	ł		
110		•		
110				
111	HRUL	Clear gear Flag		
112	X<>Y			
113	. 1			
114	%	Divide by 1 000		
115	STO IND			
16		Store in gear (n) register		
110	04154	Store in gear (ii) register		
116	HVIEW			
117	.END.			
		I		
		ľ		
		1		
		ł		
		ļ		
		1		
		ł		
		ł		
		ł		
		ł		
		l		
		1		
		I		
		-		
		ł		

01+LBL "TRI		50 CF 07	Flag 07 used to disable
P"		51 CLX	chime
02 TONE 9	Signal timer start	52 "CHIMEZH	Default is 0
07 RINSW		MS2"	Input periodic interval
04 CLX		53 PROMPT	
04 CEA 05 CETCU		54 970 24	
OC TIME	Set stopwatch to U	55 V-02	
06 INE	Save clock start time		No input?
07 510 22		DE KIN	
08 STO 23	Clock saved for chime	57 CF 26	Silence tones on first
09 -1 E2	HMS+	58+LBL "CS"	pass through chime
10 STO 21	First pass through con-	59 FS? 07	Label for control alarm
11 XEQ "2"	trol alarm '2' will set	60 RTN	Disable?
12 DOTE	Initialize routine to total	61 SE 08	else stop
17 CTA 10	100s of hours	62 TONE 9	Chime active Flag, used
13 310 10	Start date, used for re-		to test reset
14 ZREG 2J	setting stopwatch	63 TUNE 0	Chime
15 CL2	Clear block of registers	64 SF 26	Re-enable audio for future
16 CF 07		65 510 11	occurrences
17 CF 08		66 RDN	Save stack in case a calcu-
18 CF 10	Clear Flags that will ini-	67 STO 12	interrupted
19 XEQ 01	tially be tested by prgm.	68 RDN	X, Y, and Z are saved
20 STO 25		69 STO 13	
21 "COREX?"		70 "TTCS"	
21 OOKEN.	Prompt	71 PCL 24	
22 I 97 DD0MDT	Input factor, if any	70 001 27	Set up control alarm
23 PRUMPI	default=1, stored if	72 KUL 23	Get interval
24 510 28	no input	7.3 XEQ 04	Get clock time of last
25 "DISTANC	Input planned distance	74 XYZHLM	occurrence and execute
E?"		75 STO 23	ALMREL routine
26 CLX		76 RCL 13	Store next occurrence
27 PROMPT	Default is 0	77 RCL 12	Restore Z
28 STO 26		78 RCL 11	Restore X
29 GTO 00	lump over chime reset	79 RTN	
30+LBL A	routine	80+LBL D	Paguirad apond routing
31 SE 07	disable chime temperarily	81 XEQ 01	
72 01 07	Next a second se	82 RCI 25	Get ODOMETER?
77 TIME	Next occurrence	07 DCL 26	Odometer start
33 IME 34 0TO 07		03 KCL 20	Planned distance
34 510 23	Reset occurrence offset	04 T 05 U/NU	Added
35 FC/C 08	from present time	85 85 7	
36 GIU 00	reset routine	86 -	Less the distance covered
37 HMS-	Calculate time till alarm	87 "ARRIVE	to this point
38 1 E-4	triggers	HMS?"	nput desired travel time,
39 HMS-	Set back one second	88 PROMPT	innours
40 STO 17	Save clock adjustment	89 HR	
41 T+X		90 /	
42 "RESET"	Advance clock	91 "REQ SPD	Calculate rate of travel
AZ OVIEW	Use ALPHA display to	="	Output display
AA DOE	mask alarm activity	92 CTO 06	
44 FOE 45 DOE	Be sure that triggered	97 4 D E	Output routine
40 FBE	cnime occurs during	73¥LDL E 04 VEO 04	Estimated time of arrival
46 RUL 17	Set clock back to present	94 KEQ 01	ODOMETER? Prompt
47 CHS		95 RUL 25	Odometer start
48 T+X		96 -	Distance covered
49 + LBL 00	chime set routine, bypass reset	97 ENTER↑	Save in stack

98	ENTER↑		147 FC? 10	Time-out period ended?
99	RCLSW	Get trip elapsed time and	148 RTN	
100	RCL 21	adjustments for 100s of	149 " ተ ተT-"	Control clares
101	HMS+	hours and time-outs	150 TIMC	Control alarm
101		totalled	100 IINE	
102	HR	Calculate rate	151 .1	Ten minute interval
103	/		152 XEQ 04	reminder
104	RCL 26	Planned distance	153 XYZALM	Set up alarm parameters
105	R↑		154 ES2 07	in stack
106	_		155 DTN	If alarm 'silenced' quit
100	0/10		100 KIN 454 USO 07	nere, if triggered by
107	0.21		106 XEQ 03	alarm to payt occurrence
108	· · · · · ·		157 + LBL 03	omit display this time.
109	HMS	Add projected time to	158 "TIME OU	Repeat display and tone
110	TIME	clock time	Τ	twice.
111	XEQ 04	_	159 OVIEW	Reminder routine
112	FIX 2	Execute routine to get	160 TONE 5	
117		time and date in X and	IGU TUME J	
11.5		T Initializa ALPHA	161 RIN	
114	HIIME	Format time display	162 + LBL "2"	Add 100 hours to accumu
115	"⊢ "	i office clispicy	163 "ተተ2"	lator when stopwatch
116	CLX		164 1 E2	rolls over
117	NATE	Tarif to day to day	165 ST+ 21	
119	XZXY	lest if today's date	100 010 E1	Accumulator register
110				
119	A+1 :		167 XEQ 04	
120	нрніе	If different, append to	168 XYZALM	Next hundred
121	AVIEW	ALPHA	169 RTN	
122	RTN		170+LBL 04	
1234	LBL 01	Input prompt subroutine	171 HMS+	ALMREL type routine,
124			170 ENTERA	Owner's Manual here
105	"ODOMETE	Set to U for testing input	172 ENTERN	without I/O halts
12J	ODONETE		173 ENTERT	
RY.			174 24	Number of days
126	PROMPT		175 /	
127	RTN		176 INT	
1284	LBL B	Time-out toggle	177 DATE	
129	RCLSW	Trip time to date	179 8/38	
170	PCI 21		170 00754	
130	NOC 21		177 DHIET	
131		Plus 100s of hours and	180 LHSIX	
132	FC?C 10	Time-out mode?	181 24	
133	GTO 02	Time-out mode:	182 *	
134	RCL 27		183 ST- Z	
135	HMS-	If Flag 10 clear, then ini-	184 CLX	
176	RCI 21	tiate a time-out, else	105 CTO T	Set up parameters in
177	V/NV	adjust accumulator	103 310 1 407 DDU	alarm, no reset, time
137		register	186 RUN	less than 24 hours
138	HMS-	1	187 X<>Y	
139	STU 21		188 RTN	
140	"RESTART	Result of action	189 + LBL a	
••			190 RUNSW	B
141	AVIEW		191 NOTE	Reset stopwatch
142	RTN	1	100 DCL 10	
1474	N DI 00	Internet in the second	172 RUL 10	
1434		initiate a time-out	193 DDH12	Date stopwatch started
144	5F 10	Set time-out Flag	194 24	running
145	STO 27	Adjusted trip time	195 *	n days running
1464	∙LBL "T-"	Label for control alarm	196 TIME	n hours

197 RCL 22		244 "INDIC="	Speedometer display
198 7 E-5	Time stopwatch started	245 RCL 28	
199 HMS-	on first day	246 /	Correction factor
200 HMS-	taken to execute this	247 + LBL 06	
201 HMS+	block of code	248 FIX 1	Display one significant
202 1 E2	Subtracted from total	249 ARCL X	αιgiτ
203 MOD	MOD 100 to avoid data	250 AVIEW	
204 SETSW	error	251 RTN	
205 "RESET S	Confirm	252+LBL J	
М "	Comm	253 SF 07	Set Flag to disable chime
206 AVIEW		254 "CANCEL"	Time-out, if any, after
207 RTN		255 AVIEW	resetting
208+LBL C		256 RTN	
209 RCLSW	Total driving time	257+LBL F	Call global subroutine and
210 RCL 21	Trip timer	258 FC? 55	return here
211 HMS+	Accumulator register	259 CF 21	Printer?
212 "DRIVE="		260 XEQ "CAL	
213 FIX 2			
214 ATIME24		261 .END.	
215 AVIEW	Format output		
216 RTN			
217+LBL C			
218 "GEAR?"	Input prompt		
219 PROMPT	input prompt		
220 26	Index number, location		
221 +	of gear data		
222 "SPEED?"	Calculate RPM if speed		
222 0, 222	known		
223 0 224 PROMPT	Set to 0 for input test		
225 X±02	No input try pext		
226 GTO 05	If input speed, go to		
227 "RPM?"	calculate routine		
228 PROMPT	Calculate speed from		
229 RCL IND	known RPM?		
7	Recall gear data		
230 *			
231 "SPFFD="			
232 GTO 06	Go to output routine		
237+1 BL 05			
234 RCL IND	Goar data		
7	Geal uata		
275 /			
233 / PPM="	Output		
230 KIN- 237 CTO 06	Julput		
23, 310 00 27841 RI A			
230*EDE G 239 "OCTION =	Observed reading input		
237 ACTORE-	calculate actual speed		
240 PCL 28	Osastant ustaal opoou		
240 KOL 20 241 *	Constant was stored by		
242 CTO 06			
242 GIO 60	Go to output		
CTOTLOL E			

PROGRAM DESCRIPTION

FOUR CHANNEL CONTROLLER

"Four Channel Controller" provides a means of maintaining up to four userwritten controller programs or "channels". Each channel may have its own six character identifier; time, data and note files; simple message alarms; and user defined control alarms. Alarms and callable subprograms may be added to or deleted from memory at any time. The data associated with a channel may be recalled and/or printed when desired. The program is capable of synchronizing the HP 82182A Time Module's stopwatch with any channel time and of keeping track of the next available data register into which splits may be stored. Nine free registers are provided by the program for user-defined channel use.

"4CON" is the initializing portion of the program. With it, all four channels are initialized by storing the current clock time in data registers \emptyset 1 through \emptyset 4. Flags \emptyset 1 through \emptyset 4 are not tested by the program, but are provided as indicators of which channel is currently being accessed. The states of these flags are preserved in register \emptyset 6 and, therefore, will not be adversely affected by the HP 82160A HP-IL Module function INSTAT or any other flagaltering function.

All of the following routines may be given global labels, to follow or replace their respective local alpha labels, to provide global access, i.e., from control programs.

The subroutine labelled "b" initiates the channel whose number is taken from the X-register.

The subroutine labelled "c" adds alarms to any running channel without reinitializing it. The channel number is taken from the X-register.

The subroutine labelled "e" clears the registers used by the "DATA" program.

The subroutine labelled "C" recalls and prints all of the stored data pertinent to the channel whose number is taken from the X-registers.

The subroutine labelled "E" syncronizes the HP 82182A Time Module's stopwatch with any channel. The actual time taken to run the routine is considered in the calculation. The routine displays the first empty data record. When using the stopwatch, manually setting the stopwatch's split-register pointer to this value will avoid overwriting important data registers.

The subroutine labelled "DATA" allows the storage of time related data in each channel. If the calculator does not have sufficient room to store the next group of data, "NO ROOM" will be displayed and the program will halt.

The user may write programs that access these blocks of registers in the same fashion that "DATA" does. The data is stored in five-register records in which the lowest numbered record contains the channel number. The second register contains the time from initialization at which the data set was recorded. The third and fourth registers contain a message of up to twelve characters. The fifth register contains any pertinent numeric data.

This program is intended to be compatible with all HP-IL controllable devices. All of the routines will allow at least four additional levels of subroutine calls. The display mode used by routine labelled "C" is not controlled by the program and is therefore up to the discretion of the user.

OPERATING LIMITS AND WARNINGS

Obsolete reset alarms must be cleared manually via the "ALMCAT" function of the HP 82182A Time Module.

Space must be available in memory for storage of alarms. Refer to the HP 82182A Time Module Owner's Manual for details of the memory requirements of the various alarms.

Failure to adjust the stopwatch pointer when in stopwatch mode may result in the destruction of valuable data.

Default conditions (such as the states of flags 17 and 21) should not be assumed by any user-written programs. User defined program interrupts -- control alarms -- should preserve the stack whenever possible.

See step 10 of the User Instructions.

SAMPLE PROBLEM

1. A medical office administers glucose tolerance tests to many of their patients. The tests are from four to six hours in length and are used to test for Diabetes and Hypoglycemia. Blood samples must be taken at exact intervals and the measurements must be recorded. Use the program to accommodate this need.

2. Line voltage to a microcomputer must be measured periodically to test the effectiveness of a voltage regulator. Use channel 3 to sample and print the voltage at five minute intervals with the HP 3468A Voltmeter.

3. A Photographer needs to monitor three activities simultaneously including the time during which a model is on a particular assignment, how long a batch of prints is being rinsed in the darkroom and when to leave for an appointment.

DISPLAY	INPUT	FUNCTION				
Load the "4CON" program. Prior to running the example problems, be sure that there are at least eight unused program registers in your calculator. These registers will be used by the alarm stack. The minimum SIZE required by the first problem is 042.						
DATA X?		[XEQ] "4CON"				
In practice, at le However, for this reading will be us	east seven samples would be dra example, we will take only thr ed in another example).	wwn for a six hour test. ree readings. (The third				
	3	[R/S]				
NAME	BLTEST	[R/S]				
ALARM/HMS?						
The first test is	run at .5 hour. The remaining	g tests are run at 1 hour intervals.				
	.3	[R/S]				
RESET?	1	[R/S]				
PRGM?		- · -				
We will not be con	trolling a program.					
		[R/S]				
BLTEST						
If you use ALMCAT, reset. Use the "D	you can confirm that the alar ATA" routine to store the pati	m has been set with a one hour ent's initial blood sugar level.				
		[XEQ] "DATA"				
CHANNEL?	1	[R/S]				
NOTES?	FASTING BL/S	[R/S]				
DATA?	80	[R/S]				
80.00						
Let's assume that is 162 MG%.	the first alarm has been activ	vated. The next measurement				
		[XEQ] "DATA"				
CHANNEL?	1	[R/S]				
NOTES?						
The patient's name more than one chan	e could be input here to prever mel being run by "4CON".	it confusion if there is				
	MOE SUGAR	[R/S]				
DATA?	162	[R/S]				
162.00						
Recall the data. depend upon how lo similar in appeara	The outputs marked ** are appr ong it took to run the sample p once to those given here, you a	roximate. The displayed times problem. If your displays are are running the program correctly.				

DISPLAY	INPUT	FUNCTION	
	1	[XEQ] "C"	
BLTEST			
00:01:45.41 **		[R/S]*	
FASTING BL/S		[R/S]*	
80.0		[R/S]*	
00:31:50.41 **		[R/S]*	
MOE SUGAR		[R/S]*	
162.000000		[R/S]*	
END			
* [R/S] is not neces	ssary if printer exists		
2. Before running t previous problem.	this example, you should	l purge the alarms set f	rom the
	2	[XEQ] "b"	
NAME?	VRTEST	[R/S]	
ALARM/HMS?	.3	[R/S]	
RESET?	.05	[R/S]	
PRGM?	٧	[R/S]	
VRTEST			
The first alarm will every five minutes is problem could have H R15 - R22, for compa- instructions to the ization routine to s same line but are so test for a minimum of the entire system v	I go off 30 minutes after thereafter until it is r been written to store co arisons. Additionally, HP3468A Voltmeter could speed program execution eparated here for clarit or maximum voltage and o ia a (hypothetical) rela	er the timer was started manually purged. Note t ertain values in the unu the ALPHA strings used d have been prestored by They are normally pro ty. The program could b either sound an alarm or ay interface.	and will repeat hat the sample sed registers, to send an initial- grammed on the e designed to shut down
01+LBL "V" 02 AUTOIO		12 OUTA 13 IND	Voltage reading is sent
03 2	The voltmeter is the 2nd	14 X<>Y	to the X register
04 SELECT 05 REMOTE	device in the loop	15 FIX 4	Swap with time
06 "F2"	AC Volts function is	16 CLH 17 ATIME	Format and print time
07 OUTA	selected	18 PRA	•

300 Volt range is selected

Single trigger mode causes a single reading to be taken 19 X<>Y 20 FIX 2

21 PRX

22 END

Print voltage

"R4"

OUTA

"T2"

ATIME

08

09

10

11

51

Whether or not the example program was keyed in, use the ALMCAT function to confirm that the control alarm was set and purge the alarm.

[XEQ] "ALMCAT"

Press [R/S] when the display " $\uparrow\uparrow$ V" is seen. Press [R] to see the 00:05:00 reset. Press [T] to see the time 30 minutes from the time that the alarm was set. Press [shift] [c] to purge the alarm.

DISPLAY	INPUT	FUNCTION
3. Sophisticated equipmen It may be used to monitor	t is not required to various activities a	use the "Four Channel Controller". s well as timekeeping chores.
Initialize channel 3.		
	3	[XEQ] "b"
NAME?	MODEL	[R/S]
ALARM/HMS?	no input	
We are giving the channel "DATA" function.	an identification th	at will be used by the
Initialize channel 4.		
	4	[XEQ] "b"
NAME?	PRINTS	[R/S]
ALARM/HMS?	.3	[R/S]
RESET?	0 or no input	[R/S]
PRGM?		[R/S]
		[R/S]
The prints must be delive activate in one hour.	red in one hour. Add	an alarm to channel 4 to
ALARM/HMS?	1	[R/S]
RESET?	.05	[R/S]
PRGM?		[R/S]
Note that by pressing [R/ channel. To give each al the channel number and ex 6-character code or messa the channel identificatio message. Channel 3 retai	S] a series of alarms arm a different "mess ecute "c". Respond t ge. Although this al n, each message alarm ns its original ident	could be placed on the same age", use routine "c". Input o the prompt "NAME?" with a so has the effect of changing will have its own unique ification, "MODEL".
Your model has arrived. of time that the model wo	Use the "DATA" function rks in your studio.	on to keep track of the amount
		[XEQ] "DATA"
CHANNEL?	3	[R/S]
NOTES?	(model name)	[R/S]
DATA?	25	[R/S]
Recall the data	3	[XEQ] "C"

When your model has finished, you might use the "DATA" function to record the finish time and other important information.

STATUS

SIZE : 042

TOTAL PROGRAM BYTES : 470

DATA REGISTERS	
00	Scratch register for User defined program
01	Start time of channel 1
02	Start time of channel 2
03	Start time of channel 3
04	Start time of channel 4
05	Storage index - returned to R07 after block clear - used by routine "e"
06	Channel flag - 1, 2, 3 or 4
07	"DATA" storage index
08	Recall index used by routine "C" - time parameter for "XYZALM"
09	Reset parameter for "XYZALM"
10	Channel name index
11	Start date of channel 1
12	Start date of channel 2
13	Start date of channel 3
14	Start date of channel 4
15-22	Scratch registers for user defined programs
23	Name of channel 1
24	Name of channel 2
25	Name of channel 3
26	Name of channel 4
27	Start of first "DATA" record: channel number (1-4)
28	Elapsed time
29-30	Message
31	Data or scratch
32->	Additional records

FLAGS USED			
00	Set Clear	:	Return to "DATA" from routine O8 No return
01-04	Set Clear	:	Visual identification of channel 1 Not channel 1
21	Set Clear	:	Printer enabled Printer disabled
23	Set Clear	:	ALPHA input detected No ALPHA input
25	Set Clear	:	No error detected Error detected

FUNCTION LABELS	
Label	Function
"b"	Starts the time for the channel indicated by the X-register
"c"	Add alarms to the channel indicated by the X-register without resetting the timer to zero
"e"	Clear the block of registers dedicated to the "DATA" routine
"C"	Recall, view or print "DATA" records for the channel
"E"	Synchronize the stopwatch with the channel
"DATA"	Store data interactively

				SIZE: 042
STEP	INSTRUCTIONS	INPUT	FUNCTION	DISPLAY
1	Load program "4CON".		[GT0]	PACKING
2	Initialize "4CON".		[XEQ]"4CON"	DATA X?
3	Input the number of data points to be			
	stored during program operation.	data	[R/S]	NAME?
4	Input the name or code that identifies			
	the channel (6 character maximum).	name	[R/S]	ALARM/HMS?
5	Input the time interval of the first			
	alarm on channel 1. (Can be either a			
	control alarm or message alarm where the			
	message is the channel name).	HH.MMSS	[R/S]	RESET
6	Input the RESET interval.	HH.MMSS	[R/S]	PRGM?
7	If the alarm is a control alarm, input			
	the name of the peripheral function			
	or program name that is to be activated.	prgm	[R/S]	
	If the alarm is a message alarm.	no input	[R/S]	channel name
8	To set further alarms on the same channel.		[R/S]	ALARM/HMS?
	Return to step 5.			
9	To start any channel timer 1 - 4:	ch. (4)	[shift][b]	NAME?
	Return to step 4.			
10	To add alarms to a channel that has already			
	been initialized.	ch. (n)	[shift][c]	NAME?
	The channel name may be changed, if			
	desired, by keying in a different name.			
	Note: When adding intervals to timers			
	that are currently running, it is			
	important to remember that they are time			
	offsets from the original start time.			

STEP	INSTRUCTIONS	INPUT	FUNCTION	DISPLAY
	To avoid past-due alarms, input the initial			
	alarm HH.MMSS so that it will occur at a			
	future time and input the rest HH.MMSS			
	equivalent to the required cycle. For			
	example, if the timer has been running			
	for (m) hours and the alarm must activate			
	every (n) hours, the first interval must			
	be (m) + (n) hours. The reset will be			
	(n) hours. Input channel identification			
	if change desired.	name	[R/S]	
11	To clear an alarm that has been set by			
	the program.		[XEQ]"ALMCAT"	
	Alarms must be cleared manually in			
	ALMCAT mode.			
12	To store time-related data interactively.		[XEQ]"DATA"	CHANNELS?
	Input the channel number 1 - 4.	ch. (n)	[R/S]	NOTES?
	Input a descriptive alpha note, up to			
	12 characters in length.	notes	[R/S]	DATA?
	Input any numeric data or measurement			
	taken at the time "split".	data	[R/S]	
13	To view or print data	ch. (n)	[C]	(channel name)
	View elapsed time		[R/S]	nn:nn:nn.nn
	View notes		[R/S]	(notes)
	View data		[R/S]	data (appears in
				aipna and x)
14	To continue sequentially:		[R/S]	
	It is not necessary to press [R/S] if a			

STEP	INSTRUCTIONS	INPUT	FUNCTION	DISPLAY
	printer is in the system. Display will			
	continue until no more data is found filed			
	under the channel number and the display			
	"END" is seen.			END
15	To clear the entire data file and reset			
	the index to the first record.		[shift][e]	Ø.ØØØ
16	To display a running time for any channel,			
	user must manually go into SW mode to see			
	running time.	ch. (n)	[E]	SYNC()R()
	To avoid overwriting valuable data by			
	accidentally storing splits (pressing			
	the ENTER key) while in the SW mode,			
	manually set the SW pointer to the value			
	of "R" displayed in the alpha register.		[XEQ]"SW"	nn:nn:nn.n
	Note: If splits are desired and stored at			
	the pointer address displayed in the alpha			
	registers, those splits cannot be read			
	by function [c] which expects data to			
	be formatted by label "DATA".			
17	To determine the constant to be inserted			
	in place of line 215 in the "4CON" program			
	a temporary change must be made in the			
	program itself.		[GTO] .219	
			[PRGM]	
			[XEQ]"STOPSW"	
			[R/S]	
	After keying in the additional two lines			

STEP	INSTRUCTIONS	INPUT	FUNCTION	DISPLAY
	of code "STOPSW" and "STOP".		[XEQ]"PACK"	
		0	[XEQ]"SETSW"	
		1	[E]	
	Place the calculator in SW mode [XEQ]"SW"			
	and read the display. The displayed value			
	will replace line 215. Be sure that the			
	procedure has been performed more than			
	one time for accuracy and that the stop-			
	watch was initially cleared each time.			

01+LBL "4CO		48 STO 10	
И"		49 +	
02 TIME		50 CF 23	
07 STO 01	Store clock time to ini-	51 "NAME? "	Input channel ALPHA
00 010 01 04 CTO 02	tialize all 4 channels.	52 ARCL IND	i.d.
04 310 02 05 cto 07	Channel numbers and	v	
05 510 03	register numbers cor-	57 00W	
06 510 04	respona.	54 CTOP	
07 DATE		54 STOP	
08 STO 11	Store starting date for	55 HUFF	
09 STO 12	all channels. Will be	56 FS?C 23	
10 STO 13	used by Label U8 to	57 ASTO IND	Store in register channel
11 STO 14	time and add n(days)	X	(n)+22
12 CF 02	* 24 to total	58+LBL 01	
13 CF 03	Clear channel flags	59 "ALARM/H	Input alarm interval
14 SE 27		MS?"	•
15 4		60 CLX	
12 970 04	Store Flag 04 in flag	61 PROMPT	Default=0
10 310 00 17 #DOTO V2	register (Ub) to over-	62 X=02	No input?
17 "DHIH X?	existent flag	67 CTO 04	Exit
"		44 STO 08	Save temporarily
18 PRUMPI	Input number of data	25 "DECET?"	
19 5	points	65 "RESEL?	
20 *	Data points *5+26 addi-	66 LLX	Default=0
21 26	tional registers	67 PRUMPI	
22 +	Calculate index for	68 STO 09	Save reset
23.1	'DATA' routine	69 CF 23	
24 %	÷1000	70 "PRGM?"	Test input
25 26		71 AON	Control alarm?
26 +		72 STOP	
27 970 05	Save index in R05 in	73 AOFF	
20 010 03	case it will be used	74 FC?C 23	If not a control alarm.
20 ULH 20 0CT0 27	again	75 GTO 02	then get the name of
29 HSTU 23		76 ASTA X	the channel
30 HSIU 24		77 OSHE	Save the control alarm
31 HSTU 25		70 OCTO V	name in stack and put
32 ASTO 26		70 H310 I	ALPHA then append
33 XEQ e		79 °11°	name
34 1	channel 1 go to alarm	80 HRLL X	
35 GTO c	mpatroatine	81 HRCL Y	
36◆LBL b	Start channel (n) whose	82 GIU 03	Go to time offset routine
37 TIME	number is in X register	83+LBL 02	Get channel name for
38 STO IND	Corresponding register	84 CLA	default message
Y	Corresponding register	85 RCL 06	
		86 RCL 10	
40 PCI 7	Calculate register address	87 +	
40 KGE 2	of date, ch.(n) in Z	88 ARCL IND	
41 T 40 DOTE	register	X	
42 DHIC 47 OTO IND	Save start date	89♦LBL 03	Time offset routine
43 510 IND		90 DOTE	
Y	Gat flag and shannal	91 RCL IND	Clock time
44 LHSTX	number back	06	
45+LBL c		00 00 170 CD	
46 XEQ 09	Add alarms to a running	72 KUL 80 07 UMC:	+ alarm interval (time
47 22	umer channel	93 HIST	offset)

94	ENTER [↑]		142 X≠Y?	Compare to channel
95	ENTER [↑]		143 GTO 05	Try again
96	24	Number of hours	144 ISG 08	Format elpased time
97	-		145 RCL IND	display
98	INT	and much an of days	08	Get 2nd register of
àà	DOTE	and number of days	146 ADV	
100	XXXX		147 CLA	2nd register=elapsed time
101	DOTE+		148 ATIME24	
101			149 AVIEW	ALPHA null string for
102			150 CL8	comparison
103	24		151 OSTO X	
104	*		152 ISC 08	
105	51- 2		157 PCI IND	Got first 6 observators of
106	ULX	DOOmenant		ALPHA note
107	RCL 09	RU9=reset	154 ICC 80	
108	X<> Z	Place XYZAL M para-	134 136 00 166 V_V2	If no message, then skip
109	XYZALM	meters in stack in	100 8-17	blank display
1104	▶LBL 04	correct sequence	156 610 07	
111	RCL 06		157 HRCL X	Else, get entire string
112	RCL 10	Display routine	158 ARCL IND	
113	+	Channel number +22=	08	
114	RCL IND	ALPHA name	159 AVIEW	
×			160+LBL 07	Continue display
115	RTN		161 ISG 08	
116	RCL 06	Continue storing alarms	162 RCL IND	
117	GTO 01	on this channel	08	Get 5th register of record
1184	HBL C	Recall data records	163 ISG 08	
119	RCL 10	Get name of channel	164 CLA	
120	X<>Y	(file)	165 ARCL X	
121	+		166 X≠0?	Display if not 0 place in
122		Display or print	167 AVIEW	ALPHA register to
· · · ·	VIEW IND		168 GTO 06	maintain uniform
107	LOCTY	Channel number	169+LBL "DAT	print format
123		Clear old flag, display	A	Store data interactively
124	AEQ 07	channel on annunci-	170 TIME	
125	RUL 10	ator	171 TONE 9	Get time immediately
126	RUL Ør	R10=22	172 "NO DOOM	Feedback
127	FRU	RU/=Index	" "	End of file
128	+	(highest register)	177 ISC 07	
129	510 08	Initialize R08 as recall	173 134 87 174 "CHONNEL	Increment storage index
130	FIX 6	index	Du CHANNEL	Which timer?
131	LBL 05	Get every 5th register	: 175 DDOMDT	
132	5		175 FROMFT 176 VEO 00	
133	ST+ 08	Enable printer or force	176 AEW 07 177 CTO IND	Go to flag update routine
134•	▶LBL 06	AVIEW	177 STU IND 07	
135	SF 21	Error ignore	97 170 CF 20	Flag 00 will enable
136	SF 25	No more data or no data	178 SF 00 170 0750	subroutine return
137	"END"	tound Got first register of	179 X()Y	
138	RCL IND	'DATA' record	180 XEQ 08	Gosub elapsed time
0 8		Compare to channel	181 ISG 07	calculation
139	RCL 06	number	182 STO IND	Store ET in 2nd register
140	FC?C 25	IT a nonexistent register	07	
141	PROMPT	chea, ena or file	183 ISG 07	

184 "NOTES?"	Input up to 12 charac-	230 RCL 07	
185 CF 23	ters to name or	231 INT	
186 AON	describe data	232 1	
187 STOP	Test for input	233 +	
188 AOFF	If no input routine	234 OPCI X	Jutput: Synchronize
189 FC2C 23	would store 'NOTES?'	275 OVIEU	channel (n): set pointer
190 010	string, so CLA	233 HVIEW	to R(nn)
101 OCTO IND		230 KIN	
171 H310 IND	Save note	237VLBL 07	5 byte sequence called
07 100 00UE		238 CF IND 0	Clear previous flag (at
192 HSHF		6	initialization set to 04
193 ISG 07		239 STO 06	to avoid possible error
194 ASTO IND		240 SF IND X	If nonexistent or
07	Any numeric data or	241 RTN	Set current channel
195 "DATA?"	measurement?	242+LBL e	annunciator. These
196 CLX	Default=0	243 RCL 05	flags are not tested,
197 PROMPT		244 STO 07	only displayed
198 ISG 07		245 ISG X	Clear block of registers
199 STO IND		246 0	fuleas local AI PHA
07		240 0 24741 DI 10	label only if block will
200 PTN		247¥LBL 10 240 CTO IND	be used, dumped to
200 KIN	Synchronize stopwatch	248 510 180	storage medium and
201+LBL E	to channel (n) whose		index restored on com-
202 LF 00	number is in X	249 ISG Y	pletion
203 XEQ 09	Lindate channel flag	250 GTO 10	O registers bbb-eee
204 RUNSW	Set	251 END	
205 TIME	Set stopwatch on the		
206+LBL 08	fly		
207 RCL IND	Routine written into		
Y	label search time on		
208 HMS-	first execution if it		
209 RCL 06	were a subroutine		
210 10	Search time would make		
211 +	inaccurate		
212 PCL TND	Get date timer channel		
V KOL IND	started		
0 017 DOTE	_		
213 DHIE	Current date		
214 DDH15	Positive difference		
215 24	Max. number of hours		
216 *			
217 RCL Z	Plus time difference		
218 HMS+	=total number of hours		
219 FS?C 00			
220 RTN	If called by 'DATA'		
221 158 E-6	routine, return		
222 HMS+	Time taken by lines 199		
223 1 E2	through 219 must be		
224 MOD	Avoid data error when		
225 SETSW	stopwatch is set		
226 FIX 0	Format prompt		
227 "SYNC "	. ormat prompt		
228 DRCL 06	Get 'DATA' index and		
220 MRUL 80 220 HL DH	truncate to calculate		
227 F K"	last used register		

PROGRAM DESCRIPTION

LOGBOOK

"Logbook" uses the HP 82180A Extended Functions/Memory Module to store the name and times worked for accounts that are billed at an hourly rate. Additionally, purchase order numbers, billing codes and remarks can be stored without regard to their length or format. The starting time and date for each account is saved in an ASCII file and requires no data register to maintain. Files can be printed or viewed at any time and total time worked can be updated on a daily basis. Access to stored information is by account name or the first few letters of the name. The program is useful in professional offices and any application where time must be stored in a flexible format.

"Logbook" consists of four main parts:

- 1. Create File
- 2. Start Clock
- 3. Stop Clock
- 4. Output

"\$TIME" initializes an ASCII file by prompting for the file name, number of accounts and number of days to be recorded. Sixty characters are allowed for the account name and description and 9 characters each for time and date. Including file overhead, the calculation of approximate file size is: (number of accounts * 60) + (number of accounts * (number days + 1) * 20) + 30. A scratchpad space is created in each file to store the starting time of each job. This means that the user need not be concerned with data being erased by other programs or constant updating of magnetic cards. Only the file name and the first few characters of the account name are required to access the time data.

Label "B" starts the timer for each account. The start time (clock) and date is immediately stored in main memory scratch registers and the user is prompted for the file name and account name. Only the first few unique characters of the account name need to be input to locate the account in the ASCII file, a process considerably faster than label search or data recall and comparisons.

Label "b" stops the time for the named account and displays the total elapsed time for the current day. The time is displayed in HH:MM:SS.hh format in the alpha registers and HH.MMSShh format in the Y register and decimal format in the X register for easy time/rate calculations. The elapsed time is inserted in the ASCII file at the bottom of the list.

Label "C" prints or views the account name and descriptive data and chronologically outputs each date and time worked for the account. The data is formatted in the alpha register and in HH.MMSShh and decimal format in the Y and X registers. At the end of the list the total time worked is output.

OPERATING LIMITS AND WARNINGS

Character number 95 "_" should not be used in any input alpha string as the program interprets that character as an end of account record delineator. Using substantially more descriptive characters than 60 may cause the file to reach the end prematurely. If more characters are required, then change line 05 of the program accordingly.

SAMPLE PROBLEM

An accountant will be working in the offices of two of his clients on three successive days. As time worked is charged at an hourly rate, a convenient way of logging the time worked including travel time would be helpful.

DISPLAY	INPUT	FUNCTION	
Load the "\$TIME" pr	ogram		
Initialize the prog	ram	[XEQ] "\$TIME"	
N ACCTS?	2	[R/S]	
N DAYS?	3	[R/S]	
FL NAME?	\$TDEMO	[R/S]	
NAME?	NICHOLAS NABIL	[R/S]	
CODE?	JOB NO 97321-4.5	[R/S]	
REMARKS?	BUILDING WRECKERS	[R/S]	
NAME?	BENJAMIN ELIAS	[R/S]	
CODE?	JOB NO 97330-2.5	[R/S]	
REMARKS?	PLUMBING CONTRACTORS	[R/S]	
The ASCII file has this point, it woul	been created. If the file were t d look like this:	o be printed out at	
	NICHOLAS NABIL JOB NO 97321-4.5 BUILDING WRECKERS		
	0.000000 0.000000 Benjamin Elias Job no 97330-2.5 Plumbing Contractors		
	0.00000 0.000000		

The 0.000000 data represents the work spaces in the file. These spaces are overwritten by the start date and time whenever function [B] is used. The following routine will print or view the entire ASCII file. LBL "PA" 01 02 SF 25 03 SF 21 04 CLX SEEKPTA 05 06 LBL 01 GETREC 07 80 FS? 25 09 AVIEW 10 FS? 25 GTO 01 11 12 END DISPLAY INPUT FUNCTION To provide a reasonable time for this example, use the T+X function of the the HP 82182A Time module to set your clock back four hours. [XEQ] "T+X" -4 Start the clock running for the first client to keep tract of travel time which is billed at a different rate than office time. [XEQ] "B" FILE NAME? If the ASCII file is your working file, no input is necessary. For this example, we will assume that the file "\$TDEMO" is not yet the working file. "\$TDEMO" R/S ACCT? NICHOLAS [R/S]The entire account or client name need not be input each time the file is accessed. The file will be positioned to the first occurrence of the string "NICHOLAS". START The display confirms that the clock has started running. Start the clock for the second client. [XEQ] "B" [R/S]FL NAME? BEN [R/S] ACCT? Advance your clock by one hour. Note that this is not part of the program. It is performed to give a typical output. [XEQ] "T+X" 1 Stop the clock for one client. [XEQ] "b" FL NAME? [R/S]ACCT? NICHOLAS [R/S] 01:05:00.00?

If your display has a sim correctly. Press [<] t This allows an immediate elapsed time in HH.MMSShh	nilar time-formatted output the to see the elapsed time in decin rate calculation if desired. In format where it may be used for	n you are running the example nal form in the X-register. Press [X<>Y] to see the or HMS+ addition if needed.
Start the clock for the f clients office.	first client to reflect the time	e spent working in the
		[XEQ] "B"
FL NAME?		[R/S]
ACCT?	NICHOLAS	[R/S]
START		
Now your clock can be adv necessary in order to rur appearance to the output	vanced to the correct time. No n this program. It simply give	te that this is not s a more realistic
	3	[XEQ] "T+X"
Stop the clock for this a if desired. Any account in the file pertaining to	account. The very first can be can be called by a second name o "NICHOLAS" can also be called	called by just one initial . For example, the records by inputting "NABIL".
		[XEQ] "b"
FL NAME?		[R/S]
ACCT?	NICHOLAS	[R/S]
03:00:00.0		
The actual time that is i running the example.	n your display will depend on	how long you spent
Print the files		[XEQ] "C"
FL NAME?		[R/S]
ACCT?	NICHOLAS	[R/S]
NICHOLAS NABIL JOB NO 97321-4.5 BUILDING WRECKERS 3.151982 1.013860 3.151982 3.003861 - - - 3.151982 14.382076 BENJAMIN ELIAS JOB NO 97330-2.5 PLUMBING CONTRACTORS - 3.151982 13.364754	If the entire ASCII file were printed, it would be similar to the printout at the left. If there is no printer in the system, [R/S] will advance the display to each successive line. Whenever a time is output as an alpha- numeric display, its decimal form will be in the X-register and its HMS form will be in the Y-registe	NICHOLAS NABIL JOB NO 97321-4.5 BUILDING WRECKERS 03/15/1982 01:01:38 03/15/1982 03:00:38 ======= 04:04:21

<u>STATUS</u>

SIZE	:	003
FIX	:	4, 6
TOTAL PROGRAM BYTES	:	381
ASCII FILE SIZE	:	(nA * 60) + (nA * n(D + 1) * 20) + 30
		7

DATA REGISTERS	
00	n(days) * 24
01	Start/Finish time; Loop control = n records/account (Label [c])
02	Start/Finish date

FLAGS USED		
21 S	et :	Printer enabled
C	lear :	Printer disabled
23 S	et :	Alpha data detected
С	lear :	No alpha data detected
55 S	iet :	Printer exists
C	lear :	No printer

<u>Label</u>	Function
"\$TIME"	Initializes a new file and prompts for variables
"b"	Stops the time for the named account and outputs total (stored)
"B"	Starts timer for named account
"C"	Prints/views file for named account, outputs file header information, each start date and elapsed time and total elapsed time

ASCII FILE RE	CORDS
0	Account name
1	Account code, billing number, purchase order, etc.
2	Remarks or description
3-4	Each succeeding pair of records contains a start date (MM.DDYYYY) in the first record and a total elapsed time (HH.MMSShh) in the second record
n	"_" character 95, delineates end of data space, start of work space
n	Start Date of running timer for this account
n	Start clock time (HH.MMSShh) of running timer for this account
n	Next account repeats the same format as the first account until the end of file

				SIZE: 003
STEP	INSTRUCTIONS	INPUT	FUNCTION	DISPLAY
1	Load program "\$TIME".		[GTO]	PACKING
2	Initialize program "\$TIME".		[XEQ]"\$TIME"	N. ACCTS?
3	Input the number of individual clients			
	or accounts that are to be timed.	n.accts	[R/S]	N. DAYS?
4	Input the number of days or times that			
	each account will be timed.	n.days	[R/S]	FL NAME?
5	Select a name for the ASCII file, up			
	to 7 characters.	fl name	[R/S]	NAME?
6	Input the name of the first account in the			
	file. Up to 60 characters are allowed			
	for the name and following 2 lines.	name	[R/S]	CODE?
7	Input the purchase order number, billing			
	code or any other descriptive text.			
	Note that only character 95 is illegal			
	in the file.	code	[R/S]	REMARKS?
8	Any descriptive text may be input. If no			
	remarks are required, press [R/S].	remarks	[R/S]	NAME?
9	If the ASCII file is to contain more than			
	one account, the prompt "NAME?" will			
	recur as many times as are necessary.			
	Return to step 6.			
10	To start the clock for any account:		[B]	FL NAME?
11	If the ASCII File is the working file			
	(refer to HP 82180A Extended Functions/			
	Memory Module owner's manual for a			
	description of the "Working File"), then			
	no input is necessary. If not, or you			
STEP	INSTRUCTIONS	INPUT	FUNCTION	DISPLAY
------	--	---------	------------	------------
	are uncertain:	fl name	[R/S]	ACCT?
12	Input the name of the account to be timed.	acct	[R/S]	START
13	To stop the clock for any account.		[shift][b]	FL NAME?
13a	Input the file name if it is not the			
	working file.	fl name	[R/S]	ACCT?
13b	Input the name of the account being timed.	name	[R/S]	nn:nn:nn.n
14	All of the named accounts may be timed			
	independently and started or stopped			
	as necessary. However, for each account,			
	only one starting time is stored until			
	the clock has been stopped and restarted.			
	If you start and stop the clock more			
	times than the number of days or times			
	inputted at initialization (step 4), the			
	file may become prematurely full and			
	not accept further data.			
15	Error recovery. If a timer was stored			
	accidently, it is not necessary to correct			
	the error. Simply restart the individual			
	timer when ready and the new time will			
	replace the previous starting time.			
	Refer to step 10 to start.			
16	To display the timer data stored under			
	a particular account name:		[C]	FL NAME?
16a	Input the file name if the file is not			
	the working file.	fl name	[R/S]	ACCT?
16b	Input the name of the account. If the			

STEP	INSTRUCTIONS	INPUT	FUNCTION	DISPLAY
	name begins with distinctive characters			
	that are not repeated elsewhere in the			
	file, only the first few characters need			
	to be inputted.	name	[R/S]	name
				code
				remarks
				date
				HH.MMSS
	The elapsed time for the displayed date			
	is also in the Y-register in HMS format			
	and in the X-register in decimal form.			
	When each complete cycle has been			
	displayed or printed, the total elapsed			
	time will be output preceded by:			
				HH.MMSS
	If a printer is not in the system, it			
	will be necessary to press [R/S] to			
	advance the display.			

			·····
01+LBL "\$TI		50 ARCL X	
ME "		51 APPREC	Accumulate two records
02 "N ACCTS		52 APPREC	of zeros to mark the
?"		53 RTN	work (scratchpad) space
03 PROMPT		54+LBL b	
04 STO 00	Temporary storage for	55 TIME	Immediately saves time
05 60	file size calculation	56 XEQ 02	for accuracy
 Йб ж	Allow approx. 60 char-	57 GETREC	Gosub to store time and
07 "N 10792	acters for description	58 ONLIM	date in main memory
	and name	50 NOTE	Set display mode and
GO DDOMDT		20 DHIC	position file
		66 DDA13	Convert first date to
10 1	Add one day to allow for	61 1	numeric data
10 +	overhead and scratch	62 -	ii days
11 RLL 00	registers	63 24	Number of hours calcu-
12 *		64 *	lation
13 20	Allow 9 characters for	65 STO 00	Temporary
14 *	each time and date and	66 X<>Y	Swap with previous
15 +	record	67 1	pointer value
16 30	Allow 30 characters for	68 -	
17 +	overhead	69 SEEKPT	
18 7		70 INSREC	Insert time into next
19 /	Number of registers	71 3	space in file
20 INT	-	72 +	
21 XEQ 07	Gosub file name	73 SEEKPT	
22 CRFLAS		74 GETREC	Get time of start clock
23+LBL 00	Create ASCIT file	75 24	from scratch space
24 XEQ 01	Go to input prompt	76 ANUM	Convert to numeric data
25 DSE 00	routine once for each	77 HMS-	
26 GTO 00	account	78 RCL 01	
27 RTN		79 HMS+	n nours in current day
28+1 BL 01		80 RCL 00	
29 "NOME?"	to initialize accounts in	81 +	\pm number of days ± 24
30 ONN	file	82 010	i number of days * 24
71 STOP		97 OPCI X	
72 OPPDEC		00 HKCE A 04 V/\V	
77 "CODE2"	Place in successive records	07 ////	
74 CTOD		05 2	
34 310F 75 0000FC		00 - 07 CEEKDI	
33 HFFKEU 74 of 97	Test for inset was also	ON SEENFI	
30 LF 23 77 #DEMODVC	Test for input remarks	88 INSKEU	file
ST "REMHRKS		89 KUN 00 Eutera	
		90 ENTERT	Load stack
38 SIUP		91 LLH	
39 FC?C 23		92 HIIME24	Format printer display
40 ""	Store default message to	93 HR	
41 HPPREC	of records	94 HVIEW	Leave decimal value of
42 AOFF		95 RTN	calculations
43 CLA		96+LBL B	Start alock
44 95	Place underscore charac-	97 TIME	
45 XTOA	data space as end of	98 TONE 9	immediately for accuracy
46 APPREC	account delineator	99 XEQ 02	Gosub temporary storage
47 FIX 6		100 CLA	and file position
48 CLX		101 ARCL 01	Insert 6 digit unformatted
49 CLA		102 INSREC	(numeric) date in scratch space

103 CLA		156 CLA	
104 ARCL 02		157 ATIME24	Format time
105 INSREC	Insert time in scratch	158 HR	Leave decimal value of
106 2	59400	159 XEQ 05	time in X for calculations
107 +		160 RCL 00	
108 SEEKPI		161 HMS+	Running total of elapsed
109 DELREC	times Insert must be	162 STO 00	lines
110 DELREC	performed before de-	163 DSE 01	
111 "STHRT"	letion to prevent insert	164 GIU 03	
112 PRUMPT	at end of file from be-	165 "======	Signify addition
113+LBL 02	Confirm action		
114 SIU 01 115 DOTE	Temporary storage of	166 XEQ 05	
115 DHIE 116 CTO 00	user is prompted for	167 RUL 00	Print or view
116 510 02	file name prevents loss	168 LLH	
117 FIX 6	of data in stack	169 HIIME24	
110 AEM 00 110 AE	of time/date data	170 ENTERT	Leave decimal form of
117 7J 120 VTOO	Prompt account name,	171 HK 172 CTO OF	X register
120 ATOH 121 DAGEL	return -1 if misspelled	172 610 05	Last portion, RTN not
122 1	space by finding char-	173VLDL 04 174 VEO 04	necessary
127 +	acter 95	174 AEQ 04 175 VEO 04	Speeds loops and saves
123 - 124 SEEKPT	Desition files and the	175 AE& 04	I byte
125 PTN	pad area	177 CETPEC	
126 + I BI C		170ALDI 05	
127 SE 21	Routine to display time	179 522 55	If printor
128 XEQ 06	halt on AVIEW	180 PPO	n printer
129 95	Prompt account name	181 FC2 55	If not
130 XTO9	Position to scratch	182 OVIEW	11 hot
131 POSEI	space defineator	183 RTN	
132 RCL Z	-	184+I BI 06	
133 -	-	185 XEQ 07	Gosub file name
134 3	Subtract 3 records for	186 CLX	
135 -	file descriptive data	187 SEEKPT	Go to top of file
136 2	Divide into pairs	188 "ACCT?"	
137 /		189 AON	ALPHA mode
138 STO Ø1	-	190 STOP	
139 RCL Z	Set index for loop	191 AOFF	
140 SEEKPT	-	192 POSFL	
141 XEQ 04	Print/view loop will	193 X<0?	If not found, indicate
142 ADV	execute three times	194 STOP	error
143 CLX	•	195 CLA	
144 STO 00	ł	196 RTN	
145+LBL 03		197+LBL 07	
146 FIX 6	Full precision format	198 CF 23	
147 GETREC		199 "FL NAME	
148 ANUM	Convert to numeric data	?"	
149 CLA		200 AON	
120 HDHIF	Format printer display	201 STOP	
151 XEQ 05		202 AOFF	
152 GETREC		203 FC?C 23	lest input, if no input,
133 HNUM 154 ENTERA	Lood X and X with the	204 ULH	to working file
154 ENTERT 155 FIX 4	Load X and Y with time Sufficient precision for time display	205 .END.	-

PROGRAM DESCRIPTION

PLAYBACK PROGRAMMABLE TIMER

This timer may be interactively programmed to playback a series of messages or run user-defined programs at specified intervals. The program's features include compatibility with any HP-41 mass storage device and routines to store, recall, save and edit playback segments. Manual and auto playback modes are available.

"Playback" uses three control alarms to perform timing functions:

1. A control alarm which calls routine "NM" (next manual) is set in manual mode. It is used to start the playback and works by storing time in an accumulator register, R00, and setting the control alarm to activate relative to that time. The display flag annunciator for Flag 00 signifies manual mode.

2. Label "NA" (next automatic) is the control alarm entry point in the auto mode. In this mode, no visible flag is seen. Label "NM" falls through "NA" during its execution. "NA" does not store a new starting time with each playback step, but references all time offsets to the starting time of the first step, increments the step counter and continues until the last record.

3. Label "T" activates a periodic tone of a frequency chosen by the user during initial input and variable for every step. Period must be less than the step period and greater than 6 seconds to avoid the possibility of a past due alarm due to slow processing or search through a long table of global labels.

4. Label "AR" (called in the program as label 10 is the "ALMREL" program in the HP 82182A Time Module Owner's Manual. It is given a global label to enable it to be called as a subroutine in a user-defined program.

A NOTE ON INPUT

Invalid erroneous inputs must all be trapped to prevent playback errors. Tone intervals longer than the step interval, or short enough to cause a past due alarm, and failure to input a playback message or program name are examples of such inputs. If invalid inputs are detected, the input prompt is repeated.

User-defined programs are detected by the presence of zero in the first register of the step record. A flag is set, the next alarm set and the balance of the playback sequence skipped. The user function or program is addressed by an indirect GTO. It becomes a subroutine by virtue of being called by a control alarm. In other words, the user program will be executed and finished, and depending upon its structure, will wait until the alarms "NA" or "NM" are activated.

"Playback Programmable Timer" may be used in a variety of applications and amusements including children's games and activities, photographic darkroom, calisthenics and warm-up exercises, laboratory experiments, baking bread, debates (speaker name 1, speaker name 2, rebuttal 1, rebuttal 2, etc), timing dramatic scripts and routines, prompting signposts and speed changes in auto rallyes, timing long distance phone calls.

SAMPLE PROBLEM

This example will require a minimum SIZE of 3 registers. Program the "Playback Programmable Timer" to display a series of five flexibility exercises. Two of the steps require a faster cadence than the pace available in the program. Three of the steps will sound a tone every ten seconds indicating a change of direction.

DISPLAY	INPUT	FUNCTION
Initialize the prog	ram	[XEQ] "PB"
N STEPS?	5	[R/S]
MESSAGE?	BODY TWISTS	[R/S]
STEP HMS?	.01	[R/S]
TONE/HMS?	.001	[R/S]
TONE N?	9	[R/S]
MESSAGE?	FOOT CIRCLES	[R/S]
STEP HMS?	.003	[R/S]
TONE/HMS?	.001	[R/S]
TONE N?	8	[R/S]
MESSAGE?	no input	[R/S]
PROGRAM?	FASTP	[R/S]
STEP HMS?	.01	[R/S]
MESSAGE?	CALF STRETCH	[R/S]
STEP HMS?	.0045	[R/S]
TONE/HMS?	.001	[R/S]
TONE N?	7	[R/S]
MESSAGE?	no input	[R/S]
PROGRAM?	FASTP	[R/S]
STEP HMS?	.003	[R/S]
END		
Recall the Playback	series to confirm correct er	itry.
	1	[0]
1=BODY TWISTS		[R/S]*
HMS=00:01:00		[R/S]*
TN 9/00:00:10		[R/S]* [R/S]
2=FOOT CIRCLES		[R/S]*
HMS=00:00:30		[R/S]*
TN 8/00:00:10		[R/S]* [R/S]
3=PRGM, FASTP		[R/S]*

DISPLAY	INPUT	FUNCTION
HMS=00:01:00		[R/S]* [R/S]
4=CALF STRETCH		[R/S]*
HMS=00:00:45		[R/S]*
TN=0/00:00:10		[R/S]* [R/S]
5=PRGM, FASTP		[R/S]*
HMS=00:00:30		[R/S]*
Load the fast-pace program,	"FASTP".	
Initialize the Auto Run "Pla	ayback" mode.	
		[E]
If "AUTO" is not seen in the	e display, try again.	
		[E]
		[R/S]
[AUTO]		
01+LBL "FAS TP" 02 CF 02 03 23 04 RCL 03 05 X <y? 06 SF 02</y? 	Initialize flag not Test recall index to if earlier or late of "FASTP"	used by "PB" o determine r occurrence
07 11 08 ENTER↑ 09 FS?C 02 10 + 11 STO 09 12 RUNSW 13 2 E-4 14 TIME	Earlier, one minute RO9 unused by "PB"	timing
15 HMS+ 16 SETSW 17 "↑↑FP" 18◆LBL "FP" 19 TONE 9 20 CLST	Apply 2 second time stopwatch for fast Control alarm entry Control alarm	offset to loop point
21 RCLSW 22 DSE Ø9 23 XYZALM 24 END	Initialize the stac without reset	k for alarm

STATUS		
SIZE	:	n * 4 + 11
FIX	:	0,4
TOTAL PROGRAM BYTES	:	538
USER MODE	:	ON

DATA REGISTERS	
00	Total time, run message
01	Total time, run tone
02	Store index
03	Recall and run index
04	Edit, then restore index to RO2, indirect tone in run mode
05	Alpha message for playback
06	Alpha message, next six characters
07	Recall n, (Label C), tone HH.MMSS
08	DSE index for tone, label "T"
09-10	Available for user program
11	Alpha message, first six characters
12	Alpha message, last six characters NOTE: O if user program optioned program name, indirect GTO
13	Step HH.MMSS, total time until start of next step
14	Tone pitch, 1 to 9 - decimal point - tone cycle .MMSS
15	Begin next record (step two)

F	LAGS USED			
	00	Set	:	Manual mode
	04	Set	:	Edit mode
	05	Set	:	Skip tone input if a user-defined program
	06	Set	:	Run user's program Don't run the user's program
	07	Set	:	No tone Tone
	08	Set	:	First pass - skip prompt All other cases - allow prompt
	21	Set	:	Printer enabled Printer disabled
	23	Set	:	ALPHA input detected
	25	Set	:	No error detected
	55	Set Clear	• : :	Printer exists No printer
1				

Label	FUNCTION
"B"	Store playback message and parameters
"C"	Recall playback message and parameters
"D"	Edit playback message and parameters
"E"	Toggle Auto or Manual mode, initialize run

				SIZE: 4n+11
STEP	INSTRUCTIONS	INPUT	FUNCTION	DISPLAY
1	Load program "PB". Set User Mode.		[USER]	
2	Initialize "PB".		[XEQ]"PB"	N STEPS?
	Input number of steps or instructions.	n	[R/S]	MESSAGE? or
				RESIZE = (nn)
	If necessary, resize and start over.			
	The size is determined by multiplying			
	the number of steps by 4 and adding 11.			MESSAGE?
3	Input message to be played back, up to			
	12 alpha characters.	message	[R/S]	
	If no message is to be run, but rather			
	a program.	no input	[R/S]	
4	Key in the name of your playback program.	program	[R/S]	STEP HMS?
5	Input the length of time that the			
	message or program message is to be			
	displayed.	HH.MMSS	[R/S]	TONE/HMS?
6	If a periodic tone is wanted, input the			
	time interval.	HH.MMSS	[R/S]	TONE N?
7	Input tone pitch, from 0 to 9.	n	[R/S]	MESSAGE?
8	Return to step 3 of instructions			
	until done.			
9	To recall input steps at any time,			
	starting with nth step.	n	[C]	n= ()
	To continue viewing step.		[R/S]	HMS= (nn:nn:nn
	Note: [R/S] is not necessary with a			
	printer attached.		[R/S]	TN n/(nn:nn:nn)
10	To view following steps.		[R/S]	TN n/(nn:nn:nn)
11	To correct or change any step.	n	[D]	MESSAGE?

STEP	INSTRUCTIONS	INPUT	FUNCTION	DISPLAY
12	Refer to step 3 of instructions for input			
	parameters. Once edit is started, follow			
	through entire step or subsequent steps			
	will be stored in unplanned locations.			
13	The entire playback sequence may be			
	saved on any HP-41 storage medium.			
	Magnetic cards:		[RCL] 02	
			[FRC]	
			[WDTAX]	
	Mass storage, such as HP 82161A Digital			
	Cassette Drive:		[ALPHA] YOUR	
			FILE NAME	
			[ALPHA] 1000	
			[RCL] 02	
			[FRC][*]	
			[CREATE] O	
			[SEEKR]	
			[LASTX]	
			[WRTRX]	
14	To play back the stored messages:		[E]	AUTO OR MANUAL
	If the desired mode is not seen,			
	press again.		[E]	
	Auto mode will cycle continuously from			
	step to step after starting. Manual mode			
	requires the user to restart at each step.		[R/S]	
15	Guidelines for user-defined programs to			
	be run in place of playback messages:			

STEP	INSTRUCTIONS	INPUT	FUNCTION	DISPLAY
	Run time of user program should not			
	exceed the programmed step time.			
	Five levels of subroutines are available.			
	Registers 9 and up are available for			
	data storage.			
	Flag 21 should not be set unless a printer			
	is present, flag OO should not be used,			
	nor should flag 26 or 27.			
	The program should not use the T+X			
	function nor any other functions that			
	will interfere with the operation of an			
	HP 82182A Time Module based program.			
	The stack and alpha registers are			
	available for program use.			
	Do not use the function OFF.			
	The global label should not have more than			
	6 characters for indirect addressing.			
	Avoid key assignments to the top row of			
	user keys.			

		44 *******	· · · · · · · · · · · · · · · · · · ·
ØI T LBL "PB"		46 "PROGRAM	
02 "N SIEPS	Number of steps required	·?"	Input program name if
?"	to calculate index	47 STOP	chosen in place of
03 PROMPT		48 FC? 23	If no input here, cycle
04 4	Each step record consists	49 GTO 01	back to message prompt
й5 *	of 4 registers	50 SE 05	If program name input.
06 11	Add 10 housekeeping	51+1 BL 02	skip tone prompt
00 II 07 ±	registers	52 0055	Store message or program
07 T 00 #DECIZEN		52 HOFF 57 CTO IND	name, first part is in X,
08 "RESIZE/	Format size prompt	03 510 IND	If program name x=0
="		02	
09 FIX 0		54 ISG 02	
10 ARCL X		55 FC?C 23	
11 1		56 ASHF	
12 -		57 ASTO IND	
13 SF 25		02	
14 STO IND	Test for existence of	58 ISG 02	
X	highest number R	59 "STEP HM	lumit dan din s
	required	92°	
10 FC: 20		20 DDOMDT	
16 FRUNFI 17 5000 05	Display if necessary	60 FROMFI	C
17 FL?C 20		61 510 IND	Save in next register, 3rd register of step
18 GIU "PB"	Repeat initialization	02	record
19.1	prompts it size in-	62 CLX	
20 %	/1000	63 FS?C 05	Skip tone flag set?
21 10	,	64 GTO 04	
22 +	Add scratch registers	65+LBL 03	
23 STO 02	Save index	66 "TONE/HM	Tone interval desired,
24 0	Save muex	S2"	if any
25+1 BL 00		67 CLX	
267282 00 24 GTO IND		69 PROMPT	
20 310 IMD	Clear block of registers	20 V-02	No invest?
	garbage playback	07 A-0: 70 CTO 04	No input?
27 136 1	gui bugo più y buok	70 610 04	
28 GIU 00		71 6 E-4	b seconds is min. time
29+LBL B	Store routine	72 X>Y?	sible past-due alarm due
30 CF 04	Clear edit Flag	73 GTO 03	to slow processing or
31+LBL 20		74 X<>Y	label search
32 "END"			A I I I I I I I I I I I I I I I I I I I
77 100 00		75 RCL IND	Cycle back if error
33 ISG 02		75 RCL IND 02	Cycle back if error
33 156 02 34 GTO 01	Display END (no more	75 RCL IND 02 76 X<=Y?	Cycle back if error
33 156 02 34 GTO 01 35 PROMPT	Display END (no more data registers) if	75 RCL IND 02 76 X<=Y? 77 GTO 03	Cycle back if error Test if greater than step HMS
33 156 02 34 GTO 01 35 PROMPT 36+1 B1 01	Display END (no more data registers) if indexx=eee	75 RCL IND 02 76 X<=Y? 77 GTO 03 78 X<>Y	Cycle back if error Test if greater than step HMS Cycle back on error
33 156 02 34 GTO 01 35 PROMPT 36+LBL 01 37 CE 05	Display END (no more data registers) if indexx=eee	75 RCL IND 02 76 X<=Y? 77 GTO 03 78 X<>Y 79★LBL 04	Cycle back if error Test if greater than step HMS Cycle back on error Return input to X
33 156 02 34 GTO 01 35 PROMPT 36+LBL 01 37 CF 05 30 CF 05	Display END (no more data registers) if indexx=eee Flag 05 will be tested	75 RCL IND 02 76 X<=Y? 77 GTO 03 78 X<>Y 79◆LBL 04	Cycle back if error Test if greater than step HMS Cycle back on error Return input to X If no tone input prompted
33 156 02 34 GTO 01 35 PROMPT 36+LBL 01 37 CF 05 38 CF 23	Display END (no more data registers) if indexx=eee Flag 05 will be tested for 'skip tone input' on line 63	75 RCL IND 02 76 X<=Y? 77 GTO 03 78 X<>Y 79◆LBL 04 80 ISG 02	Cycle back if error Test if greater than step HMS Cycle back on error Return input to X If no tone input prompted execution resumes here Undate index
33 156 02 34 GTO 01 35 PROMPT 36+LBL 01 37 CF 05 38 CF 23 39 "MESSAGE	Display END (no more data registers) if indexx=eee Flag 05 will be tested for 'skip tone input' on line 63 Prompt message input	75 RCL IND 02 76 X<=Y? 77 GTO 03 78 X<>Y 79◆LBL 04 80 ISG 02 81 STO IND	Cycle back if error Test if greater than step HMS Cycle back on error Return input to X If no tone input prompted execution resumes here Update index
33 156 02 34 GTO 01 35 PROMPT 36+LBL 01 37 CF 05 38 CF 23 39 "MESSAGE ?"	Display END (no more data registers) if indexx=eee Flag 05 will be tested for 'skip tone input' on line 63 Prompt message input	75 RCL IND 02 76 X<=Y? 77 GTO 03 78 X<>Y 79◆LBL 04 80 ISG 02 81 STO IND 02	Cycle back if error Test if greater than step HMS Cycle back on error Return input to X If no tone input prompted execution resumes here Update index
33 156 02 34 GTO 01 35 PROMPT 36+LBL 01 37 CF 05 38 CF 23 39 "MESSAGE ?" 40 AON	Display END (no more data registers) if indexx=eee Flag 05 will be tested for 'skip tone input' on line 63 Prompt message input	75 RCL IND 02 76 X<=Y? 77 GTO 03 78 X<>Y 79◆LBL 04 80 ISG 02 81 STO IND 02 82 X=0?	Cycle back if error Test if greater than step HMS Cycle back on error Return input to X If no tone input prompted execution resumes here Update index
33 156 02 34 GTO 01 35 PROMPT 36+LBL 01 37 CF 05 38 CF 23 39 "MESSAGE ?" 40 AON 41 STOP	Display END (no more data registers) if indexx=eee Flag 05 will be tested for 'skip tone input' on line 63 Prompt message input	75 RCL IND 02 76 X<=Y? 77 GTO 03 78 X<>Y 79◆LBL 04 80 ISG 02 81 STO IND 02 82 X=0? 83 GTO 06	Cycle back if error Test if greater than step HMS Cycle back on error Return input to X If no tone input prompted execution resumes here Update index
33 156 02 34 GTO 01 35 PROMPT 36+LBL 01 37 CF 05 38 CF 23 39 "MESSAGE ?" 40 AON 41 STOP 42 ASTO X	Display END (no more data registers) if indexx=eee Flag 05 will be tested for 'skip tone input' on line 63 Prompt message input	75 RCL IND 02 76 X<=Y? 77 GTO 03 78 X<>Y 79◆LBL 04 80 ISG 02 81 STO IND 02 82 X=0? 83 GTO 06 84◆LBL 05	Cycle back if error Test if greater than step HMS Cycle back on error Return input to X If no tone input prompted execution resumes here Update index
33 156 02 34 GTO 01 35 PROMPT 36+LBL 01 37 CF 05 38 CF 23 39 "MESSAGE ?" 40 AON 41 STOP 42 ASTO X 43 FS?C 23	Display END (no more data registers) if indexx=eee Flag 05 will be tested for 'skip tone input' on line 63 Prompt message input No input?	75 RCL IND 02 76 X<=Y? 77 GTO 03 78 X<>Y 79+LBL 04 80 ISG 02 81 STO IND 02 82 X=0? 83 GTO 06 84+LBL 05 85 9	Cycle back if error Test if greater than step HMS Cycle back on error Return input to X If no tone input prompted execution resumes here Update index Tone 9 supplied as default
33 156 02 34 GTO 01 35 PROMPT 36+LBL 01 37 CF 05 38 CF 23 39 "MESSAGE ?" 40 AON 41 STOP 42 ASTO X 43 FS?C 23 44 GTO 02	Display END (no more data registers) if indexx=eee Flag 05 will be tested for 'skip tone input' on line 63 Prompt message input No input? Then try next possibility	75 RCL IND 02 76 X<=Y? 77 GTO 03 78 X<>Y 79+LBL 04 80 ISG 02 81 STO IND 02 82 X=0? 83 GTO 06 84+LBL 05 85 9 86 "TONE N?	Cycle back if error Test if greater than step HMS Cycle back on error Return input to X If no tone input prompted execution resumes here Update index Tone 9 supplied as default Promot nitch
33 156 02 34 GTO 01 35 PROMPT 36+LBL 01 37 CF 05 38 CF 23 39 "MESSAGE ?" 40 AON 41 STOP 42 ASTO X 43 FS?C 23 44 GTO 02 45 CLX	Display END (no more data registers) if indexx=eee Flag 05 will be tested for 'skip tone input' on line 63 Prompt message input No input? Then try next possibility	75 RCL IND 02 76 X<=Y? 77 GTO 03 78 X<>Y 79+LBL 04 80 ISG 02 81 STO IND 02 82 X=0? 83 GTO 06 84+LBL 05 85 9 86 "TONE N? "	Cycle back if error Test if greater than step HMS Cycle back on error Return input to X If no tone input prompted execution resumes here Update index Tone 9 supplied as default Prompt pitch

87 SF 25	Prepare to test parameter	177 V-00	
88 PROMPT		133 A-0? 174 ODCL IND	
89 TONE IND	Does tone exist?	134 HRUL IND 07	
×		00 175 ICC 07	
90 FC?C 25	If invalid parameter,	133 136 03 477 ODCL IND	
91 GTO 05	repeat prompt	136 HRUL IND	Display ALPHA message
92 ST+ IND	Add to time register	03 177 OUTEU	
N2	-	137 HVIEW	
93+IBI 06		138 156 03	
94 PCI 04	B02 was stored here at	139 FIX 4	Display step time
95 FS2C 04	beginning of routine, if	140 "HMS= "	
96 STO 02	this cycle was an edit,	141 RUL IND	
97 CTO 8	then restore original	03	
9841 BI D		142 ATIME24	
99 4	Continue	143 AVIEW	Display tang (n) in for
100 *	Edit routing	144 "TN "	mat: TONE n every
100 *	Eart routine	145 FIX 0	.MMSS
101 0		146 ISG 03	
102 T 107 DCL 00	Calculate beginning	147 RCL IND	
103 KUL 02 104 EDC	porary index	03	
104 FRC		148 INT	Integer part is tone pitch
100 +	Add end register and store temporary index	149 ARCL X	
106 X() 02	Exchange temporary	150 "⊢∕"	
107 510 04	index with actual index	151 LASTX	
108 57 04	and save	152 FRC	Fractional part is .MMSS
109 GIU 20	Bypass clear edit flag at	153 FIX 4	
110+LBL C	Label (B) entry point	154 ATIME24	
111 SF 21	Enable printer or halt	155 X≠0?	
112 CF 29	Display formatting	156 AVIEW	Only display if non-
113 510 07	Save step n to permit SST	157 RTN	meters exist
114+LBL 07	to next step on comple-	158 ISG 07	
115 HDV	tion	159 CLX	Add 1 to step number
116 RCL 07		160 GTO 07	continue sequentially
117 4	For printer	161+LBL E	
118 *		162 FC? 55	Initialize Playback, clear
119 7	Step n (4)	163 CF 21	Flag 21 to prevent halt
120 +		164 FC?C 00	and togole playback mo
121 RCL 02		165 SF 00	mode
122 FRC		166 "AUTO"	Toggle mode flag. Alter-
123 +		167 FS? 00	nate use of routine sets
124 STO 03	Calculate recall index	168 "MANUAL"	In 'AUTO' mode, play-
125 FIX Ø		169 AVIEW	back is continuous
126 CLA		170 10	In 'MANUAL' mode,
127 ARCL 07		171 RCL 02	playback stops after
128 "⊢="		172 FRC	every complete step
129 RCL IND	Get step n to format	173 +	Calculate recall index.
03	output display	174 STO 03	starting with first
130 SIGN		175 CF 06	playback record
131 X≠0?	Get first part of message	176 SE 08	Flag 06 will be tested
132 "HPRGM,		177 RTN	during playback for
••	Not ALPHA? Then	178+I BI "NM"	'run user program' on
	program name	1. 2 1 1 1 1 1 1 1 1 1 1	mode prompt

179 "RUN"	Control alarm entry	225 RCL IND	
180 FL/L 08		X	
181 PRUMPT	Skip prompt on first pass	226 HR	
182 JUNE 9	Audible feedback: Clock	227 RCL 2	ber of tope cycles not
183 IME	has started running	228 /	to exceed time of play-
184 510 00	Save start clock time	229 FIX 0	back step
185 510 01		230 RND	
186+LBL "NH"	Alarm 'Next Auto-	231 STO 08	
187 ISG 03	matically'	232 GTO 09	
188 GTU 08		233+LBL "T"	
189 "END"	End of playback	234 TONE IND	'Tone' control alarm
190 PROMPT		04	Audible
191+LBL 08		235+LBL 09	
192 CF 07	Clear tone flag	236 CLA	Get message and display
193 RCL IND	Get message or program	237 ARCL 05	
03	name	238 ARCL 06	
194 STO 05		239 FC? 06	Display only if message,
195 SIGN	SIGN test can test for	240 AVIEW	not program name
196 X≠0?	alpha characters whereas	241 RCL 00	
197 SF 06	if ALPHA requiring	242 FS? 07	If tone is part of playback
198 ISG Ø3	additional flag test	243 STO 01	step
199 RCL IND	Set 'get User program'	244 FS?C 06	
03	Tiag Get last 6 characters and	245 GTO IND	If User Program, run it
200 STO 06	save	06	
201 ISG 03		246 FS?C 07	If no tone, stop and wait
202 "↑↑NA"	Control alarm dependent	247 RTN	for next control alarm
203 FS? 00	upon status of Flag 00,	248 "↑↑T"	If tone, set tone control
204 "↑↑NM"	auto/manual	249 RCL 01	alarm for next occur-
205 RCL IND	Get step time	250 RCL 07	Tone interval
03		251 XEQ 10	
206 RCL 00		252 STO 01	Time offset subroutine
207 XEQ 10	Add to finish time of last	253 DSE 08	Save finish time of tone
208 XYZALM	step and calculate time	254 XYZALM	period for next occur-
209 STO 00	Offset pa Parameters in stack do	255 RTN	rence
210 ISG 03	Save finish time	256+LBL 10	Set alarm if index permits
211 RCL IND	Get tone parameters if	257+LBL "AR"	ALMREL time offset
03	any	258 HMS+	subroutine
212 X=0?		259 ENTER↑	Global label allows User program (Elag 06 set)
213 SF 07	Clear tone flag	260 ENTER↑	to use
214 X=0?	-	261 24	Label 10 as a subroutine
215 GTO 09		262 /	Calculate number of days
216 INT		263 INT	and set up stack with
217 STO 04		264 DATE	XYZ parameters
218 LASTX		265 X<>Y	
219 FRC		266 DATE+	
220 STO 07	Get tone cycle time	267 LASTX	
221 HR		268 24	
222 RCL 03		269 *	
223 1		270 ST- Z	
224 -		271 CLX	
		272 STO T	
		273 RDN	
		274 X<>Y	
		275 .END.	

PROGRAM DESCRIPTION

RANDOM SEED GENERATOR

The random seed generator may be used with any random number generator to provide an automatic seed, different every time, that will assure a long non-repetitive period. The routine takes the seconds and hundredths of seconds at the time it is called and multiplies them by the clock time to get a larger, unpredictable number. The number is then increased to a large value that will not exceed the precision of the HP-41 and tested to check for multiples of five or two which would appreciably shorten the period of the random number generator. If the number passes, it is converted to a fraction and returned to the calling routine. If it fails, the cycle is repeated with a new time until the number passes. The result will be a series of accidental digits, at least seven in length, ending in 1, 3, 7 or 9.

On test runs of up to 5000 iterations the 6 least significant digits exhibited the most randomness with a typical mean of .4995 to .501 and a standard deviation of .27.

The routine uses only the stack and requires no other subroutines, flags or data registers. It is used in the example problem with the random generator from the HP-41 Standard Pac, page 24, developed by Don Malm. It will generate one million distinct random numbers between 0 and 1 regardless of the initial starting value (seed). An excellent article listing several references on random number generation may be found in the July, 1980 issue of the Hewlett-Packard Journal, written by Homer Russell.

014	▶LBL "RZ"	
024	LBL 01	
03	TIME	
04	1 E2	
05	*	
06	FRC	
07	TIME	
08	ж.	
09	1 E8	
10	*	
11	INT	
12	STO Y	
13	5	
14	MOD	
15	X=0?	
16	GTO 01	
17	RCL Y	
18	2	
19	MOD	
20	X=0?	
21	GTO 01	
22	R↑	
23	1 E9	
24	1	
25	FRC	
26	.END.	

Use of local label will speed iterations if number fails test and routine must be reexecuted one or more times Separate seconds and hundredths from clock time Multiply by clock time to get larger number (more digits) Enlarge to a value that will remain within the precision of the HP-41 Truncate for test Save in stack Test if divisible by 5 If a multiple of 5, try another number Get large integer back Test for multiple of 2 If number fails, try again Get large number back if passed test Back to fraction, seed formed, exit

NOTES

~

HEWLETT-PACKARD HP-41 USERS' LIBRARY Time Module Solutions I

For the HP 82182A Time Module

Bar Codes

TIMER SOLUTIONS I

APPOINTMENT	CALE	NDAR	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	1
WORLD TIME	CONVE	RTER	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	7
EXERCISE MO	ONITOR	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	8
AUTOMOBILE	TRIP	COMPL	JTEF	r A	ND	SPE	ED	CAL	IBR	ATI	ON	•	•	•	•	•	•	11
FOUR-CHANNE	EL CON	TROLL	ER	•	•	•	•	•	•	•	•	•	•	•	•	•	•	16
LOGBOOK .	• •	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	20
"PLAYBACK"	PROGR	AMMAE	BLE	TI	MER	₹.	•	•	•	•	•	•	•	•	•	•	•	22
RANDOM SEE) GENE	RATOF	2	•	•	•	•		•		•	•	•	•	•	•	•	26

NOTICE

The program material contained herein is supplied without representation or warranty of any kind. Hewlett-Packard Company therefore assumes no responsibility and shall have no liability, consequential or otherwise, of any kind arising from the use of this program material or any part thereof.











APPOINTMENT CALENDAR LOAD-CARD READER VERSION PROGRAM REGISTERS NEEDED: 4


























FOUR CHANNEL CONTROLLER V PROGRAM REGISTERS NEEDED: 7













PLAYBACK PROGRAMMABLE TIMER FASTP PROGRAM REGISTERS NEEDED: 9



RANDOM SEED GENERATOR RZ PROGRAM REGISTERS NEEDED: 7



NOTES

NOTES

NOTES



Hewlett-Packard Software

In terms of power and flexibility, the problem-solving potential of the HP-41C programmable calculator is nearly limitless. And in order to see the practical side of this potential, HP has different types of software to help save you time and programming effort. Every one of our software solutions has been carefully selected to effectively increase your problem-solving potential. Chances are, we already have the solutions you're looking for.

Application Pacs

To increase the versatility of your HP-41C, HP has an extensive library of "Application Pacs". These programs transform your HP-41C into a specialized calculator in seconds. Included in these pacs are detailed manuals with examples, minature plug-in Application Modules, and keyboard overlays. Every Application Pac has been designed to extend the capabilities of the HP-41C.

You can choose from:

Aviation Clinical Lab Circuit Analysis Financial Decisions Mathematics Structural Analysis Surveying Securities Statistics Stress Analysis Games Home Management Machine Design Navigation Real Estate Thermal and Transport Science

Users' Library

The Users' Library provides the best programs from contributors and makes them available to you. By subscribing to the HP-41C Users' Library you'll have at your fingertips literally hundreds of different programs from many different application areas.

* Users' Library Solutions Books

Hewlett-Packard offers a wide selection of Solutions Books complete with user instructions, examples, and listings. These solution books will complement our other software offerings and provide you with a valuable tool for program solutions.

You can choose from:

Business Stat/Marketing/Sales Home Construction Estimating Lending, Saving and Leasing Real Estate Small Business Geometry High-Level Math Test Statistics Antennas Chemical Engineering Control Systems Electrical Engineering Fluid Dynamics and Hydraulics Civil Engineering Heating, Ventilating & Air Conditioning Mechanical Engineering Solar Engineering Calendars Cardiac/Pulmonary Chemistry Games Optometry I (General) Optometry II (Contact Lens) Physics Surveying

* Some books require additional memory modules to accomodate all programs.

TIME MODULE SOLUTIONS I

APPOINTMENT CALENDAR WORLD TIME CONVERTER EXERCISE MONITOR AUTOMOBILE TRIP COMPUTER AND SPEED CALIBRATION FOUR-CHANNEL CONTROLLER LOGBOOK "PLAYBACK" PROGRAMMABLE TIMER RANDOM SEED GENERATOR

THIS BOOK INCLUDES BARCODE FOR QUICK, EASY, ACCURATE ENTRY OF THESE PROGRAMS.

